

IGEL OS Base System



- What is New Knowledge Base Updates for IGEL OS 12.7.3 (see page 3)
- Introduction to IGEL OS 12 (see page 4)
- Configuration of IGEL OS 12 Device Settings (see page 6)
- Tray Applications in IGEL OS 12 (see page 358)
- Boot Process (see page 389)
- Articles on Deploying and Updating IGEL OS 12 (see page 394)
- Articles on Integrating IGEL OS 12 Devices Into Your Infrastructure (see page 525)
- Articles on Network Configuration in IGEL OS 12 (see page 531)
- Articles on Single-Sign On (SSO) with IGEL OS 12 (see page 542)
- Articles on Integrating IGEL Apps With Your Base System (see page 588)
- Articles about Securing IGEL OS 12 (see page 591)
- Articles about Hardware-Related Topics (see page 635)
- Articles on Miscellaneous Topics (see page 642)
- Troubleshooting: Error Message "Problem with libva for Chromium 2.16.0 BUILD 3.0 RC1" after Reboot (see page 643)
- Starting Methods for Apps (see page 644)

IGEL OS Base System 2 / 647



What is New - Knowledge Base Updates for IGEL OS 12.7.3

Using Structure Tags During Onboarding

Using structure tags during onboarding, newly registered devices will automatically have the information on where they are to be placed in the structure tree of the IGEL Universal Management Suite (UMS) Console. For details, see:

- Onboarding IGEL OS 12 Devices¹
- How to Automate the Rollout Process in the IGEL UMS²
- Using Structure Tags with IGEL OS Devices³.

IGEL OS Base System 3 / 647

^{1.} https://kb.igel.com/en/how-to-start-with-igel/current/onboarding-igel-os-12-devices

^{2.} https://kb.igel.com/en/universal-management-suite/current/how-to-automate-the-rollout-process-in-the-igel-um

^{3.} https://kb.igel.com/en/universal-management-suite/current/using-structure-tags-with-igel-os-11-devices



Introduction to IGEL OS 12

IGEL OS 12 is installed in the form of the IGEL OS Base System app.

Installation and Update


The Base System app can be installed on the devices through explicit app assignment in the IGEL Universal Management Suite (UMS) Web App. For more information on explicit app assignment, see IGEL UMS 12: Basic Configuration⁴ and How to Assign Apps to IGEL OS Devices via the UMS Web App⁵.

You can find information on how to update the Base System app in IGEL UMS 12: App Update⁶.

IGEL OS 12 Release Notes

You can find information about the apps and app versions in the IGEL App Portal⁷ in the **Description** and **History** tabs of the apps.

The component list of the IGEL OS Base System app can be found in the **Description** tab under **Read More**.



^{4.} https://kb.igel.com/en/universal-management-suite/current/migrate-a-ums-server-with-the-same-embedded-databa

IGEL OS Base System 4 / 647


^{5.} https://kb.igel.com/en/universal-management-suite/current/how-to-assign-apps-to-igel-os-devices-via-the-ums-

^{6.} https://kb.igel.com/en/how-to-start-with-igel/current/igel-ums-12-app-update

^{7.} https://app.igel.com/#/



The changelog of the IGEL OS Base System app can be found in the **History** tab.



IGEL OS Base System 5 / 647



Configuration of IGEL OS 12 Device Settings

This article explains how you can edit the system and session settings of IGEL OS 12 devices. Generally, you can change IGEL OS 12 device settings:

- via the UMS Web App using either profiles or the Device Configurator or, for some cases, Corporate Identity Customization (CIC) Configurator
- locally on the device via IGEL Setup

The best practice is to configure your devices via profiles in the UMS Web App. For customizing user interface settings in accordance with your company's corporate design standards, the use of CICs is recommended.

Configuration Options

You can use the following configuration methods:

Configura tion Method	Description	Opening Options
IGEL Setup	Configurations are made locally on the device. For more information, see IGEL Setup (see page 32).	 Starting methods defined under Accessories > Setup Keyboard command [Ctrl] + [Alt] + [s] Keyboard command [Ctrl] + [Alt] + [F2] in the appliance mode
Device Configurat or	The Device Configurator can be opened from the UMS Web App > Devices. Configurations made here have the same effect as local configurations.	 Double clicking on the device name Clicking the Edit Configuration button Selecting the Edit Configuration command in the context menu of the device
	For more information, see https://kb.igel.com/en/universal-management-suite/current/devices-view-and-manage-your-endpoint-devices-in-t.	

IGEL OS Base System 6 / 647




Configura tion Method	Description	Opening Options
Profile Configurat or	The Profile Configurator can be opened from the UMS Web App > Configuration > Profiles. Configurations are made through activating parameters to be defined by the profile and then applying the profile to the device. Note: When creating profiles, a Quick Setup mode is available for specific apps. It offers not all parameters for configuration, but only the most important ones that are necessary for starting to quickly use the app. For an overview of the Configuration area of the UMS Web App, see https://kb.igel.com/en/universal-management-suite/current/configuration-centralized-	Creating and assigning profiles to devices: • see https://kb.igel.com/en/universal-management-suite/current/how-to-create-and-assign-profiles-in-the-igel-ums- Opening existing profiles: • Double clicking on the profile name • Clicking the Edit Configuration button • Selecting the Edit Configuration command in the context menu of the profile
Identity Customiza tion (CIC)	The CIC Configurator can be opened from the UMS Web App > Configuration > Corporate Identity Customizations. The CIC Configurator provides the opportunity to cutomize the user interface of your devices in a more easier way than the other configuration methods.	Creating and assigning CICs: • see https://kb.igel.com/en/universal- management-suite/current/how-to-use- corporate-identity-customizations-in-ig Opening existing CICs: • Double clicking on the CIC name • Clicking the Edit Configuration button • Selecting the Edit Configuration command in the context menu of the CIC



Configurations applied through profiles take precedence and cannot be changed through other configuration methods. In other configuration methods, the parameter is grayed out and a lock symbol indicates that the setting is configured through a profile:

IGEL OS Base System 7 / 647






In the Device Configurator or IGEL Setup, hovering over the lock will display the name of the profile that defines the parameter.

 $For more information, see \ https://kb.igel.com/en/universal-management-suite/current/how-to-check-which-profiles-define-parameters-in-t.\\$

General GUI Elements of the Configurator Dialog



	GUI Element	Description
1	Search for Settings	Clicking the icon opens the Search for Settings tab. You can use free text to search for configuration pages and parameter fields. You can also search for registry keys by activating the toggle button for advanced search, and enabling the Include Registry option.
		Clicking on a search result displays the configuration page containing the result. The result is highlighted on the page.
		When a search result is clicked, the search menu remains displayed in the top right corner with the following navigation options:
		 arrows to go to the next or the previous search result search icon to expand the search tab X to close the search
2	Related Pages	Clicking the icon displays the Related Pages tab. The tab displays a list of pages that contain settings related to the settings on the current page.
3	Tooltip	Hovering over the icon displays information about the parameter.

IGEL OS Base System 8 / 647



	GUI Element	Description
4	Reset to default	Clicking the icon resets the parameter to the default value.
		In the Profile Configurator this icon is replaced by the parameter
		activator:


Adjustment Tracking in the Configurator Dialog



The adjustment tracker icon in the top right corner tracks the number of unsaved changes. Clicking the icon opens the **Unsaved adjustments** and the **All adjustments** tabs. The **Unsaved adjustments** tab displays a list of pages that contain unsaved changes. Clicking a page in the list opens the page. The unsaved changes are marked with an orange dot on the right side of the parameter. In the **All adjustments** tab, you find a list of pages that contain saved changes, grouped by tabs.


Navigation Tree Highlights

When using the configurator in the IGEL UMS Web App, your changes are marked with the following colored icons in the navigation tree for easier tracking.




IGEL OS Base System 9 / 647





The icons marking the type and status of the change have a display priority, with unsaved changes having the highest priority and saved changes having the lowest.

For example, if there is a saved change on one child page and a unsaved change on another child page, the parent page and the tab will be marked for the unsaved change.



Saving Changes and Exiting the Configurator Dialog

You have the following options to save changes and close the configurator:

- → Click **Save and Close** to save your changes and close the configurator.
- → Click **Close** if you have not made any changes and would like to abort the configurator. If you have made changes, a confirmation dialog is displayed. In the dialog, you have the following options:
 - Click **Discard** to close without saving the changes.
 - Click **Save and Close** to save the changes before closing.

IGEL OS Base System 10 / 647



- Click **Cancel** to go back and see the list of unsaved changes.
- → Click **Save** if you have finished configuring a setup area and would like to save your settings without closing the configurator.

Configurator Tabs

Settings for all apps except IGEL OS Base System app are displayed under the tab **Apps**.

IGEL OS Base System settings are grouped by function under the following tabs:

- Accessories in IGEL OS 12 (see page 12)
- User Interface (see page 41)
- Network (see page 129)
- Devices in IGEL OS12 (see page 206)
- Security Configuration in IGEL OS 12 (see page 228)
- System Configuration in IGEL OS 12 (see page 268)

IGEL OS Base System 11 / 647



Accessories in IGEL OS 12

In this chapter, you find information on the configuration of accessories in IGEL OS.

- Terminals in IGEL OS (see page 13)
- SSH Client (see page 15)
- VNC Viewer in IGEL OS 12 (see page 17)
- Network Tools (see page 18)
- Application Launcher (see page 22)
- App Portal (see page 25)
- System Information (see page 26)
- Screenshot Tool (see page 29)
- Setup (see page 32)
- System Log Viewer in IGEL OS 12 (see page 34)
- Task Manager (see page 37)

IGEL OS Base System 12 / 647




Terminals in IGEL OS

With a local terminal, you can execute local commands on your device. This article shows how to configure the starting methods for terminals, and how to use local terminals in IGEL OS.



it is also possible to access a local shell without a terminal session: Alternatively, you can switch to the virtual terminals tty11 and tty12 by pressing [Ctrl]+[Alt]+[F11] or [Ctrl]+[Alt]+[F12]. Pressing [Ctrl]+ [Alt]+[F1] takes you back to the user interface.

Menu path: Accessories > Terminals



Terminal Sessions

List of configured local terminal sessions

To manage the list of sessions, proceed as follows:

- Click to create a new entry.
- Click to remove the selected entry.
- Click / to edit the selected entry.
- Click to copy the selected entry.

IGEL OS Base System 13 / 647



→ Click to define the starting methods for the session.

The starting methods parameters are described under Starting Methods for Apps (see page 644).

Using Local Terminal

To use the local terminal, proceed as follows:

- 1. Start the local terminal.
- 2. Login as user or root.



If Use password is enabled in the Administrator area under Security > Password, you need to enter the administrator password to access a local terminal as root.

If an administrator password is set, accessing a local terminal as user is only possible if the following two conditions are met:

- Access to local terminals has been activated for user. This is possible with the registry key system.security.usershell under System > Registry. The default setting of the registry key forbids terminal access for user.
- Use password is enabled in the User area under Security > Password.

For accessing a local terminal as user, the user password has to be entered.

For more on password configuration, see Password and User Types in IGEL OS 128.

3. Enter the shell commands supported by IGEL OS.



For a collection of commands supported by IGEL OS, see the IGEL Community cheatsheet⁹.

IGEL OS Base System 14 / 647

^{8.} https://kb.igel.com/en/igel-os-base-system/12.6.1/password-and-user-types-in-igel-os-12


^{9.} https://www.igelcommunity.com/post/igel-os-linux-commands-cheatsheet



SSH Client

You can launch applications on a remote computer via SSH (Secure Shell). The display is usually on the terminal; X11 connections can also be routed via SSH. This article shows how to configure SSH sessions in IGEL OS.

Menu path: Accessories > SSH Client



Application via SSH

To manage the list of SSH sessions, proceed as follows:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.
- → Click to define the starting methods for the session.

The starting methods parameters are described under Starting Methods for Apps (see page 644).

IGEL OS Base System 15 / 647



Command

Menu path: SSH Client > [Session Name] > Command

Here, you can change the following settings:

Remote user name

User name under which the application runs on the remote computer. If left blank, user will be asked for it at session startup.

Remote Host

Host name or IP address of the remote computer.

Command Line

Command which is to be executed on the remote computer immediately after logging in.

Options

Menu path: SSH Client > [Session Name] > Options

Here, you can change the following settings:

Enable X11 connection forwarding

✓ X11 applications on the remote computer that are launched via the SSH session will be shown on your device. (Default)

 \square No X11 programs can be launched on the remote computer via the SSH session.

Enable compression

✓ The data will be compressed for transmission.

☐ The data will not be compressed for transmission. (Default)

Port

SSH port. (Default: 22)

IGEL OS Base System 16 / 647



VNC Viewer in IGEL OS 12



Starting from IGEL OS Base System 12.6.0, the VNC Viewer accessory was removed from the base system. The TigerVNC VNC Viewer app is offered as a replacement and a more flexible solution for VNC session types, see TigerVNC VNC Viewer¹⁰.

IGEL OS Base System 17 / 647


^{10.} https://kb.igel.com/en/igel-apps/current/tigervnc-vnc-viewer



Network Tools

This article shows the starting methods configuration and the use of Network Tools in IGEL OS. The tool provides network analysis, for example, Ping, Netstat, Traceroute.

Menu path: Accessories > Network Tools



You can configure the starting methods for an easy access of the Network Tool.

The starting methods parameters are described under Starting Methods for Apps (see page 644).


Starting from OS version 12.3.1, **Password protection** is not configurable and administrator credentials are required to start Network Tools.

Using Network Tools

->Start Network Tools.

IGEL OS Base System 18 / 647





To obtain information regarding a network device available on your device, proceed as follows:

- 1. Switch to the **Devices** tab.
- 2. Under **Network device**, select the network device for which you would like to obtain information. The information regarding the selected network device will be shown.

To send a ping query to a device in your network, proceed as follows:

1. Switch to the **Ping** tab.

IGEL OS Base System 19 / 647



- 2. Under **Network address**, enter the IP address or the host name of the device to which you would like to send a ping query.
- 3. If necessary, add the number of ping queries under **Send**.
- 4. Click **Ping**.

The set number of ping queries will be sent. The results will then be shown.

To obtain information regarding the network status of your device, proceed as follows:

- 1. Switch to the **Netstat** tab.
- 2. Select the desired information under **Display**:
 - Routing Table Information
 - Active Network Services
 - Multicast Information
- 3. Click **Netstat**.

The desired information will be shown.

To identify the router via which an IP data packet from your device reaches a specific target computer, proceed as follows:

- 1. Switch to the **Traceroute** tab.
- 2. Under **Network address**, give the IP address of the target computer.
- 3. Click **Trace**.

The device will send IP packets to the target computer at short intervals, each with a TTL (Time To Live, i.e. maximum number of hops) increased by 1.

When the packet reaches the target computer, "reached" will be shown in the last line and no further packet will be sent.

If no computer replies, "no reply" will be shown.

To obtain DNS information regarding an address on the Internet from your device, proceed as follows:

- 1. Switch to the **Lookup** tab.
- 2. Under **Network address**, give the IP address or the host name.
- 3. Under **Information type**, select which information is to be shown.

The following information types are available:

- Default Information
- Internet Address
- Canonical Name
- CPU / OS Type
- Mailbox Exchange
- Mailbox Information
- Name Server
- Host name for Address
- Text Information
- Well Known Services
- Any / All information
- 4. Click Lookup.

The desired information will be shown.

Further information regarding the DNS (Domain Name System) can be found on Wikipedia

IGEL OS Base System 20 / 647



under Domain Name System¹¹.

Detailed descriptions of the Domain Name concept can be found in RFC 1034¹² and in related RFCs.

^{11.} https://en.wikipedia.org/wiki/Domain_Name_System


^{12.} https://tools.ietf.org/html/rfc1034



Application Launcher

With the Application Launcher, you can launch predefined sessions, and device functions and tools. You are also given information regarding the device and the licenses used. This article shows how to configure the Application Launcher in IGEL OS.

Menu path: Accessories > Application Launcher



You can configure the starting methods for an easy access of the Application Launcher.


The starting methods parameters are described under Starting Methods for Apps (see page 644).

Application Launcher Configuration

Menu path: Application Launcher > Application Launcher Configuration

IGEL OS Base System 22 / 647





Hide system page

- ✓ The button for displaying the system tools (accessories) will not be shown.
- ☐ The 🌣 button for displaying the system tools (accessories) will be shown. (Default)

Show current user name in About, Application Launcher and start menu

- ✓ The current user will be shown at the top edge of the relevant window. (Default)
- ☐ The current user will not be shown.

in order for user names to be recognized and passed on, you must configure two settings beforehand:

- Enable using Active Directory/Kerberos under Security > Active Directory/Kerberos. For details, see Active Directory/Kerberos Configuration in IGEL OS 12 (see page 254)
- Enable local logon under Security > Logon > Active Directory/Kerberos. For details, see Active Directory/Kerberos - Enable Login in IGEL OS 12 (see page 242)

Single click mode

- Sessions are started with a single-click. Recommended for users of touchscreen monitors.
- ☐ Sessions are started with a double-click. (Default)

IGEL OS Base System 23 / 647



1 You can hide the shutdown menu from the Application Launcher using the Hide Shutdown menu **button** option under **User Interface > Commands > Shutdown Menu > Quick Access**. For more information, see Commands Session in IGEL OS 12 (see page 126) .

24 / 647 IGEL OS Base System



App Portal


This article shows how to configure the starting methods for the App Portal in IGEL OS.

0

To use the IGEL App Portal locally on the device, verify first that **Permit local app installation** is enabled under **Security > Update**. (Default)

For detailed information on how to use the App Portal, see *How to Start with IGEL > Installing IGEL OS Apps Locally on the Device*.

Menu path: Accessories > App Portal



The starting methods parameters are described under Starting Methods for Apps (see page 644).

IGEL OS Base System 25 / 647



System Information

This article shows the starting methods configuration and the use of System Information in IGEL OS. Through System Information, you can obtain information regarding the operating system of your device, the installed system components, internal and connected hardware, and the network. You can also measure the performance of your device using various benchmarks.


0

An administrator password is required by default to start **System Information** if **Use Password** is enabled under **Security > Password**. For details, see Password and User Types in IGEL OS 12¹³.

The password requirement can be changed through the **Password protection** option in the starting

The password requirement can be changed through the **Password protection** option in the starting methods configuration.

Menu path: Accessories > System Information



You can configure the starting methods for an easy access of the System Information.

The starting methods parameters are described under Starting Methods for Apps (see page 644).


IGEL OS Base System 26 / 647

^{13.} https://kb.igel.com/en/igel-os-base-system/12.6.1/password-and-user-types-in-igel-os-12




Using System Information

->Start System Information.



To obtain system information regarding a specific component of your IGEL OS device, proceed as follows:


- 1. Navigate to the desired area, e.g. **Computer > Operating System**. The information regarding the desired area will be shown.
- 2. To send the information shown, e.g. to the IGEL Support, click **Copy to Clipboard**. The information is on your clipboard. With **Paste** or [Ctrl] + [V], you can paste the information into an e-mail or a web form.



^{14.} https://kb.igel.com/en/igel-os-base-system/12.6.1/usb-access-control-in-igel-os-12

IGEL OS Base System 27 / 647






IGEL OS Base System 28 / 647



Screenshot Tool

This article shows the starting methods configuration and the use of the Screenshot Tool in IGEL OS.

Menu path: Accessories > Screenshot Tool



You can configure the starting methods for an easy access of the System Information.

The starting methods parameters are described under Starting Methods for Apps (see page 644).

Using Screenshot Tool

1. Start the Screenshot Tool.



2. Select a **Region to capture** option. You have the following options:

IGEL OS Base System 29 / 647



• Entire screen


The entire screen content will be photographed.

Active window

The window that is currently active will be photographed.

• Select a region

You can select a section of the screen using the mouse.




- 3. Set the **Capture the mouse pointer** option.
 - ✓ The mouse pointer is visible on the screenshot.
- 4. Specify the **Delay before capturing** in seconds. The minimum value is 0.
- 5. Click OK.

If you have enabled **Entire screen** or **Active window**, the screenshot will be taken after the **Delay before capturing** has elapsed.

If you have enabled **Select a region**, you can select the desired part of the screen using the mouse. To do this, press and hold the left mouse button while dragging the mouse across the screen.

IGEL OS Base System 30 / 647





6. Specify how the screenshot is to be used.

You have the following options:

• Save

If this option is enabled, the screenshot will be saved in PNG format via your device. You can save the screenshot locally, on a network drive or on a USB mass storage device.

- Copy to the clipboard
 - If this option is enabled, the screenshot will be available in the device's local cache.
- Open with

If this option is enabled, the screenshot will be opened in your device's image viewer.


IGEL OS Base System 31 / 647



Setup

With the IGEL Setup, you can configure your endpoint device. This article shows how to configure the starting methods for the IGEL Setup in IGEL OS.

Menu path: Accessories > Setup



The starting methods parameters are described under Starting Methods for Apps (see page 644).


If you configure user types and passwords under **Security > Password**, a login window appears at the start of the IGEL Setup. For more information, see Password and User Types in IGEL OS 12 (see page 233).



If you do not configure the user types and passwords, the IGEL Setup can be opened without password protection.

IGEL OS Base System 32 / 647





->Select from the configured user types and provide the corresponding password.

The following user types can be configured to access the IGEL Setup:

- Administrator
- Setup administrator
- Setup user


IGEL OS Base System 33 / 647



System Log Viewer in IGEL OS 12

This article shows how to configure the System Log Viewer in IGEL OS. With this function, you can view your device's system logs.

Menu path: Accessories > System Log Viewer



You can configure the starting methods for an easy access of the System Log Viewer.

The starting methods parameters are described under Starting Methods for Apps (see page 644).

Options

Menu path: Accessories > System Log Viewer > Options

Here, you can add additional files to the files shown by default. The System Log Viewer shows the following files by default:

- /config/Xserver/card0
- /config/Xserver/monitor-info

IGEL OS Base System 34 / 647



- /config/Xserver/xorg.conf-0
- /var/log/Xorg.0.log
- /var/log/auth.log
- /var/log/daemon.log
- /var/log/igfmount.log
- /var/log/kern.log
- /var/log/syslog
- /var/log/tcsetup.log
- /wfs/user/setup-assistant.log

To add a further file to the display, proceed as follows:

- 1. Click
- 2. In the **Add** dialog, enter the path and the file name of the desired file. Example: /var/log/ splash.debug



if you want to add several files, you can also use the asterisk *. Example: /var/log/

*.log or /var/log/ *.txt

3. Click OK.

When the System Log Viewer is started, the file that you have added will be shown.



Known Issue


The added file is only shown after the restart of the device. The configuration will be reworked in a future release.

Using System Log Viewer

→ Start the **System Log Viewer**.

IGEL OS Base System 35 / 647





 $\,\rightarrow\,$ In the left-hand column, select the file that you want to view.

The selected file will be shown in the right-hand column.


IGEL OS Base System 36 / 647



Task Manager

The Task Manager provides an overview of the applications and other processes running on the device. It can be used to pause, end, or change the priority of processes. This article shows the starting methods configuration and the use of the Task Manager in IGEL OS.

Menu path: Accessories > Task Manager



You can configure the starting methods for an easy access of the Task Manager.

The starting methods parameters are described under Starting Methods for Apps (see page 644).

Using Task Manager

With the Task Manager, you can observe and influence applications and processes in the following ways:

- Determining device processor usage
- Determining device memory usage
- Determining processor usage by a specific application
- Determining memory usage by a specific application
- Pausing and continuing an application
- Closing an application
- Force closing an application

IGEL OS Base System 37 / 647



Changing the priority of an application

->Start the **Task Manager**.

To determine the device's total processor usage:

->Read the percentage value under CPU.




To calculate the value in bytes, click and enable **Show memory usage in bytes**.

To determine the extent to which a specific application contributes to processor usage, proceed as follows:

1. In the search window, enter the name of the application or part of the name. The Task Manager will now show only the relevant applications and processes.

2. Read the percentage value for the relevant application in the **CPU** column.



IGEL OS Base System 38 / 647




To determine the extent to which a specific application contributes to memory usage, proceed as follows:

- 1. Click next to and ensure that **Virtual Bytes** and **Private Bytes** are enabled.
- 2. In the search window, enter the name of the application or part of the name.

 The Task Manager will now show only the relevant applications and processes.
- 3. Read the values in the **VSZ** and **RSS** columns.

The **VSZ** column shows how much memory is available for the application. The **RSS** column shows

how much memory the application is currently using.



To pause an application, proceed as follows:

- 1. Highlight the application.
- 2. Open the application's context menu by right-clicking on it and select **Stop**.

 The application will be paused (Signal SIGSTOP). You can then continue the application.

To continue an application, proceed as follows:

- 1. Highlight the application.
- 2. Open the application's context menu by right-clicking on it and select **Continue**. The application will continue (Signal SIGCONT).

To close an application, proceed as follows:

IGEL OS Base System 39 / 647



- 1. Highlight the application.
- 2. Open the application's context menu by right-clicking on it and select **Terminate**. The application will close (Signal SIGTERM).
 - 1 In this case, the application is instructed to close by the operating system. If the application does not react to this instruction, you can force it to close with the **Kill** command.

To force an application to close, proceed as follows:

- 1. Highlight the application.
- 2. Open the application's context menu by right-clicking on it and select **Kill**. The application will be forced to close (Signal SIGKILL).

To change the priority of an application, proceed as follows:

- 1. Highlight the application.
- 2. Open the application's context menu by right-clicking on it and select **Priority**.
- 3. Select one of the following values for the priority:
 - Very low (nice value: 15)
 - Low (nice value: 5)
 - Normal (nice value: 0)
 - **High** (nice value: -5). This value can only be set by the administrator.
 - **Very high** (nice value: -15) This value can only be set by the administrator.
 - As a normal user, you can only change the priority from a higher value to a lower value. Example: If you have changed the priority from **Normal** to **Low**, you can only then change it to **Very low** you can no longer change it back to **Normal**. The administrator can increase the priority.
 - The priority corresponds to the nice value. High values result in a low priority, while low values result in a high priority.

IGEL OS Base System 40 / 647



User Interface

In this chapter, you find information on the configuration of the user interface in IGEL OS.

- Copy of Language Settings in IGEL OS 12 (see page 42)
- Language Settings in IGEL OS 12 (see page 44)
- Display Settings in IGEL OS 12 (see page 46)
- Screenlock / Screensaver in IGEL OS 12 (see page 57)
- Hotkeys (see page 68)
- Input (see page 70)
- Desktop Settings in IGEL OS 12 (see page 101)
- Commands Session in IGEL OS 12 (see page 126)


IGEL OS Base System 41 / 647



Copy of Language Settings in IGEL OS 12

This article shows how to configure the country-specific language settings in IGEL OS 12.

Menu path: User Interface > Language



Language

The language of the user interface.

Keyboard layout

When the language is changed for the first time, the keyboard layout is automatically set to the same language.

Show indicator in taskbar

✓ Shows a country abbreviation for the keyboard layout in the taskbar.

☐ No indicator is shown. (Default)

IGEL OS Base System 42 / 647



Input language

The default setting is geared to the selected keyboard layout.

Standards and formats

Sets the country-specific standards and formats, e.g. time and currency. The default setting is geared to the selected input language.


IGEL OS Base System 43 / 647



Language Settings in IGEL OS 12

This article shows how to configure the country-specific language settings in IGEL OS 12.

Menu path: User Interface > Language



Language

The language of the user interface.

Keyboard layout

When the language is changed for the first time, the keyboard layout is automatically set to the same language.

Show indicator in taskbar

✓ Shows a country abbreviation for the keyboard layout in the taskbar.

☐ No indicator is shown. (Default)

IGEL OS Base System 44 / 647



Input language

The default setting is geared to the selected keyboard layout.

Standards and formats

Sets the country-specific standards and formats, e.g. time and currency. The default setting is geared to the selected input language.

IGEL OS Base System 45 / 647



Display Settings in IGEL OS 12

This article shows how to configure the display settings for the monitors in IGEL OS.


Take notice that a successful and correct display configuration depends, however, on many factors. For example, cables, current driver, BIOS settings, etc. can influence your screen configuration and, thus, have to be considered when setting up the monitor environment.



You can also use the display tray app for display configurations. For more information, see Tray Applications in IGEL OS 12 (see page 358).

Also note the following: When the endpoint device is connected to different environments, such as when the user switches between different workplaces, it will attempt to store each monitor setup.

Menu path: User Interface > Display Settings



A

Always try the configuration locally before applying it to multiple devices via a profile: A faulty display configuration can cause your GUI to become unstable and lead to a black screen.

IGEL OS Base System 46 / 647



If you face a black screen problem because of the wrong display configuration, try one of the following recovery options:


- In the UMS: Edit the display configuration via **Devices > [device name] > [device's context menu] > Edit Configuration** or via a new profile.
- In Web UMS: Edit the settings by clicking **Edit Configuration** in the Device Information of the device under **Devices > [device name]**.
- On the endpoint device: Restart the device and select **Emergency boot (setup only)** during the boot procedure. In the Setup, you can then change the display configuration.

General Settings

Number of screens

The number of monitors used can be selected by clicking the numbered buttons.

In a multimonitor configuration, every screen connected to the endpoint device can be configured independently after selecting the screen. The selected screen is highlighted with a yellow frame. The white bar at the bottom edge of the screen represents the physical orientation of the monitor. The position of the screens can be configured by drag&drop.



Screen resolution

The resolution can be selected from a drop-down menu. (Default: Autodetect)

IGEL OS Base System 47 / 647



- You have the option of defining your own resolutions via the registry key x.xserver0.custom_resolution. In order for the values set there to take effect, the resolution must be set to **Autodetect**. The following parameters apply to the entry in the registry:
 - WxH: W = width, H = height (example: 1920x1080)
 - WxH@R : W = width, H = height, R = refresh rate (example: 1920x1080@60 or 1920x1200@59.8)

Be careful when changing resolutions manually. Excessively high resolutions can cause a black screen.

- For details of the display resolution supported by your IGEL device, please see the datasheet archive for legacy IGEL devices¹⁵.

For detailed instructions on MST configuration for UD3 and UD7, see:

- UD3 Model M350C: Multistream Transport
- UD7 Model H860C: Multistream Transport Monitor Daisy Chaining

Screen rotation

The rotation can be selected from a drop-down menu. (Default: None)

Advanced Settings for the Screen

Detect refresh rate automatically

- ✓ A refresh rate for the monitor is identified automatically. (Default)
- \square A refresh rate for the monitor is to be set manually.

Refresh rate

Number of individual images per second Possible values:

• **30 ... 100** (Default: 60)



Be careful when changing the refresh rate manually since a faulty configuration can cause a black screen.

Graphic card

Graphic card assigned to the selected screen. A graphic card can have more outputs than are actually used. In order to ensure transparency, you may need to assign the graphic cards manually.

IGEL OS Base System 48 / 647

^{15.} https://kb.igel.com/knowledge-base-archive/current/datasheet-archive





If Automatic is set for the Monitor and no configurable monitor is found for the selected graphic card, the next available monitor will be used by another graphic card.

Monitor

Connection type. (Default: Automatic)

- Power Options of the Display in IGEL OS 12 (see page 50)
- Access Control to the Display in IGEL OS 12 (see page 52)
- Gamma Correction (see page 54)
- DPI Options (see page 55)

49 / 647 IGEL OS Base System




Power Options of the Display in IGEL OS 12

This article shows how to configure energy-saving stages in IGEL OS.



Changing the default settings may result in higher power consumption and shorter battery runtime.

Menu path: User Interface > Display Settings > Power Options > Power Management / Brightness Reduction



Power Management

Handle display power management

✓ The DPMS energy saving functions are enabled. (Default)



The display must support Display Power Management Signaling (DPMS).

On Battery / Plugged In

You can select time frames after which energy-saving modes get activated. The time frames are configured separately for **On Battery** and **Plugged In** use of the device. When **Never** is selected, the energy-saving mode is disabled.

The following energy-saving modes can be configured:

IGEL OS Base System 50 / 647



• Standby Time

After this time frame, the device goes to standby mode.

Suspend Time

After this time frame, the device goes to sleep mode.

• Off Time

After this time frame, the device turns off.



A Chronologically, **Standby** mode must occur before or simultaneously with **Suspend** mode, and **Suspend** mode must occur before or simultaneously with **Off** mode. Therefore, verify that the customized timeout values are greater than or equal to the timeout values of earlier modes: **Standby Time ≤ Suspend Time ≤** Off Time.

Inconsistent values will result in BadValue error.

Brightness Reduction

These settings are relevant for mobile devices resp. for devices with integrated display.

If a device is switched on but not used for some time, energy can be saved by brightness reduction. The values of the reduction are configured separately for **On Battery** and **Plugged In** use of the device.

On Battery / Plugged In

On inactivity reduce to

The percent value to which the brightness is reduced after a period of inactivity.

Reduce after

The period of inactivity after which brightness is reduced. You can set the period between 10-120 seconds. Setting the value to 9 deactivates the reduction.


IGEL OS Base System 51/647



Access Control to the Display in IGEL OS 12

This article shows how to control access to the display in IGEL OS. Device access control is enabled by default.

Menu path: User Interface > Display Settings > Access Control



Disable console switching

✓ You can NOT switch to the console using [Ctrl] + [Alt] + [F11] or [Ctrl] + [Alt] + [F12].

☐ You can access the console using [Ctrl] + [Alt] + [F11] or [Ctrl] + [Alt] + [F12]. (Default)

Access control

✓ Access to this display from other computers will be controlled. (Default)

Disable TCP connections

✓ All TCP connections to the display are disabled. Only local applications are displayed. The xhost mechanism does not function. (Default)

This parameter is ignored if XDMCP is configured.

IGEL OS Base System 52 / 647



List of Trusted X Hosts

List of approved computers for console access

To manage the list:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

When adding the **Trusted host**, give the name of the remote host (not the IP address) you would like to add.


IGEL OS Base System 53 / 647



Gamma Correction

This article shows how to increase or decrease the various brightness ranges in order to adjust the display on your screen in IGEL OS.

Menu path: User Interface > Display Settings > Gamma Correction



You can change the gamma values for red, green and blue on each screen separately. The scale ranges from 0.10 (dark) to 10 (light) and is set to 1.00 by default.

Gamma Value Red

Changes the brightness curve for the red color portion.

Gamma Value Green

Changes the brightness curve for the green color portion.

Gamma Value Blue

Changes the brightness curve for the blue color portion.


IGEL OS Base System 54 / 647



DPI Options

This article shows how to configure DPI values for the display in IGEL OS.

Menu path: User Interface > Display Settings > DPI Options



Monitor DPI detection

Defines how the DPI value should be determined. Possible options:

- Off: The DPI value is defined by Monitor DPI. There is no automatic detection.
- **Smart** (Default):

The DPI value is defined automatically. With this setting, the user interface is readable also on monitors with very high resolutions, e.g. 4k monitors. The DPI value is set to either 96, 125, 150, 175, 200, 225, 250, 275 or 300, depending on which value is closest to the value calculated based on the monitor resolution.

• Pixel-Precise:

The DPI value is defined automatically. With this setting, the user interface is readable also on monitors with very high resolutions, e.g. 4k monitors. The value calculated based on the monitor resolution is used directly.

Monitor DPI

IGEL OS Base System 55 / 647



The DPI resolution (dots per inch) for your monitor. (Default: 96) This parameter is only available if **Monitor DPI detection** is set to **Off**.

IGEL OS Base System 56 / 647



Screenlock / Screensaver in IGEL OS 12


This article shows how to configure the starting methods for the screenlock and screensaver in IGEL OS.

0

The automatic activation of the screensaver separate from the screenlock can be configured under **Screenlock / Screensaver > Options**. For details, see Screenloock/Screensaver Options in IGEL OS 12 (see page 58).

The look of the taskbar on the locked screen can be configured under **Screenlock / Screensaver > Taskbar**. For details, see Taskbar in Locked Screen in IGEL OS 12 (see page 61).

Menu path: User Interface > Desktop > Screenlock / Screensaver



You can configure the screenlock and screensaver to be activated via icons in the Quick Start Panel and on the desktop or via hotkey.

The starting methods parameters are described under Starting Methods for Apps (see page 644).

- Options (see page 58)
- Taskbar (see page 61)
- Screensaver in IGEL OS 12 (see page 65)


IGEL OS Base System 57 / 647



Options

This article shows how to configure the setting options for the screenlock and the screensaver in IGEL OS.

Menu path: User Interface > Screenlock / Screensaver > Options



Start automatically

✓ The screenlock and screensaver starts automatically if there is no activity on the device within the **Timeout** period. Depending on the configurations under **Require password to unlock (screenlock)** and **Allow administrator password**, the screen can be unlocked with the local user/administrator password. (Default)

Timeout

Period of time in minutes before the screenlock and the screensaver starts. (Default: 5)

Require password to unlock (screenlock)

✓ If a user is logged in, the same authentication is required to unlock the screen. For example, if the user is logged in via Active Directory (AD), the AD credentials are used to unlock the screen. For more information, see Active

IGEL OS Base System 58 / 647



Directory/Kerberos - Enable Login in IGEL OS 12 (see page 242). The authentication methods can be configured under Security > Logon. For more information, see Logon Settings in IGEL OS 12 (see page 238). (Default)

□ The screen can be unlocked without authentication.

Different screenlock timeout

□ You can specify a time limit for the screenlock to activate separately from the screensaver.

□ The same time limit will be used for the screenlock and the screensaver. This means that after the set time the screen will be locked and then the screensaver will appear. (Default)

Screenlock timeout

Period of time in minutes before the screenlock starts. (Default: 5)

Allow administrator password

□ Access is allowed for the user and the administrator. The screen can also be unlocked by the administrator password, if the administrator password is configured. For more information, see Password and User Types in IGEL OS 12 (see page 233).

□ Access is allowed for the user only. (Default)

Countdown duration in seconds

Countdown time after which the screenlock is initiated. If the value is 0, the screen is locked without a countdown. (Default: 0)



The appearance of the digits for the countdown is specified together with the settings for the clock display under **Screenlock / Screensaver > Screensaver**. The following parameters are relevant for the countdown:

- Clock display monitor
- Show seconds
- Horizontal clock position
- Vertical clock position
- Clock background color
- Clock foreground color

For detailed information, see Screensaver in IGEL OS 12 (see page 65) .

Countdown visual effect

While the countdown is running, a current screenshot is displayed in the background. This parameter determines the visual effect that the screenshot will be displayed with. Possible options:

- Dark screenshot
- Gray screenshot

IGEL OS Base System 59 / 647



Countdown background image

Path and file name of an image file, which is displayed in the background while the countdown is running. This background image is displayed instead of the screenshot, if the path and file name are valid; if the field is empty, the screenshot is displayed. Supported file formats: JPEG, PNG, GIF. Example: /images/image.jpg


IGEL OS Base System 60 / 647



Taskbar

This article shows how to configure the taskbar for the login dialog and for when the screen is locked in IGEL OS.

Menu path: User Interface > Desktop > Screenlock / Screensaver > Taskbar



You can use the following parameters to enable / disable access to tray apps when the screen is locked. The parameters for the desktop (that can be found under **User Interface > Desktop > Taskbar Items**) and the parameters for the lockscreen are independent from each other. You need to enable / disable the icons for both use cases separately. For more information, see Tray Applications in IGEL OS 12 (see page 358) and Taskbar Items in IGEL OS 12 (see page 113).

Show UMS connection status tray icon on lockscreen

When the screen is locked, the current status of the Universal management Suite (UMS) connection is shown in the system tray. For example, with the icon for connected. Clicking the icon displays information about the connected UMS server. (Default)

Show battery tray icon on lockscreen

When the screen is locked, the current status of the battery is shown in the system tray. For example, with the icon . Hover over the icon to see information on the charge. Clicking the icon displays the battery tray app. (Default)

Show ethernet connection status tray icon on lockscreen

IGEL OS Base System 61 / 647



✓ The current status of the LAN network connection is shown in the system tray. For example, with the icon for connected. Clicking the icon displays the LAN tray app. (Default)
Show wifi connection status tray icon on lockscreen
✓ The current status of the Wi-Fi network connection is shown in the system tray. For example, with the icon Clicking the icon displays the Wi-Fi tray app. (Default)
Show mobile-broadband connection status tray icon on lockscreen
✓ The current status of the network connection is shown in the system tray. For example, with the icon Clicking the icon displays the mobile broadband tray app. (Default)
Show input settings tray icon on lockscreen
✓ If a mouse is detected, the 😊 icon is shown in the system tray. If a touchpad is detected, or both a mouse and a
touchpad are detected, the 🔲 icon is shown. Clicking the icon displays the mouse & touchpad tray app.
☐ The icon is not shown when the screen is locked. (Default)
Show audio tray icon on lockscreen
☑ The 🜒 and 🛂 icons are shown in the system tray. Clicking the icon displays the sound tray app.
☐ The icon is not shown when the screen is locked. (Default)
Taskbar Settings for the Login Dialog
Show taskbar in login screen
✓ A taskbar is shown in the login screen. (Default)
Show clock
✓ A clock is shown in the taskbar in the login screen. (Default)
Show keyboard layout switcher
✓ A keyboard layout switcher is shown in the taskbar in the login screen. (Default)
Show on-screen keyboard button
${m ec{\!$
☐ The button is not shown. (Default)

IGEL OS Base System 62 / 647

Show shutdown button



Start on-screen keyboard automatically
✓ The on-screen keyboard is started automatically with the login screen.
☐ The on-screen keyboard is not started automatically. (Default)
Show reboot button
✓ The reboot button is shown in the taskbar in the login screen.
☐ The button is not shown. (Default)
Show shutdown button
✓ The shutdown button is shown in the taskbar in the login screen. (Default)
Taskbar Settings When the Screenlock Is Active
Show taskbar in screenlock
✓ A taskbar is shown when the screen is locked. (Default)
Show clock
✓ A clock is shown in the taskbar when the screen is locked. (Default)
Show keyboard layout switcher
✓ A keyboard layout switcher is shown in the taskbar when the screen is locked. (Default)
Show on-screen keyboard button
🗹 A button to start an on-screen keyboard is shown in the taskbar when the screen is locked.
☐ The button is not shown. (Default)
Start on-screen keyboard automatically
✓ The on-screen keyboard is started automatically when the screen is locked.
\square The on-screen keyboard is not started automatically. (Default)
Show reboot button
✓ The reboot button is shown in the taskbar when the screen is locked.
☐ The button is not shown. (Default)

IGEL OS Base System 63 / 647



$ ule{\hspace{-0.1cm} \hspace{-0.1cm} \checkmark}$ The shutdown button is shown in the taskbar when the screen is locked.	
☐ The button is not shown. (Default)	
Show logoff button	
✓ The logoff button is shown in the taskbar when the screen is locked.	

IGEL OS Base System 64 / 647




Screensaver in IGEL OS 12

This article shows how to configure the screensaver in IGEL OS.

You can configure the activation of the screensaver under **Screenlock / Screensaver > Options**. For details, see Screenloock/Screensaver Options in IGEL OS12 (see page 58).

Menu path: User Interface > Desktop > Screenlock / Screensaver > Screensaver



Screen background color

Color palette for determining the background color of the screen in screensaver mode. Click the color preview square to open the color selector.

Enable image display

✓ An image will be shown as the screensaver. (Default)

File for screensaver logo

IGEL OS Base System 65 / 647



Complete path for an individual image file or directory that contains an unlimited number of images. If no path is given, the IGEL logo will be used.



if you enter a folder instead of a single image file as the source, all images in the folder will be displayed as a slide show. The display time for the images can be configured under Image duration.

One image per monitor

☑ If a number of monitors are used, a different image will be shown on each one. (Defa	ıult)
--	-------

☐ Images will be distributed over the monitors.

Image duration

Time in seconds until the image is changed. (Default: 10)

Image display mode

Type of display. The following are available to choose from:

- Small-sized hopping: Small images are shown in changing positions. (Default)
- **Medium-sized hopping:** Larger images are shown in changing positions.
- Full-screen center cut-out: The images are shown in full-screen size. However, they may be
- Full-screen letterbox: The images are shown as large as possible in relation to the screen size.

Clock display monitor

Selects the monitor on which the clock is to be shown. The following are available to choose from:

- None (Default)
- All
- Display [1-8]

Show seconds

✓ Time is shown with seconds in digital format.

☐ Time is shown without seconds in digital format. (Default)

Clock display size

The following sizes are available to choose from:

- Tiny
- Small
- Medium
- Large

IGEL OS Base System 66 / 647



• Huge

Horizontal clock position

The following screen positions are available to choose from:

- Left
- Center
- Right

Vertical clock position

The following screen positions are available to choose from:

- Top
- Center
- Bottom

Clock background color

Color palette for determining the background color of the clock. Click the color preview square to open the color selector.

Clock background opacity percentage

The opacity of the clock background. (Default: 75)

Clock foreground color

Color palette for determining the color of the numbers displayed. Click the color preview square to open the color selector.


IGEL OS Base System 67 / 647



Hotkeys

Hotkeys configured for frequently used operations make it easier to use the device. A hotkey is a combination of one or more modifiers and an alphanumeric key. This article shows how to configure hotkeys in IGEL OS.

Menu path: User Interface > Hotkeys



Editing Hotkeys

You can enable or disable hotkeys and change the keys used:

- 1. Click to edit the hotkey of the selected operation.
- 2. Use the **Hotkey** option to enable the hotkey.
- 3. Select a predefined **Modifier**.

A modifier is a key symbol or key combination. These are the pre-defined modifiers and the associated key symbols:

• None: No modifier is used

• Shift: 🔐

• Ctrl: [Ctrl]

• Win:

IGEL OS Base System 68 / 647



- i When this keyboard key is used as a modifier, it is represented as Win; when it is used as a key, it is represented as Super_L.
- **Alt**: [Alt]

Key combinations are formed as follows with | :

- **Ctrl|Alt**: [Ctrl] + [Alt]
- 4. Enter a **Key** that is to be used as the hotkey to start the operation.
 - To enter a key that does not have a visible character, e. g. the [Tab] key, open a terminal, log on as user and enter xev -event keyboard. Press the key to be used for the hotkey. The text in brackets that begins with keysym contains the key symbol for the **Key** field. Example: Tab in (keysym 0xff09, Tab)
- 5. Click Confirm.

69 / 647 IGEL OS Base System



Input

The following input devices can be configured in IGEL OS.

- Keyboard Settings in IGEL OS 12 (see page 71)
- Additional Keyboard Layouts in IGEL OS 12 (see page 78)
- Mouse Settings in IGEL OS 12 (see page 80)
- Touchpad Settings in IGEL OS 12 (see page 84)
- Touchscreen Configuration in IGEL OS 12 (see page 92)


IGEL OS Base System 70 / 647



Keyboard Settings in IGEL OS 12

This article shows how to configure the keyboard settings in IGEL OS.

Menu path: User Interface > Input > Keyboard



Keyboard layout

Specify the keyboard layout. The selected layout applies to all parts of the system including emulations, window sessions and X applications.

Enable dead keys

✓ Dead keys can be used to enter special characters.

☐ Dead keys cannot be used to enter special characters. (Default)

Keyboard type

Specifies the keyboard type. Possible values:

IGEL OS Base System 71 / 647



- **Default**: Automatically selects the keyboard type according to the computer type (Macbook, Chromebook or PC105 for all others).
- Standard PC keyboard (105 keys)

☐ The secure keyboard input mode is disabled. (Default)

- IBM keyboard (122 keys)
- Trimodal keyboard
- Sun Type 6 keyboard
- Chromebook
- Macbook

Macbook internationalThinkpad
Show indicator in taskbar
✓ Shows the language code for the keyboard in the taskbar.
\square Hides the language code for the keyboard in the taskbar. (Default)
Repeat delay
Determines the delay (in milliseconds) before automatic repetition begins. (Default: 660)
Repeat rate
Determines the number of times a character repeats per second. (Default: 40)
Test
Free-text area to test the repeat settings.
Start with NumLock on
✓ NumLock will be enabled automatically during the boot process. (Default)
Secure keyboard input with Cherry SECURE BOARD
✓ A secure keyboard input mode will be enabled for the connected Cherry SECURE BOARD. In this mode, keyboard traffic between the keyboard and the endpoint is transmitted over a TLS 1.3 encrypted connection. The standard keyboard channel will be locked, which means that keyboard input devices without the secure mode will be blocked; see https://www.cherry-world.com/cherry-secure-board-1-0.html.

IGEL OS Base System 72 / 647




Input Methods for Keyboard in IGEL OS 12

This article shows how to configure keyboard input methods in IGEL OS. This is necessary if the settings under **User Interface > Language** (see page 44) do not suit your needs and you require, for example, input support for the Chinese or Japanese languages. The feature is currently experimental.

Input Methods

Menu path: User Interface > Input > Keyboard > Input Methods



Keyboard input methods (experimental)

Input Method Editor (IME) support is activated. You can select the required input method under **Methods** (see page 74) and initial states under **Intelligent Pinyin** (see page 76).

☐ Input Method Editor (IME) support is disabled. (Default)

Next input method

Defines keyboard shortcuts to toggle between input methods defined under **Methods** (see page 74) and keyboard layout defined under **User Interface > Input > Keyboard**. (Default: <Super>space)

Rules for the hotkeys:

• Use angle brackets <> for a modifier.

IGEL OS Base System 73 / 647



- Type the name of the key right after a modifier, without blanks.
- Use a blank to separate several hotkeys.
 Example: <Super>space <Shift><Alt>m

Candidates orientation

Specifies how all the possible characters for an input code will be shown.

Possible values:

- vertical (Default)
- horizontal

Show property panel

Specifies if the property panel should be displayed. Properties in the panel change depending on the selected input method.



Possible values:

- do not show (Default)
- hide automatically
- always

Auto hide timeout


A period of time in milliseconds during which the property panel will be displayed after focus-in or property change. This setting is relevant if **Show property panel** is set to "hide automatically".

Methods

Menu path: User Interface > Input > Keyboard > Input Methods > Methods

IGEL OS Base System 74 / 647





After activating **User Interface > Input > Keyboard > Input Methods > Keyboard input methods**, you can select the following input methods:

Chinese Intelligent Pinyin

- ✓ Intelligent Pinyin can be used as an input method for Chinese.
- ☐ Intelligent Pinyin cannot be used. (Default)

Chinese Bopomofoto

- ✓ Bopomofoto can be used as an input method for Chinese.
- ☐ Bopomofoto cannot be used. (Default)

Japanese - Mozc


- ✓ Mozc can be used as an input method for Japanese.
- ☐ Mozc cannot be used. (Default)

Enabled input methods as well as available IME functions can be selected via the corresponding icon in the system tray.

Examples:


IGEL OS Base System 75 / 647





Intelligent Pinyin

Menu path: User Interface > Input > Keyboard > Input Methods > Intelligent Pinyin



The following settings are relevant if **Chinese Intelligent Pinyin** is activated as an input method under **User Interface > Input > Keyboard > Input Methods > Methods**.

Initial state Chinese

IGEL OS Base System 76 / 647



✓ The keyboard input is initially set to Chinese. (Default)
☐ The keyboard input is initially set to English.
Initial state full width
✓ Initially, full-width characters are used.
\square Initially, half-width characters are used. (Default)
Initial state full punctuations
✓ Initially, full-width punctuation is used. (Default)
\square Initially, half-width punctuation is used.
Initial state Simplified Chinese
✓ The keyboard input is initially set to Simplified Chinese. (Default)
☐ The keyboard input is initially set to Traditional Chinese.

IGEL OS Base System 77 / 647




Additional Keyboard Layouts in IGEL OS 12

This article shows how to configure additional keyboard layouts in IGEL OS.

For information on how to configure an on-screen keyboard, see On-screen Keyboard (see page 96).

Menu path: User Interface > Input > Additional Keyboard Layouts



Layout [1-3]

Enable this layout

✓ Keyboard layout is enabled and can be defined.

☐ Keyboard layout is disabled. (Default)

Keyboard layout

Selects the language for the keyboard layout.

Enable dead keys

IGEL OS Base System 78 / 647

Modifiers

Additional modifier for the hotkey



Enable this function if the keyboard used supports dead keys for special characters. Hotkey ✓ A hotkey can be used to switch to this keyboard. ☐ The hotkey is disabled. (Default) Key Key for the hotkey **Modifiers** Additional modifier for the hotkey Hotkey for Default Keyboard Layout Activate hotkey to switch to the default keyboard layout ✓ A hotkey can be used to take you back to the default keyboard layout. This is useful when a number of keyboard layouts are configured. ☐ The hotkey is disabled. (Default) Hotkey Key for the hotkey **Modifiers** Additional modifier for the hotkey Hotkey for Next Keyboard Layout Activate hotkey to switch between a number of keyboard layouts ✓ A hotkey which switches to the next keyboard layout can be used. This is useful when a number of keyboard layouts are configured. ☐ The hotkey is disabled. (Default) Hotkey Key for the hotkey


IGEL OS Base System 79 / 647



Mouse Settings in IGEL OS 12

This article shows the mouse settings that you can configure in IGEL OS 12.

Menu path: User Interface > Input > Mouse



Left-handed mode

✓ The mouse is in left-handed mode.

☐ The mouse is in right-handed mode. (Default)

Natural scroll

When scrolling with the mouse wheel, the screen content moves in reverse to the wheel movement. If you scroll the wheel down, the screen moves upwards and vice-versa.

☐ When scrolling with the mouse wheel, the screen content moves synchronously to the wheel movement. If you scroll the wheel down, the screen moves downwards and vice-versa. (Default)

IGEL OS Base System 80 / 647



Emulate 3 button mouse

☑ Enables emulation of the third (middle) mouse button for mice with only two physical buttons. This third button is emulated by pressing both buttons at the same time. The **Emulate timeout** determines how long (in milliseconds) the driver waits before deciding whether two buttons were pressed at the same time.

☐ Disables emulation of the third (middle) mouse button for mice with only two physical buttons. (Default)

Emulate timeout

Determines how long (in milliseconds) the driver waits before deciding whether two buttons were pressed at the same time.

Hide cursor

✓ The mouse pointer will be hidden after the defined time limit.

☐ The mouse pointer is never hidden. (Default)

Idle time for visible cursor

The period after which the pointer is hidden.

Pointer speed

Determines the mouse resolution in counts per inch.

Double click interval

Changes the maximum interval in milliseconds between two consecutive mouse clicks which are to be recognized as a double-click. The smaller the interval, the faster the consecutive clicks need to happen, to be recognized as a double click.

Double click distance

Changes the maximum distance in pixels between two clicks which are to be recognized as a double-click. The object under the second click is double-clicked.



If the Show input settings tray icon on desktop option is enabled under User Interface > Desktop > Taskbar Items, and a mouse is detected, you can use the Mouse & Touchpad tray app to quickly configure the following mouse settings:

Primary Button

Sets the primary button both for mouse and touchpad. In IGEL Setup, you can configure this through **Left-handed mode**.

Pointer Speed

Sets the speed of the pointer both for mouse and touchpad. In IGEL Setup, you can configure this through **Pointer speed**.

81 / 647 **IGEL OS Base System**



Double-click Speed


Sets how fast two consecutive mouse clicks need to happen to be recognized as a double-click. You can test this with the **click to test** area. In IGEL Setup, you can configure this through **Double click interval**. The smaller the interval, the faster the consecutive clicks need to happen, to be recognized as a double click.

• Scrolling Direction

Sets the direction of the screen movement when scrolling with the mouse. In IGEL Setup, you can configure this through **Natural scroll**.

IGEL OS Base System 82 / 647





IGEL OS Base System 83 / 647




Touchpad Settings in IGEL OS 12

This article shows the touchpad settings that you can configure in IGEL OS 12.

1 The actual settings depend on the hardware supported by the particular touchpad.

Menu path: User Interface > Input > Touchpad



Enable touchpad on boot

✓ The touchpad is enabled on boot. This can be overridden by the hotkey configured below. (Default)

Hotkey

- ✓ Each time you press the hotkey, you activate or deactivate the touchpad.
- ☐ No hotkey can be used to activate or deactivate the touchpad. (Default)

IGEL OS Base System 84 / 647



Modifiers
Modifiers for the hotkey
Key
Key for the hotkey
Natural Scroll
When scrolling through the touchpad, the screen content moves synchronously to the fingers' movement. If you move your fingers down, the screen moves downwards and vice-versa.
☐ When scrolling through the touchpad, the screen content moves in reverse to the fingers' movement. If you move your fingers down, the screen moves upwards and vice-versa. (Default)
Custom configuration
✓ Further touchpad settings can be configured according to your needs.
□ No custom configuration can be made. (Default)
Tapping mode
Switches the tapping mode on or off. Possible values:
With tapping (Default)Without tapping

Min speed

Minimum speed of the pointer in seconds. (Default: 1.00)

Max speed

Maximum speed of the pointer in seconds. (Default: 1.75)

Acceleration

Acceleration from the minimum to the maximum speed in seconds. (Default: 0.01)

With some touchpads, you can assign mouse actions to tapping the corners of the touchpad. The action can be configured for each corner to trigger a right, left, or middle mouse click.

- Top left action (Default: No action)
- **Top right action** (Default: Middle mouse button)

IGEL OS Base System 85 / 647



• Bottom left action (Default: No action)

• Bottom right action (Default: Right mouse button

If the **Show input settings tray icon on desktop** option is enabled under **User Interface > Desktop > Taskbar Items**, and a touchpad is detected, you can use the Mouse & Touchpad tray app to quickly configure the following touchpad settings:

Primary Button

Sets the primary button both for mouse and touchpad. In IGEL Setup, you can configure this through **Left-handed mode** under **User Interface > Input > Mouse**.

Pointer Speed

Sets the speed of the pointer both for mouse and touchpad. In IGEL Setup, you can configure this through **Pointer speed** under **User Interface > Input > Mouse**.

Enabled

The toggle buttons enables/disables the touchpad.

Touchpad Sensitivity

Sets how sensitive the touchpad is to the touch. In IGEL Setup, you can configure this through **Min speed**, **Max speed**, and **Acceleration**. If you have those values custom configured, it is advised not to change the slider in the tray app, as it will reset the levels in the IGEL Setup.

• Scrolling Direction

Sets the direction of the screen movement when scrolling with the touchpad. In IGEL Setup, you can configure this through **Natural scroll**.

Scrolling Method

Sets the type of finer movement to be detected as scrolling. In IGEL Setup, you can configure this through **Two finger vertical scroll** and **Two finger horizontal scroll** under **User Interface > Input > Touchpad > Scrolling**.

Tap to Click


The toggle switch enables/disables clicking with a tap on the touchpad. In IGEL Setup, you can configure this through **Tapping mode**.

Palm Detection

The toggle switch enables/disables palm detection. When enabled, it avoids triggering a function accidentally with the palm of your hand. The function must be supported by the device. In IGEL Setup, you can configure this through **Palm detect** under **User Interface > Input > Touchpad > Advanced**.

IGEL OS Base System 86 / 647





- Scrolling with Touchpad in IGEL OS 12 (see page 88)
- Advanced Touchpad Settings in IGEL IOS 12 (see page 90)

IGEL OS Base System 87 / 647




Scrolling with Touchpad in IGEL OS 12

This article shows how to configure the scrolling with the touchpad in IGEL OS.

8

In order to configure scrolling, **Custom configuration** needs to be enabled under **User Interface > Input > Touchpad**.

Menu path: User Interface > Input > Touchpad > Scrolling



Vertical scroll

✓ The right edge of the touchpad will be used as a vertical scrollbar. The vertical scroll speed can be set. (Default)

□ The right edge is not enabled as a scrollbar.

Vertical scroll speed

The distance from which scrolling is recognized when moving the finger in a vertical direction. (Default: 25)

Two finger vertical scroll

IGEL OS Base System 88 / 647



✓ Two-finger scrolling is enabled for vertical scrolling.				
☐ Two-finger scrolling is disabled. (Default)				
Horizontal scroll				
$\overline{m{arphi}}$ The bottom edge of the touchpad will be used as a horizontal scrollbar. The horizontal scroll speed can be se				
☐ The bottom edge is not enabled as a scrollbar. (Default)				
Horizontal scroll speed				
The distance from which scrolling is recognized when moving the finger in a horizontal direction. (Default: 25)				
Two finger horizontal scroll				
✓ Two-finger scrolling is enabled for horizontal scrolling.				
☐ Two-finger scrolling is disabled. (Default)				

IGEL OS Base System 89 / 647




Advanced Touchpad Settings in IGEL IOS 12

This article shows how to configure advanced settings of the touchpad in IGEL OS.

0

In order to configure advanced settings, **Custom configuration** needs to be enabled under **User Interface** > **Input** > **Touchpad**.

Menu path: User Interface > Input > Touchpad > Advanced



Corner coasting

✓ You can continue scrolling if your finger reaches the corner when scrolling vertically or horizontally along the touchpad edges. The scrolling continues while the finger stays in the corner.

☐ The scrolling stops as soon as the reaches the corner. (Default)

Circular scrolling

✓ You can scroll in a circle. In the selection menu, you can specify where to begint the circular scrolling.

☐ Circular scrolling is disabled. (Default)

Circular scroll trigger

IGEL OS Base System 90 / 647



Trigger region of the touchpad to start circular scrolling. Possible values:

✓ The tap and drag gesture ends only after an additional tap.

☐ The tap and drag gesture ends when you release the finger. (Default)

- All edges (Default)
- Top edge
- Top right corner
- Right edge
- Bottom right corner
- Bottom edge
- Bottom left corner
- Left edge
- Top left corner

Tap	and	drag	gesture
-----	-----	------	---------

✓ You can move items by tapping them and then touching again and dragging them by moving the finger on the touchpad. (Default)

Locked drags

Palm detect

✓ Avoids triggering a function accidentally with the palm of your hand. The function must be supported by the device.

☐ Palm detection is disabled. (Default)

ClickPad

✓ ClickPads are permitted. These are touchpads with so-called integrated soft buttons on which physical clicks are possible.

IGEL OS Base System 91 / 647




Touchscreen Configuration in IGEL OS 12

This article shows how to configure the touchscreen connected to your endpoint device in IGEL OS. To ensure that you can open the setup and navigate within it, the initial configuration should take place with a mouse and keyboard connected.

For information on how to calibrate the touchscreen, see Touchscreen Calibration (see page 95).

For information on how to configure an on-screen keyboard, see On-screen Keyboard (see page 96).

Menu path: User Interface > Input > Touchscreen



Enable touchscreen

✓ The touchscreen is enabled.

☐ The touchscreen is disabled. (Default)

Touchscreen type

Selects the touchscreen driver which is to be used. Possible options:

IGEL OS Base System 92 / 647



- EvTouch (USB) (Default)
- eGalax
- Elo Multitouch (USB)
- Elo Singletouch (USB)
- TSharc

Touchscreen already calibrated					
If you enable the touchscreen function, the touchscreen must be calibrated before use.					
✓ Calibration starts automatically after each system boot. (Default)					
□ Calibration does not start automatically after each system boot.					
Swap X and Y values					
✓ X values are interpreted as Y values and Y values as X values. Enable this option if the mouse pointer moves vertically when you move your finger in a horizontal direction. Enable if the touchscreen is used rotated by 90°.					
☐ X and Y values are not swapped. (Default)					
Minimal X value / Minimal Y value					
These values are determined by the calibration tool. However, you can also change them manually. (Default: 0)					
Maximal X value / Maximal Y value					
These values are determined by the calibration tool. However, you can also change them manually. (Default: 4000)					
Emulate right button					
✓ A right-click is generated by touching the screen for the period of time defined under Right button timeout .					
☐ Touching the screen for a long time does not generate a right-click. (Default)					

Right button timeout

Time (in milliseconds) after which a right-click is generated. (Default: 1000)

Multimonitor

Graphic card

Graphics card assigned to the selected touchscreen. A graphics card can have more outputs than are actually used. In order to ensure transparency, you may need to assign the graphics cards manually.



If **Automatic** is set for the **Touchscreen monitor** and no configurable monitor is found for the selected graphics card, the next available monitor will be used by another graphics card.

93 / 647 IGEL OS Base System



Touchscreen monitor

Assigns a monitor connection to the touchscreen. Example: **DisplayPort**. (Default: Automatic)

- Touchscreen Calibration (see page 95)
- On-screen Keyboard (see page 96)


IGEL OS Base System 94 / 647



Touchscreen Calibration

This article shows the starting options for the touchscreen calibration tool in IGEL OS.

Menu path: User Interface > Input > Touchscreen > Touchscreen Calibration



The starting methods parameters are described under Starting Methods for Apps (see page 644).


IGEL OS Base System 95 / 647



On-screen Keyboard

This article shows how to configure the starting methods for an on-screen keyboard in IGEL OS.

Menu path: User Interface > Input > Touchscreen > On-screen keyboard



The starting methods parameters are described under Starting Methods for Apps (see page 644).

- Appearance Configuration in IGEL OS 12 (see page 97)
- Application Integration in IGEL OS 12 (see page 99)

IGEL OS Base System 96 / 647




Appearance Configuration in IGEL OS 12

This article shows how to configure the appearance of the on-screen keyboard in IGEL OS.



The layout for the normal keyboard is used for the on-screen keyboard.

Menu path: User Interface > Input > Touchscreen > On-screen keyboard > Appearance



Show function keys

✓ The on-screen keyboard features the function keys [F1] ... [F12]. (Default)

Show navigation keys

✓ The on-screen keyboard features the arrow keys for navigating on the screen. (Default)

Show Numpad

✓ The on-screen keyboard features the number block.

 \square The on-screen keyboard does not feature the number block. (Default)

IGEL OS Base System 97 / 647



Enable switching to alternative layout

✓ The on-screen keyboard has an additional key by which the user can toggle between the normal layout and a reduced layout. The reduced layout resembles the numpad, with the following differences:

- Additional backspace key [←]
- Additional tab key [♣]
- Additional space key []
- Additional escape key [Esc]
- Return key [↩] instead of [Enter] key

☐ Switching to the reduced layout is not possible. (Default)


IGEL OS Base System 98 / 647



Application Integration in IGEL OS 12

This article shows how to configure the integration of the on-screen keyboard in IGEL OS.

Menu path: User Interface > Input > Touchscreen > On-screen keyboard > Application Integration



Taskbar Settings for the Login Dialog

These settings are relevant if a login is necessary in order to use the device. This applies to all logon methods that are possible with the device.

Show on-screen keyboard button

✓ A button for launching the on-screen keyboard is shown during the login dialog.

☐ The on-screen keyboard cannot be launched during the login dialog. (Default)

Start on-screen keyboard automatically

✓ The on-screen keyboard is shown during the login dialog and can be used for input.

IGEL OS Base System 99 / 647



☐ The on-screen keyboard is not shown during the login dialog. However, it can be launched via a button if Show on-screen keyboard button is enabled. (Default)				
Taskbar Settings When the Screenlock Is Active				
Show on-screen keyboard button				
☑ A button for launching the on-screen keyboard is shown when the screen is locked.				
\Box The on-screen keyboard cannot be launched when the screen is locked. (Default)				
Start on-screen keyboard automatically				
✓ The on-screen keyboard is shown when the screen is locked.				
☐ The on-screen keyboard is not shown when the screen is locked. However, it can be launched via a button if Show on-screen keyboard button is enabled. (Default)				
On-Screen Keyboard Toggle Button				
Show button				
✓ A button for switching the on-screen keyboard on and off is shown on the desktop.				
☐ The toggle button is not shown. (Default)				
Button size				
The size of the toggle button. A size between 40 and 80 pixels can be chosen. (Default: 60px)				
Automatically show on-screen keyboard when text field is selected				
✓ The on-screen keyboard is shown automatically when an input field is selected.				
☐ The on-screen keyboard is not shown automatically. (Default)				


IGEL OS Base System 100 / 647



Desktop Settings in IGEL OS 12

This article shows how to configure general settings for the appearance of the desktop in IGEL OS.

Menu path: User Interface > Desktop



Local window manager for this display

✓ Enables local window management for the display. (Default)

User interface theme

You can either select one of our predefined color schemes or define a color scheme of your own.

- **IGEL color**: The color of dialog frames and the taskbar is blue, headings and icons are white, highlights are light blue.
- **IGEL dark**: The color of dialog frames and the taskbar is black, headings and icons are white, highlights are dark gray.
- **IGEL light**: The color of dialog frames and the taskbar is light gray, headings and icons are black, highlights are dark grey.
- Custom colors: Define your own color combinations below.
 - Base color of the UI theme: The color of dialog frames and the taskbar. Click the color preview square to open the color selector.

IGEL OS Base System 101 / 647



- **Highlight color of the UI theme**: The color of highlights. Click the color preview square to open the color selector.
- Icon and font color: The optimization can be selected based on custom colors.

Desktop icon size

The size of icons displayed on the desktop

Desktop icon font color

The font color for the labels associated with the desktop icons. Click the color preview square to open the color selector.

Monitor for desktop icons

If you use several monitors, select the one that is to display desktop icons.

- All monitors
- Same as taskbar
- 1st monitor
- 2nd monitor
- (other monitors if connected)

Single click mode

✓ Programs are opened with a single click. (Default)

Desktop Fonts

Default font

The font type of texts appearing on the taskbar and in the start menu. The following fonts are available to choose from:

- RobotoRegular (Default)
- Sans
- Sans Bold
- Serif
- Serif Bold

Default font size

The font size of texts appearing on the taskbar and in the start menu in pt (points).

Desktop icon font size

The font size of texts for desktop icons in pt (points).

IGEL OS Base System 102 / 647



Titlebar font

The font type of texts appering in titlebars. The following fonts are available to choose from:

- RobotoBold (Default)
- Sans
- Sans bold
- Serif
- Serif Bold

Titlebar font size

The font size of texts appearing in titlebars in pt (points).

- Background (1st Monitor) (see page 104)
- Taskbar Configuration in IGEL OS 12 (see page 108)
- Taskbar Background in IGEL OS 12 (see page 111)
- Taskbar Items in IGEL OS 12 (see page 113)
- Pager in IGEL OS 12 (see page 117)
- Start Menu in IGEL OS 12 (see page 122)
- In-Session Control Bar in IGEL OS 12 (see page 124)


IGEL OS Base System 103 / 647



Background (1st Monitor)

This article shows how to configure the desktop background in IGEL OS.

Menu path: User Interface > Desktop > Background (1st Monitor)



You can use predefined IGEL backgrounds, a fill color or a color gradient. You can also use a background image of your own.



1 You can set up a separate background image for each monitor that is connected to the device.

Wallpaper

Provides a selection of predefined IGEL backgrounds:

- Neutral
- Off
- IGEL (Default)

Wallpaper style

IGEL OS Base System 104 / 647



Provides various design versions:

- Auto
- Centered
- Tiled
- Stretched (Default)
- Scaled
- Zoomed

Color style

Sets a fill color or a color gradient.

- Solid color
- Horizontal gradient (Default)
- Vertical gradient

Desktop color

The desktop color if **Wallpaper** is set to **Off**. Click the color preview square to open the color selector.

2nd desktop color

The second desktop color if **Wallpaper** is set to **Off** and a gradient **Color style** is selected. Click the color preview square to open the color selector.

Custom wallpaper download

✓ You can provide a user-specific background image on a download server. Specify the download server under **Desktop > Background > Custom Wallpaper Server**.

☐ Custom wallpaper is not used. (Default)

Custom wallpaper file

The name of the background image file

The user-specific background image will be downloaded from the specified server if the function was enabled and if requested manually through **Wallpaper update** under **Desktop > Background > Custom Wallpaper Server**. The download can also be launched from the IGEL Universal Management Suite (UMS) via the **Update desktop customization** command.



A user-specific boot image can be provided on a download server. The file types BMP, JPG, GIF, TIF, PNG and SVG are supported for an own background image and bootsplash. A total storage area of 25 MB is available for all user-specific images. For more information, see *Universal Management Suite > UMS Reference Manual > Firmware Customizations in the IGEL UMS*.


IGEL OS Base System 105 / 647



Custom Wallpaper Server

This article shows how to configure the download server for your own background images in IGEL OS.

Menu path: User Interface > Desktop > Background > Custom Wallpaper Server



Protocol

Determines the protocol that is to be used. The following are available to choose from:

- HTTP: Download from a web server. (Default)
- HTTPS: Download from a TLS/SSL-secured web server
- FTP: Download from an FTP server
- SecureFTP: Download via SSH-secured FTP
- FTPS: Download from a TLS/SSL-secured FTP server
- **File**: The image file lies in the file system of the device, possibly as a shared NFS or Windows update. You can enter the location under **Local path**.

Local path

The path to the background image. The parameter is shown when **File** is selected as protocol.

Server name

IGEL OS Base System 106 / 647



Name or IP address of the server used

Server path

Directory in which you saved the background image

Port

Port used (Default: 80)

User name

Name of the user account on the server

Password

Password for this account

Wallpaper update

The button refreshes the background image when clicked.

IGEL OS Base System 107 / 647




Taskbar Configuration in IGEL OS 12

This article shows how to enable and configure the taskbar in IGEL OS.



Further settings can be found under **User Interface > Screenlock / Screensaver > Taskbar**. For detailed information on those settings, see Taskbar (see page 61).

Menu path: User Interface > Desktop > Taskbar



Use taskbar

✓ The taskbar is displayed and the setting options are available. (Default)

Taskbar position

Specifies the display position of the taskbar. Possible values:

- Bottom (Default)
- Top

IGEL OS Base System 108 / 647



- Left
- Right

Vertical taskbar mode

Specifies how items are shown in the taskbar. This parameter is available if Taskbar position is set to Left or Right. Possible values:

- **Vertical**: The session texts are rotated by 90°.
- **Deskbar**: The session texts are not shown. (Default)

Taskbar height/width

Specifies the size of the taskbar in pixels. This is the height of the taskbar if the position is top or bottom, and the width of the taskbar if the position is left or right. (Default: 48)



i If Maximum number of rows/columns in window button list is set to Automatic, the window buttons as well as the icons in the Quick Start Panel will be shown in a number of rows depending on the height of the taskbar. The number of rows increases in increments of 55 pixels:

- 1 55 pixels: One row
- 56 110 pixels: Two rows
- 111 165 pixels: Three rows
- 166 220 pixels: Four rows
- 221 275 pixels: Five rows
- 276 or more pixels: Six rows

The Maximum number of rows/columns in window button list parameter is described under Taskbar Items in IGEL OS 12 (see page 113).

Number of rows/columns in taskbar

Specifies the number of rows for the Quick Start Panel. The following taskbar items can be broken down into a number of rows and columns: Icons in the Quick Start Panel, window buttons. Possible values:

- Automatic: The number of rows for the Quick Start Panel depends on the height and width of the taskbar.
- **Numeric value**: The chosen value specifies the number of rows for the Quick Start Panel.

Multimonitor taskbar size

Specifies whether the taskbar is expanded onto several monitors or restricted to one monitor. Possible values:

- Restrict taskbar to one monitor
- Extend taskbar to all monitors

IGEL OS Base System 109 / 647



Monitor

Specifies the screen on which the taskbar is shown. This parameter is available if Multimonitor taskbar size is set to **Restrict taskbar to one monitor**. (Default: 1st monitor)

Taskbar on top of all windows

${\color{red} \underline{ \textbf{\textit{V}}}} \ \ \text{The taskbar is displayed on all screens, even in sessions with a full-screen window.}$
\square The taskbar is not displayed in sessions with a full-screen window. (Default)

Taskbar auto hide

✓ The taskbar is hidden automatically and will only be shown if the mouse pointer is moved to the position of	the
taskbar at the edge of the screen.	

☐ The taskbar is always displayed. (Default)

Auto hide behavior

Specifies when the taskbar is automatically hidden. Possible values:

- Intelligently: The taskbar is shown as standard. The taskbar will be hidden if the space is needed by a window, e. g. a window in full-screen mode.
- Always: The taskbar is hidden as standard. The taskbar will be shown if the mouse pointer is moved to the edge of the screen.

Taskbar show delay

Time interval in milliseconds before the taskbar is shown. The mouse pointer must be at the edge of the screen constantly during this time interval. This setting is only effective if **Taskbar auto hide** is enabled. (Default: 600)



i With the show delay, you can prevent the taskbar for a full-screen session being covered by the device's taskbar. A show delay is necessary if the taskbar for the full-screen session is set to be shown automatically and both taskbars are positioned at the same screen edge. If no show delay is set and the user brings up the taskbar for the full-screen session, this will immediately be covered by the device's taskbar. During the show delay time interval, the user has time to move the mouse pointer away from the edge of the screen.

Taskbar hide delay

Time interval in milliseconds before the taskbar is hidden. This setting is only effective if **Taskbar auto hide** is enabled. (Default: 400)


IGEL OS Base System 110 / 647



Taskbar Background in IGEL OS 12

This article shows how to configure the background style of the taskbar in IGEL OS.

Menu path: User Interface > Desktop > Taskbar Background



Background style

Possible values:

- System preset (Default)
- Solid color
- Color gradient
- Background image

Further settings depending on the style selection:

Taskbar color

The color for the taskbar. Click the color preview square to open the color selector.

IGEL OS Base System 111 / 647



2nd taskbar color

The 2nd color for the taskbar if you want to create gradient colors. Click the color preview square to open the color selector.

Reverse gradient

✓ The color gradient is reverse.

☐ The color gradient is normal. (Default)

Background image path

Path to the background image


IGEL OS Base System 112 / 647



Taskbar Items in IGEL OS 12

This article shows how to configure taskbar items in IGEL OS.

Menu path: User Interface > Desktop > Taskbar Items




Taskbar clock

✓ A clock is shown in the taskbar.

Clicking the taskbar clock displays the calendar and the **Timezone** dropdown menu. You can use the dropdown to set the timezone the device is located in. The dropdown menu is only accessible if the **System > Time and Date > Timezone systray settings** parameter is enabled. For details, see Time and Date in IGEL OS 12 (see page 269).

IGEL OS Base System 113 / 647





Sorting order in window button bar

Specifies the criteria according to which the window buttons are sorted. Possible values:

- **Timestamp**: The window buttons are sorted in the chronological order in which the windows were opened.
- **Group and timestamp**: The window buttons are grouped according to the type of application. If, for example, a number of setup applications are open, all associated window buttons will be arranged next to each other. Within the group, the window buttons are sorted chronologically. (Default)
- **Window title**: The window buttons are sorted alphabetically.
- **Group and window title**: The window buttons are grouped according to type. If for example a number of setup applications are open, all associated window buttons will be arranged next to each other. Within the group, the window buttons are sorted alphabetically.
- **Drag'n'Drop**: You can order the buttons as you wish using drag and drop.

Maximum number of rows/columns in window button bar

Specifies the maximum number of rows available for window buttons. Possible values:

- Automatic: The number of rows depends on the settings of the Taskbar height/width and Number of rows/columns in taskbar parameters under User Interface > Desktop > Taskbar. For details on the parameters, see Taskbar Configuration in IGEL OS 12 (see page 108).
- **Numeric values**: This value specifies the maximum number of rows. (Default: 1)

Show labels in window button bar

✓ The names of the ongoing sessions are displayed in the associated window buttons. (Default)

IGEL OS Base System 114 / 647



✓ The system tray is shown in the taskbar. (Default)



1 The following parameters enable icons to access the system tray applications. For details on system tray apps, see Tray Applications in IGEL OS 12 (see page 358).

The parameters for the desktop and the parameters for the locksreen are independent from each other. You need to enable / disable the icons for both use cases separately. You can enable taskbar items for the lockscreen under User Interface > Desktop > Screenlock / Screensaver > Taskbar. For more information, see Taskbar (see page 61).

Show UMS connection status tray icon on desktop

✓ The current status of the Universal management Suite (UMS) connection is shown in the system tray. For example, with the icon of for connected. Clicking the icon displays information about the connected UMS server. (Default)

Show battery tray icon on desktop

✓ The current status of the battery is shown in the system tray. For example, with the icon • . Hover over the icon to see information on the charge. Clicking the icon displays the battery tray app. (Default)

Show ethernet connection status tray icon on desktop

✓ The current status of the LAN network connection is shown in the system tray. For example, with the icon 🖵 for connected. Clicking the icon displays the LAN tray app. (Default)

Show wifi connection status tray icon on desktop

✓ The current status of the Wi-Fi network connection is shown in the system tray. For example, with the icon 🛜. Clicking the icon displays the Wi-Fi tray app. (Default)

Show mobile-broadband connection status tray icon on desktop

✓ The current status of the mobile network connection is shown in the system tray. For example, with the icon 📶 or X. Clicking the icon displays the mobile broadband tray app. (Default)

Show input settings tray icon on desktop

✓ If a mouse is detected, the 🖰 icon is shown in the system tray. If a touchpad is detected, or both a mouse and a touchpad are detected, the __ icon is shown. Clicking the icon displays the mouse & touchpad tray app. (Default)

IGEL OS Base System 115 / 647



Show display tray icon on desktop

✓ The current display configuration icon is shown in the system tray. For example, with the icon. Clicking the icon displays the display tray app. (Default)

Show audio tray icon on desktop

✓ The → and → icons are shown in the system tray. Clicking the icon displays the sound tray app. (Default)

Size of icons in system tray

Specifies the size of system tray icons (volume, network connection etc.). You can select a pre-defined value or enter a numeric value.

Predefined values:

• **Automatic**: The size is adjusted to the height and width of the taskbar.

• Small: 20 pixels (Default)

Medium: 40 pixelsLarge: 60 pixels

IGEL OS Base System 116 / 647




Pager in IGEL OS 12

You can use the Pager tool to enable the use of multiple virtual desktops and organize your IGEL OS desktop. The Pager allows you to divide one desktop into several virtual workspaces. This article shows how to configure and use the Pager tool in IGEL OS. For details on how to use the pager, see the below section Using Pager (see page 118).



Make sure you have enabled **User Interface > Desktop > Taskbar > Taskbar on top of all windows** before using the Pager. For more information on the setting, see Taskbar Configuration in IGEL OS 12 (see page 108).

Menu path: User Interface > Desktop > Pager




Use pager

✓ The Pager is enabled. You can configure up to 25 virtual desktops. The Pager will be displayed on the right of the taskbar:

IGEL OS Base System 117 / 647





☐ The Pager is disabled. (Default)

Number of screens - Horizontal

Specifies how many workspaces will be shown next to each other. (Default: 2)

Number of screens - Vertical

Specifies how many workspaces will be shown above each other. (Default: 1)



Known Issue

The vertical value is implemented as horizontal and all the screens are shown next to each other. The configuration will be reworked in a future release.

Paging resistance

Specifies how many pixels the cursor needs to be moved over the edge of the screen before it triggers a switch of the desktop. (Default: 10)

You only need to use this setting if you enable at least one of the following options – **Wrap workspaces while** dragging a window or **Wrap workspaces with pointer**.

Wrap workspaces while dragging a window

- ✓ The desktop is switched as soon as a window is dragged out of view.
- ☐ The desktop is not switched when a window is dragged out of view. (Default)

Wrap workspaces with pointer

- ✓ The desktop is switched as soon as the mouse reaches the edge of the screen.
- ☐ The desktop is not switched when the mouse reaches the edge of the screen. (Default)

Using Pager

The Pager makes switching between multiple full-screen applications easier. Instead of minimizing/maximizing sessions or switching between them using key combinations, you simply click on the desired workspace using the mouse. When you switch back, the virtual desktop is displayed exactly as before (unless you restarted the system or changed the language in the IGEL Setup).


IGEL OS Base System 118 / 647



The Pager can only be used in non-appliance mode.

To use multiple workspaces:


1. Launch the desired sessions/applications on your device, e.g. Chromium browser and System Information.



2. In the Pager panel in the taskbar, navigate to another workspace, e.g. Workspace 2, and click it.

119 / 647 IGEL OS Base System






In Workspace 2, you will see the empty desktop, without opened sessions/applications.



IGEL OS Base System 120 / 647







4. When you need to switch back to the Chromium browser and System Information, simply select the corresponding workspace (in this example, Workspace 1) in the Pager panel in the taskbar. Your desktop will be displayed exactly as before switching to Workspace 2.



You can use drag & drop to rearrange the sessions/applications between the workspaces. Click and hold the application/session symbol in the taskbar and drag it to the desired workspace in the Pager panel.


IGEL OS Base System 121 / 647



Start Menu in IGEL OS 12

This article shows how to configure the desktop start menu in IGEL OS.

Menu path: User Interface > Desktop > Start Menu



The following options, which are all enabled by default, can be configured to be shown in the start menu:

Screenlock

✓ The 🙃 icon is shown. (Default)

For the icon to be displayed, the following parameters need to be enabled:

- at least one login method under **Security > Logon**. For more information, see Logon Settings in IGEL OS 12 (see page 238).
- the Require password to unlock (screenlock) option under User Interface > Screenlock / Screensaver > Options. For more information, see Options (see page 58).

IGEL OS Base System 122 / 647



- Show Shutdown menu button
- ✓ The icon is shown. (Default)
 - System tab
- ✓ The icon is shown. (Default)
 - About
- ✓ The icon is shown. (Default)
 - Show current user name in About, Application Launcher and start menu.
 - 1 In order for user names to be recognized and passed on, you must configure two settings beforehand:
 - Enable using Active Directory/Kerberos under Security > Active Directory/Kerberos. For details, see Active Directory/Kerberos Configuration in IGEL OS 12 (see page 254)
 - Enable local logon under Security > Logon > Active Directory/Kerberos. For details, see Active Directory/Kerberos - Enable Login in IGEL OS 12 (see page 242)


IGEL OS Base System 123 / 647



In-Session Control Bar in IGEL OS 12

This article shows how to configure the control bar for full-screen sessions in IGEL OS.

Menu path: User Interface > Desktop > In-Session Control Bar




In a full-screen session, the in-session control bar allows you

- to eject a USB drive.
- to start the wireless manager (only available in Appliance Mode).
- to minimize the session view (not available in Appliance Mode).
- to end the session.

Use in-session control bar in all supported sessions

✓ The in-session control bar is shown. Depending on the configuration, the in-session control bar will be permanently visible or will be shown as soon as you move the cursor to the top edge of the screen.

☐ In-session control bar is not used. (Default)



IGEL OS Base System 124 / 647



• ThinLinc

Start Monitor

The monitor on which to start the session window.

Using In-Session Control Bar

\rightarrow	To eject a USB device, click	
---------------	------------------------------	--

- → To start the wireless manager in Appliance Mode, click .
- → To minimize the session view, click . (Not available in Appliance Mode.)
- \rightarrow To end the session, click \mathbf{X} .
- → To make the in-session control bar permanently visible, click .


IGEL OS Base System 125 / 647



Commands Session in IGEL OS 12

This article shows how to set up system command sessions in IGEL OS.

Menu path: User Interface > Commands > Shutdown menu / Sort icons / Restart windowmanager



System commands can be made accessible to the user through configuring them as sessions:

- **Shutdown menu**: Opens the shutdown menu. You can configure the shutdown menu under **System > Power Options > Shutdown**. For more information, see Shutdown Settings in IGEL OS 12 (see page 300).
- **Sort icons**: Sorts the symbols on the desktop so that they form a block.
- **Restart windowmanager**: Restarts the device's user interface.


The starting methods parameters are described under Starting Methods for Apps (see page 644).

IGEL OS Base System 126 / 647



Quick Access

Menu path: User Interface > Commands > Shutdown Menu > Quick Access



Here, you can configure the quick access to the shutdown menu from the start menu and the Application Launcher.

Show Shutdown menu button

✓ The icon is shown in the start menu. (Default)

Hide Shutdown menu button

✓ The icon is shown in the Application Launcher.

IGEL OS Base System 127 / 647



☐ The icon is not shown in the Application Launcher. (Default)

IGEL OS Base System 128 / 647



Network

In this chapter, you find information on network configuration in IGEL OS.

- DHCP Options in IGEL OS 12 (see page 130)
- DNS Settings in IGEL OS 12 (see page 134)
- Mobile Broadband in IGEL OS 12 (see page 136)
- Wireless Connections in IGEL OS 12 (see page 139)
- LAN Interfaces in IGEL OS 12 (see page 150)
- Default Gateway Configuration in IGEL OS 12 (see page 159)
- Network Drives (see page 163)
- Common Settings of the Network in IGEL OS 12 (see page 170)
- SCEP Client (NDES) in IGEL OS 12 (see page 172)
- VPN Settings in IGEL OS 12 (see page 180)
- Proxy Configuration in IGEL OS 12 (see page 202)

IGEL OS Base System 129 / 647




DHCP Options in IGEL OS 12

This article shows how to configure standard and custom DHCP options with which the client can request information from the DHCP server in IGEL OS.

Standard Options

Menu path: Network > DHCP Options > Standard Options



User class

A freely definable character string which can serve as a criterion for allocating specific settings for the DHCP server.

List of standard options

Options with which the client can request information from the DHCP server.

IGEL OS Base System 130 / 647



You will find information regarding the various DHCP options in RFC 2132 DHCP Options and BOOTP Vendor Extensions¹⁶.

To manage the list of options, proceed as follows:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking • brings up the **Add** dialogue, where you can define the following settings:

Activated

✓ The option is enabled. (Default)

Option name

The name of the option. Select from the list of predefined names.


Custom Options

Menu path: Network > DHCP Options > Custom Options

IGEL OS Base System 131 / 647

^{16.} https://tools.ietf.org/html/rfc2132





• For more information regarding these options, see the manual for your DHCP server or your network components.

To manage the list of options, proceed as follows:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking • brings up the **Add** dialogue, where you can define the following settings:

Activated

IGEL OS Base System 132 / 647



✓ The option is enabled. (Default)

Option name

The name of the option. Add a prefix of your own in order to prevent a conflict with the default DHCP options. Example of the syntax: [YourPrefix]-[OptionName] . English letters, numbers and the special character "-" are allowed.

Code

A number that is used by the DHCP server and DHCP client to reference an option. A number between 80 and 254 can be chosen. (Default: 80)

Data type

Type of option. Possible values:

- Boolean
- Integer 8
- Integer 16
- Integer 32
- Signed integer 8
- Signed integer 16
- Signed integer 32
- Unsigned integer 8
- Unsigned integer 16
- Unsigned integer 32
- IP address
- Text (Default)
- String


IGEL OS Base System 133 / 647



DNS Settings in IGEL OS 12

This article shows how to configure DNS settings in IGEL OS.

Menu path: Network > DNS



Enable DNS

✓ The manual DNS configuration will be used.

☐ The DNS configuration will be carried out by DHCP or BOOTP. (Default)

Default domain

Usually the name of the local network.

Nameserver


IGEL OS Base System 134 / 647



IP address of the nameserver to be used.

Nameserver

IP address of an alternative nameserver.



Manually overwrite DHCP settings

- The default route, the domain name, and the DNS server will be overwritten by manual entries.
- ☐ Manual entries will not overwrite DHCP settings. (Default)

Dynamic DNS registration

- ✓ The terminal name will be registered dynamically via the DNS or DHCP server.
- ☐ The terminal name will not be registered dynamically. (Default)

Dynamic DNS registration method

- **DHCP**: Updates the terminal name through DHCP option 81. (Default)
- **DNS**: Sends updates to the DNS server in accordance with RFC 2136.

TSIG key file for additional DNS authentication

Path to the private key if TSIG-based DDNS registration is used.

IGEL OS Base System 135 / 647




Mobile Broadband in IGEL OS 12

This article shows how to configure a modem or a surf stick in IGEL OS 12.



1 You can also use the Mobile Broadband Tray App for quick configurations. For details, see Tray Applications in IGEL OS 12 (see page 358).

Menu path: Network > Mobile Broadband



Ensure that data traffic is adequately secured. You can do this in the following ways:

- Use a private APN.
- Use OpenVPN and block traffic that would circumvent VPN with firewall rules.

If the surf stick is inserted and has been configured, the network connection will be established after the endpoint device boots. It can take between a few seconds and around 1 minute to establish a connection. The network connection will remain in place until the surf stick is removed or the endpoint device is put on standby or shut down.

The status of the network connection is shown in the system tray:

• The network connection is established; the endpoint device is online. This symbol is shown if **Modem** is selected as the device type: If **Router** is selected as the device type, the corresponding symbol for a LAN connection is shown:



IGEL OS Base System 136 / 647



• The network connection was interrupted; the endpoint device is offline. This symbol is shown if **Modem** is selected as the device type: X If **Router** is selected as the device type, the corresponding symbol for a LAN connection is shown:



You can change the following settings:

Enable Mobile Broadband

${m ec{m ec V}}$ The mobile broadband network can be used if a supported modem is connected. (De	fault
☐ The mobile broadband network cannot be used.	

Device type

The type of the connected device. Possible options:

- Modem: The device will be operated as a modem. The access data can be changed with the parameters number, user name, password, APN, network ID and PIN. (Default)
- Router: The device will be operated as a router. The device must be configured in advance in such a way that it is ready for use when it is inserted.



Select the Router device type if you use a device from Huawei in the HiLink mode; example: Huawei E3372.

When Modem is Selected as Device Type

Custom APN (Access Point Name)

APN (Access Point Name) for your network connection. If you do not know the APN, ask your mobile communications operator for it.

Provider username

User name for your network connection. If you do not know the user name, ask your mobile communications operator for it.

Provider password

Password for your network connection. If you do not know the password, ask your mobile communications operator for it.

Enable automatically connect

✓ The mobile internet connection is established automatically. (Default)

IGEL OS Base System 137 / 647



Allow changing the SIM-PIN in the tray application The PIN of the SIM-card can be changed in the tray application. (Default)				
Allow changing the request for the SIM-PIN after boot inside the tray application The request for the PIN after booting can be enabled/disabled in the tray application. (Default)				
Roaming ✓ The WWAN modem is allowed to connect to roaming networks. (Default) □ The WWAN modem can only connect to home networks.				

IGEL OS Base System 138 / 647




Wireless Connections in IGEL OS 12

This article shows how to configure wireless connections in IGEL OS.



You can use the **Automatic switch of network connection** parameter under **Network > Common Settings** to set the behaviour of switching between LAN, Wi-Fi, and WWAN networks. For details, see Common Settings of the Network in IGEL OS 12 (see page 170).

Menu path: Network > Wireless



You can find details of compatible wireless hardware in the IGEL Linux 3rd Party Hardware Database¹⁷.



Predictable Network Interface Names (PNINs)

The names of Ethernet and WLAN interfaces are predictable network interface names (PNINs), see Predictable Network Interface Names¹⁸. This ensures the stability of interface names on reboot and generally improves the reliability of associating configurations with interfaces.

IGEL OS Base System 139 / 647

^{17.} https://www.igel.com/linux-3rd-party-hardware-database/

^{18.} https://www.freedesktop.org/wiki/Software/systemd/PredictableNetworkInterfaceNames/



• As " eth0 ", " eth1 ", and " wlan0 " have been replaced by PNINs, configurations or custom scripts that include the old names of Ethernet and WLAN interfaces, e.g. eth0, eth2, wlan0, have to be adjusted.

The following already existing configurations do NOT require manual adjustment since old names eth0, eth1, etc. will internally be replaced by the correct PNINs automatically:

- (11.10-en) Tcpdump
- To view the PNINs and the order of the configured interfaces, you can use the following commands. The default interface is always listed first, the second interface is listed second, etc.

Ethernet (LAN): cat /config/net/en-interfaces

WLAN: cat /config/net/wl-interfaces

(Note: Only the first wireless interface (former wlan0) is supported. All other wireless interfaces will be ignored.)

• If you need to configure more than two Ethernet interfaces, go to **System > Registry** > **network.interfaces.ethernet.device%** and add an instance by clicking **Add Instance**. To explicitly assign a configuration instance to a certain interface, enter the corresponding PNIN for the registry key **network.interfaces.ethernet.device%.ifname**.

Activate wireless interface

✓ The wireless interface is enabled. (D	efault
☐ The wireless interface is disabled.	

Get IP from DHCP server

The IP address of the endpoint device will be obtained automatically using DHCP. (Default)

DHCP options can be specified under **Network > DHCP Options**. For details on the configuration, see DHCP Options in IGEL OS 12 (see page 130).

Specify IP address

The IP address and the network mask are entered manually.

IP address

IP address of the endpoint device

Network mask

Network mask of the endpoint device

IGEL OS Base System 140 / 647



IPv6 configuration:

- Compatibility mode: Behavior of earlier firmware versions. (Default)
- **Disabled**: IPv6 is completely disabled.
- **Automatic**: IPv6 auto-configuration is based on router advertisements (can include DHCPv6). You will find further information in RFC 4861¹⁹.
- **DHCPv6**: IPv6 configuration using DHCPv6 if router advertisements are not available. You will find further information in RFC 4862 Section 5.5.2²⁰.

Enable Wi-Fi automatic switch

✓ Wi-Fi is turned on automatically when a wired LAN connection is disconnected and Wi-Fi is turned off automatically when a wired LAN connection is established.

☐ Wi-Fi is not turned on automatically when a wired LAN connection is disconnected and Wi-Fi is not turned off automatically when a wired LAN connection is established. (Default)



If the toggle button in the Wi-Fi tray app is used for turning the Wi-Fi on or off, the Wi-Fi automatic switch gets disabled until the reboot of the device. On reboot, the previously configured setting will be restored. For details, see Tray Applications in IGEL OS 12 (see page 358).

- Wi-Fi Networks Configuration in IGEL OS 12 (see page 142)
- Wireless Regulatory Domain (see page 148)

IGEL OS Base System 141 / 647

^{19.} https://tools.ietf.org/html/rfc4861

^{20.} https://tools.ietf.org/html/rfc4862#section-5.5.2



Wi-Fi Networks Configuration in IGEL OS 12

This article shows how to configure wireless network connections in IGEL OS. All the wireless network connections configured for the device are shown in the list, including connections configured through the UMS or the Wi-Fi tray app. For more information on the tray app, see Tray Applications in IGEL OS 12 (see page 358).



For further configuration see How to Configure Server Certificate Verification during 802.1x Authentication in IGEL OS 12 (see page 535).

Menu path: Network > Wireless > Wi-Fi Network



To edit the Wi-Fi networks list, proceed as follows:


- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking • brings up the **Add** dialogue, where you can define the settings of the wireless network.

IGEL OS Base System 142 / 647



Wi-Fi Networks Settings



Wireless network name (SSID)

IGEL OS Base System 143 / 647



Name of the wireless network (SSID)

Enable encryption



Encrypted connection is used. (Default)

Network authentication

You can configure the following network authentication methods.

- WPA Personal: Wi-Fi Protected Access Pre-Shared Key (WPA / IEEE 802.11i/D3.0)
- WPA Enterprise: Wi-Fi Protected Access with 802.1X authentication (WPA / IEEE 802.11i/D3.0)
- WPA2 Personal (Default): Wi-Fi Protected Access Pre-Shared Key (WPA2 / IEEE 802.11i/RSN)
- WPA2/WPA3 Enterprise: Wi-Fi Protected Access with 802.1X authentication (WPA2 / WPA3 / IEEE 802.11i/RSN)
- WPA3 Personal: Wi-Fi Protected Access SAE (Simultaneous Authentication of Equals)
- WPA3 Enterprise B192: allow connections to WPA3 Enterprise with 192-bit mode (00-0F-AC:12 cipher suite, GCMP-256 pairwise cipher and required PMF)

Depending on the selection, you can configure the corresponding parameters below.

- For WPA/WPA2/WPA3 Personal encryption, see WPA/WPA2/WPA3 Personal (see page 144).
- For WPA/WPA2/WPA3 Enterprise encryption, see WPA Enterprise or WPA2/WPA3 Enterprise or WPA3 Enterprise B192 Enterprise Encryption (see page 145).

WPA/WPA2/WPA3 Personal Encryption

Network key

WPA network key/passphrase as set at the access point. This is either an ASCII character string with a length of 8...63 or exactly 64 hexadecimal digits.

Data encryption

- Default: The default value depends on which network authentication method is selected. For WPA, TKIP is the default. For WPA2, AES (CCMP) is the default. (Default)
- TKIP: Temporal Key Integrity Protocol (IEEE 802.11i/D7.0)
- AES (CCMP): AES in Counter mode with CBC-MAC (RFC 3610, IEEE 802.11i/D7.0)
- AES (CCMP) + TKIP: One of two encryption methods is selected by the access point.
- Automatic: The access point can choose the encryption method freely nothing is stipulated.

AP shows SSID (scan mode)

Scan mode for access points.

- **Default (visible SSID)** (Default)
- Broadcast (visible SSID): Alternative for access points which allow the SSID broadcast

144 / 647 **IGEL OS Base System**



• No broadcast (hidden SSID): Alternative for access points which refuse the SSID broadcast (hidden access points)

Enable automatically connect

Automatic connection to the access point is enabled. (Default)

WPA Enterprise or WPA2/WPA3 Enterprise or WPA3 Enterprise B192 Encryption

Data encryption

- Default: The default value depends on which network authentication method is selected TKIP for WPA, AES (CCMP) for WPA2.
- **TKIP**: Temporal Key Integrity Protocol (IEEE 802.11i/D7.0)
- AES (CCMP): AES in Counter mode with CBC-MAC (RFC 3610, IEEE 802.11i/D7.0)
- AES (CCMP) + TKIP: One of two encryption methods is selected by the access point.
- Automatic (Default): The access point can choose the encryption method freely nothing is stipulated.



i In case of WPA3 Enterprise B192 Encryption, GCMP-256 encryption is silently enforced regardless of the Data encryption setting.

EAP type

- **PEAP**: Protected Extensible Authentication Protocol
- TLS: Transport Layer Security with client certificate
- TTLS: Tunneled Transport Layer Security
- FAST: Flexible Authentication via Secure Tunneling

Anonymous identity

This identity is sent by authentication instead of the actual **Identity**. This prevents the disclosure of the actual identity of the user. The anonymous identity is relevant for any of the above-mentioned EAP Types, except for TLS.

Auth method

Method for authentication that is available for the selected EAP type. Possible options:

- MSCHAPv2: Microsoft Challenge Handshake Authentication Protocol (Default)
- TLS: Transport Layer Security with client certificate
- **GTC**: Generic Token Card
- MD5: MD5-Challenge
- PAP: Password Authentication Protocol

145 / 647 **IGEL OS Base System**



Validate server certificate

The endpoint device validates the authenticity of the authentication server against the certificate file. This certificate file is stored under the path defined by CA root certificate. (Default)

 \Box The authenticity of the authentication server is not validated.

CA Root Certificate

Path and file name of the file that contains the certificates with which the authentication server authenticates itself.

Identity

Username that is stored at the authentication server

Password

Password relevant to the user name

Enable automatically connect

Automatic connection to the access point is enabled. (Default)

AP shows SSID (scan mode)

Scan mode for access points.

- **Default (visible SSID)** (Default)
- Broadcast (visible SSID): Alternative for access points that allow the SSID broadcast
- No broadcast (hidden SSID): Alternative for access points that refuse the SSID broadcast (hidden access points)

TLS as EAP Type

The following settings are relevant if you have selected **TLS** as **EAP type:**

Manage certificates with SCEP (NDES)

✓ Client certificates will automatically be managed with SCEP. For more information on SCEP configuration, see SCEP Client (NDES) in IGEL OS 12 (see page 172).

☐ Client certificates will not be managed with SCEP. (Default)

Client Certificate

Path to the file with the certificate for client authentication in the PEM (base64) or DER format.



if a private key in the PKCS#12 (PFX) format is used, leave this field empty.

146 / 647 **IGEL OS Base System**



Private key

Path to the file with the private key for the client certificate. The file can be in the PEM (base64), DER, or PKCS#12 (PFX) format. The **Private key password** may be required for access.

Identity

User name for network access

Private key password

Password for the **Private key** for the client certificate

FAST as EAP Type

The following setting is relevant if you have selected **FAST** as **EAP type**:

Automatic PAC provisioning

Specifies how the PAC (Protected Access Credential) is delivered to the client.

Possible options:

- **Disabled**: PAC files have to be transferred to the device manually, e.g. via UMS file transfer.
- **Unauthenticated**: An anonymous tunnel will be used for PAC provisioning.
- Authenticated: An authenticated tunnel will be used for PAC provisioning.
- Unrestricted: Both authenticated and unauthenticated PAC provisioning is allowed. PAC files are automatically created after the first successful authentication. (Default)



PAC files are stored in /wfs/eap_fast_pacs/.

PAC file names are automatically derived from the Identity, but are coded. In the case of the manual PAC provisioning, you can determine the PAC file names with the following script: /bin/ gen_pac_filename.sh


IGEL OS Base System 147 / 647



Wireless Regulatory Domain

This article shows how to set the location of the device in IGEL OS.

Menu path: Network > Wireless > Wireless Regulatory Domain



Wireless regulatory domain

Select the area in which the device is located.

- Not configured (Default)
- Africa
- Arctic
- Asia
- Australia
- Europe
- North America
- South America
- World

Location

Select the country in which the device is located. The available options are based on the selected area.

- Not configured (Default)
- World
- Albania
- Armenia

[...]

IGEL OS Base System 148 / 647



• Cyprus

IGEL OS Base System 149 / 647




LAN Interfaces in IGEL OS 12

This article shows how to configure LAN interfaces in IGEL OS.



1 You can use the LAN tray app for quick ethernet network configurations. For details, see Tray Applications in IGEL OS 12 (see page 358).

Menu path: Network > LAN Interfaces > [Interface]



Predictable Network Interface Names (PNINs)

The names of Ethernet and WLAN interfaces are predictable network interface names (PNINs), see Predictable Network Interface Names²¹. This ensures the stability of interface names on reboot and generally improves the reliability of associating configurations with interfaces.

- As "eth0", "eth1", and "wlan0" have been replaced by PNINs, configurations or custom scripts that include the old names of Ethernet and WLAN interfaces, e.g. eth0, eth2, wlan0, have to be adjusted.
 - The following already existing configurations do NOT require manual adjustment since old names eth0, eth1, etc. will internally be replaced by the correct PNINs automatically:
 - (11.10-en) Tcpdump
- To view the PNINs and the order of the configured interfaces, you can use the following commands. The default interface is always listed first, the second interface is listed second, etc.

IGEL OS Base System 150 / 647

^{21.} https://www.freedesktop.org/wiki/Software/systemd/PredictableNetworkInterfaceNames/



Ethernet (LAN): cat /config/net/en-interfaces

WLAN: cat /config/net/wl-interfaces

(Note: Only the first wireless interface (former wlan0) is supported. All other wireless interfaces will be ignored.)

• If you need to configure more than two Ethernet interfaces, go to **System > Registry** > **network.interfaces.ethernet.device%** and add an instance by clicking **Add Instance**. To explicitly assign a configuration instance to a certain interface, enter the corresponding PNIN for the registry key **network.interfaces.ethernet.device%.ifname**.

✓ The interface is enabled. (Default)

☐ The interface is disabled.

Get IP from DHCP server

✓ The IP address of the client will be obtained automatically using DHCP. (Default)

DHCP options can be specified under **Network > DHCP Options > Standard Options**. For more information, see DHCP Options in IGEL OS 12 (see page 130).

Specify an IP address

The IP address and the network mask are entered manually.

IP address

IP address of the device

Network mask

Network mask of the device

IPv6 configuration

- Compatibility mode: Behavior of earlier firmware versions. (Default)
- **Disabled**: IPv6 completely disabled
- **Automatic**: IPv6 auto configuration based on router advertisements (can include DHCPv6). For further information, see RFC 4861.²²

22. https://tools.ietf.org/html/rfc4861

IGEL OS Base System 151 / 647



• **DHCPv6**: IPv6 configuration using DHCPv6 if router advertisements are not available. This is mentioned in RFC 4862 Section 5.5.2.²³

Network link type

- Auto sense (Default)
- 1000 Mbps Full Duplex
- 100 Mbps Full Duplex
- 100 Mbps Half Duplex
- 10 Mbps Full Duplex
- 10 Mbps Half Duplex

Force auto-negotiation

✓ The half-/full-duplex problems can be avoided for switches that expect the auto-negotiation flag for fixed bandwidths.

☐ Auto-negotiation is not forced. (Default)

- Network Port Authentication in IGEL OS 12 (see page 153)
- Wake On LAN Settings in IGEL OS 12 (see page 156)

IGEL OS Base System 152 / 647

^{23.} https://tools.ietf.org/html/rfc4862#section-5.5.2




Network Port Authentication in IGEL OS 12

This article shows how to enable and configure network port authentication in IGEL OS.



For further configuration see How to Configure Server Certificate Verification during 802.1x Authentication in IGEL OS 12 (see page 535).

Menu path: Network > LAN Interfaces > [Interface] > Authentication



Enable IEEE 802.1x authentication

✓ Network port authentication is enabled.

☐ Network port authentication is disabled. (Default)

If you enable authentication, further options become available:

EAP type

The type of the authentication procedure:

- PEAP: Protected Extensible Authentication Protocol (Default)
- TLS: Transport Layer Security with client certificate
- TTLS: Tunneled Transport Layer Security
- FAST: Flexible Authentication via Secure Tunneling

Anonymous identity

IGEL OS Base System 153 / 647



This identity is sent by authentication instead of the actual **Identity**. This prevents the disclosure of the actual identity of the user. The anonymous identity is relevant for any of the above-mentioned EAP Types, except for TLS.

Auth method

The following authentication methods are available:

- MSCHAPV2: Microsoft Challenge Handshake Authentication Protocol (Default)
- TLS: Transport Layer Security with client certificate
- GTC: Generic Token Card
- MD5: MD5-Challenge
- PAP: Password Authentication Protocol

Validate server certificate

✓ The server's certificate is checked cryptographically. (Default)

CA root certificate

The path to the CA root certificate file. This can be in PEM or DER format.

Identity

User name for RADIUS

Password

Password for network access



if you leave the Identity and Password fields empty, an entry mask for authentication purposes will be shown. However, this does not apply to the methods with a client certificate (TLS and PEAP-TLS) where these details are mandatory.

If **Identity** and **Password** entered via the entry mask should be saved, see How to Configure the Permanent Storage of User-Provided Network Credentials (Wi-Fi and Ethernet) (see page 539).

The following settings are relevant if you have selected **TLS** as **EAP Type**:

Manage certificates with SCEP (NDES)

Client certificates will automatically be managed with SCEP. For more information, see SCEP Client (NDES) in IGEL OS 12 (see page 172).

☐ Client certificates will not be managed with SCEP. (Default)

Client certificate

154 / 647 **IGEL OS Base System**



Path to the file with the certificate for client authentication in the PEM (base64) or DER format.



if a private key in the PKCS#12 (PFX) format is used, leave this field empty.

Private key

Path to the file with the private key for the client certificate. The file can be in the PEM (base64), DER, or PKCS#12 (PFX) format. The **Private key password** may be required for access.

Identity

User name for network access

Private key password

Password for the **Private key** for the client certificate

The following setting is relevant if you have selected **FAST** as **EAP Type**:

Automatic PAC provisioning

Specifies how the PAC (Protected Access Credential) is delivered to the client. Possible options:

- **Disabled**: PAC files have to be transferred to the device manually, e.g. via UMS file transfer.
- Unauthenticated: An anonymous tunnel will be used for PAC provisioning.
- Authenticated: An authenticated tunnel will be used for PAC provisioning.
- Unrestricted: Both authenticated and unauthenticated PAC provisioning is allowed. PAC files are automatically created after the first successful authentication. (Default)
- PAC files are stored in /wfs/eap_fast_pacs/. PAC file names are automatically derived from the **Identity**, but are coded. In the case of the manual PAC provisioning, you can determine the PAC file names with the following script: /bin/ gen_pac_filename.sh
- in tests with hostapd, it has been necessary to disable TLS 1.2. To do that, enter the following command for **System > Registry**
 - > network.interfaces.ethernet.device0.ieee8021x.phase1_direct: tls_disable_tlsv1_2=1 To add further device registry keys, go to System > Registry > network.interfaces.ethernet.device% and click Add Instance.

155 / 647 **IGEL OS Base System**



Wake On LAN Settings in IGEL OS 12

With Wake-on-Lan (WoL), you can switch on devices over the network. This article shows how to configure the packets or messages with which the endpoint device can be started in IGEL OS.

For further information on the WoL functionality of the Universal Management Suite (UMS), see (12.05.100-en) Wake on LAN Configuration in the IGEL UMS.



WoL via Docking Stations and USB-C-to-LAN adapters

When using the supported devices with USB-C docking, or USB-C-to-LAN adapters, WoL is only supported from suspend mode and not power off mode. For more details, see Devices Supported by IGEL OS 12.



IGEL OS 12.3.2 or higher: WoL Setting in BIOS is Detected on Supported Lenovo Devices:


On Lenovo devices that are supported by IGEL OS 12, the system can detect whether WoL is enabled in the BIOS or not. If the system detects that WoL is disabled in the BIOS, all WoL described on this configuration page is disabled.

You can enable or disable the WoL detection with **System > Registry > network > interfaces > respect_bios_wol_setting** (registry key network.interfaces.respect_bios_wol_setting).

Menu path: Network > LAN Interfaces > [Interface] > Wake On LAN

IGEL OS Base System 156 / 647





Wake on magic packet

✓ The device can be started with a Wake-on-LAN magic packet. (Default)

Wake on ARP packet

- ✓ The device can be started with a Wake on ARP packet.
- \square The device cannot be started with a Wake on ARP packet. (Default)

Wake on broadcast message

- ✓ The device can be started with a Wake on broadcast message.
- \square The device cannot be started with a Wake on broadcast message. (Default)

Wake on multicast message

- ✓ The device can be started with a Wake on multicast message.
- ☐ The device cannot be started with a Wake on multicast message. (Default)

Wake on physical activity

✓ The device can be started with a physical activity.

IGEL OS Base System 157 / 647



☐ The device cannot be started with a physical activity. (Default)
Wake on unicast message
✓ The device can be started with a Wake on unicast message.
☐ The device cannot be started with a Wake on unicast message. (Default)


IGEL OS Base System 158 / 647



Default Gateway Configuration in IGEL OS 12

This article shows how to configure the default gateway in IGEL OS.

Menu path: Network > Default Gateway



Default gateway

✓ Routing is enabled.

☐ Routing is disabled. (Default)

Default gateway

Gateway that routes the packets to the target network

Interface

The network interface via which the route is to run

• Predictable Network Interface Names (PNINs)

IGEL OS Base System 159 / 647



The names of Ethernet and WLAN interfaces are predictable network interface names (PNINs), see Predictable Network Interface Names²⁴. This ensures the stability of interface names on reboot and generally improves the reliability of associating configurations with interfaces.

As "eth0", "eth1", and "wlan0" have been replaced by PNINs, configurations or custom scripts that include the old names of Ethernet and WLAN interfaces,
 e.g. eth0, eth2, wlan0, have to be adjusted.

The following already existing configurations do NOT require manual adjustment since old names eth0, eth1, etc. will internally be replaced by the correct PNINs automatically:

- (11.10-en) Tcpdump
- To view the PNINs and the order of the configured interfaces, you can use the following commands. The default interface is always listed first, the second interface is listed second, etc.

Ethernet (LAN): cat /config/net/en-interfaces

WLAN: cat /config/net/wl-interfaces

(Note: Only the first wireless interface (former wlan0) is supported. All other wireless interfaces will be ignored.)

If you need to configure more than two Ethernet interfaces, go to System > Registry
 network.interfaces.ethernet.device% and add an instance by clicking Add Instance.
 To explicitly assign a configuration instance to a certain interface, enter the corresponding PNIN for the registry key network.interfaces.ethernet.device%.ifname.

IGEL OS Base System 160 / 647


^{24.} https://www.freedesktop.org/wiki/Software/systemd/PredictableNetworkInterfaceNames/



Routing in IGEL OS 12

This article shows how to configure routing in IGEL OS.

Menu path: Network > Default gateway > Routing [1-5]



Routing

✓ This route is enabled.

☐ This route is disabled. (Default)

Network route / Host route

Type of route.

- **Network route**: The routing relates to a (sub) network. (Default)
- **Host route**: The routing relates to the address of a computer.

IGEL OS Base System 161 / 647



Network/Host IP or Name

The address of the network (for a network route) or the IP address or the name of the host (for a host route).

Network mask

Mask for the desired IP range, e.g. 255.255.255.0

Gateway

Gateway that routes the packets to the target network

Interface

The network interface via which the route is to run

IGEL OS Base System 162 / 647



Network Drives

The following network drives can be configured in IGEL OS.

- NFS in IGEL OS 12 (see page 164)
- Windows Drive Configuration in IGEL OS 12 (see page 167)


IGEL OS Base System 163 / 647



NFS in IGEL OS 12

This article shows how to integrate network drives using the Network File System (NFS) in IGEL OS.

Menu path: Network > Network Drives > NFS



NFS Mount List

List of integrated network drives


To manage the network drives, proceed as follows:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking brings up the **Add** dialogue, where you can define the following settings:

IGEL OS Base System 164 / 647





Enabled

✓ The network drive will be integrated. (Default)

Local mount point

The local directory under which the server directory is to be visible. (Default: /nfsmount)



Server

NFS server that exports the directory.

IGEL OS Base System 165 / 647





For **Server**, you can provide an IP address, a hostname or a Fully-Qualified Domain Name (FQDN).

Directory name

Path under which the NFS server exports the directory.


IGEL OS Base System 166 / 647



Windows Drive Configuration in IGEL OS 12

This article shows how to integrate network drives shared by Windows as well as those from Linux/Unix servers via the SMB protocol (Samba) in IGEL OS.

Menu path: Network > Network Drives > Windows Drive



SMB Mount List

List of integrated network drives shared through SMB


To manage the list of drives, proceed as follows:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

IGEL OS Base System 167 / 647



Clicking brings up the **Add** dialogue, where you can define the following settings:



Enabled

✓ The network drive will be integrated. (Default)

Local mount point

The local directory under which the server directory is to be visible. (Default: /smbmount)

IGEL OS Base System 168 / 647





For **Local mount point**, only / (Linux/Unix-style forward slash) can be used as a path separator. Note that if you enter, for example, \smbmount as a moint point, a directory called \smbmount will be created, because \ is a legal character in Linux directory names. For **Share name**, however, / (Linux/ Unix-style forward slash) or \ (Windows-style backward slash) can be used as a path separator.

Server

The IP address, Fully-Qualified Domain Name (FQDN) or NetBIOS name of the server



If a NetBios name is provided for **Server**, make sure it is not preceded by slashes, e.g. \ \myComputer (wrong) vs. myComputer (correct).

Share name

Path name as exported by the Windows or Unix Samba host

User name

User name for your user account on the Windows or Unix Samba host

Password

Password for your user account on the Windows or Unix Samba host

User writable

✓ The user can not only read but also write directory contents.	Otherwise, only the local root user is able to do
this.	

☐ The user can only read directory contents. (Default)


IGEL OS Base System 169 / 647



Common Settings of the Network in IGEL OS 12

This article shows how to configure common network settings in IGEL OS 12.

Menu path: Network > Common Settings



Computer name

Local name of the device. If the field is empty, the default name is used. The default name is combined of ' ITC ' and the MAC address of the device.

For more information on naming configurations, see (12.05.100-en) How to Rename IGEL OS Devices .

Host List

List of configured hosts. If no Domain Name Service (DNS) is used, you can specify a list with computers in order to allow translation between the fully qualified host name, the short host name and the IP address.

To manage the list of computers, proceed as follows:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking brings up the **Add** dialogue, where you can define the following settings:

• IP address

IP address of the host you would like to add.

IGEL OS Base System 170 / 647



 Fully qualified host name Host name along with the domain, e.g. mail.example.com

Short host name

E.g. mail

Automatic switch of network connection

✓ The network connections (LAN, Wi-Fi, WWAN) are turned on and off automatically based on availability. (Default)



The automation is based on the following order of priorities:

- 1. LAN
- 2. Wi-Fi
- 3. Mobile broadband

Actions of the automation:

- 1. When a LAN connection is available, Wi-Fi and mobile broadband connections get disabled. The toggles in the the mobile broadband tray App and Wi-Fi tray app get disabled, so you cannot overwrite the setting there.
- 2. When a LAN connection is not available, the Wi-Fi connection is enabled automatically, and mobile broadband remains disabled. You can use the toggle in the Wi-Fi tray app to enable/disable Wi-Fi. When the network type is disabled through the toggle, the setting is saved persistently over boot.
- 3. When there are no available LAN and Wi-Fi connections, mobile broadband gets enabled. You can use the toggle in the mobile broadband tray app to enable/disable Wi-Fi. When the network type is disabled through the toggle, the setting is saved persistently over

For more on network tray apps, see Tray Applications in IGEL OS 12 (see page 358).

\square The network connections are not turned on and off automatically. The toggles can be used i	n the mobile
broadband tray app and Wi-Fi tray app to manage connections.	

IGEL OS Base System 171 / 647




SCEP Client (NDES) in IGEL OS 12

SCEP allows the automatic provision of client certificates via an SCEP server and a certification authority. This type of certificate is automatically renewed before it expires and can be used for purposes such as network authentication (e.g. IEEE 802.1x). This article shows how to configure SCEP certificate management in IGEL OS.



The SCEP configuration process is quite complex, for example, you need to enter the **CA certificate fingerprint** (under Certification Authority) and the **Challenge password** (under SCEP server). To save time and effort, we recommend you to set up SCEP in the IGEL Universal Management Suite (UMS) as a profile and distribute it to the devices. For more information, see How to Create and Assign Profiles in the IGEL UMS Web App²⁵.

Menu path: Network > SCEP Client (NDES)



Manage certificates with SCEP

✓ Certificate management via SCEP Client (NDES) is enabled.

☐ Certificate management via SCEP Client (NDES) is not enabled. (Default)

A Microsoft Windows Server (MSCEP, NDES) for example can serve as a queried counterpart (SCEP server and certification body). More information can be found at Microsoft, e.g. in the following Technet article: Network Device Enrollment Service (NDES) in Active Directory Certificate Services (AD CS)²⁶.

- SCEP Server in IGEL OS 12 (see page 173)
- Certificate (see page 176)
- Certification Authority Configuration in IGEL OS12 (see page 179)

IGEL OS Base System 172 / 647

^{25.} https://kb.igel.com/en/universal-management-suite/current/how-to-create-and-assign-profiles-in-the-igel-ums-


^{26.} https://learn.microsoft.com/en-us/archive/technet-wiki/9063.active-directory-certificate-services-ad-cs-network-device-enrollment-service-ndes



SCEP Server in IGEL OS 12

This article describes the settings required for connecting the IGEL OS device to an SCEP server.


Menu path: Network > SCEP Client (NDES) > SCEP Server



SCEP server URL

Address by which the SCEP client communicates with the SCEP server. Examples:

- http://myserver.mydomain.com/certsrv/mscep/mscep.dll (Windows Server 2019)
- http://myserver.mydomain.com/certsrv/mscep (before Windows Server 2019)



Proxy server for SCEP requests

If a proxy must be used, provide its address in the format host:port; otherwise, leave the field blank.

Challenge password

The password that the SCEP client must present to the SCEP server in its requests (CSR).

i Microsoft NDES Server Settings

IGEL OS Base System 173 / 647



By default, the password on a Microsoft NDES server is valid for 1 hour and can be used only once. In order to use the password on numerous devices, additional settings must be made on the NDES server. For information, see the section "Password and Password Cache" on https://social.technet.microsoft.com²⁷. On a Microsoft NDES server, you can retrieve the password under https://<HOSTNAME>/certsrv/mscep_admin

1 Automatic Password Retrieval (NDES only)

When automatic retrieval is enabled, the device extracts the NDES challenge password from the NDES server (https://<HOSTNAME>/certsrv/mscep_admin).

To enable automatic retrieval of the NDES password, make the following settings in **System > Registry**:

- Set network.scepclient.cert%.use_ready_made_challenge_password_com mand to NDES.
- Set
 network.scepclient.cert%.ndes.challenge_password_retrieval.use
 r to the username with which the NDES challenge password can be retrieved from the
 NDES server (https://<HOSTNAME>/certsrv/mscep_admin).
- Set
 network.scepclient.cert%.ndes.challenge_password_retrieval.cry
 pt_password to the password with which the NDES challenge password can be
 retrieved from the NDES server (https://<HOSTNAME>/certsrv/mscep_admin).
- If you want HTTPS to be used, you have two options:
 - Set
 network.scepclient.cert%.ndes.challenge_password_retrieva
 l.cacert to from getca operation.
 - Enter the appropriate certificate under network.scepclient.cert%.ndes.challenge_password_retrieva l.cacert
- If you want to use unsecured HTTP, set network.scepclient.cert%.ndes.challenge_password_retrieval.cac ert to none (not using https).
- If you want to use Kerberos instead of the Default method NTLM, set
 network.scepclient.cert%.ndes.challenge_password_retrieval.aut
 h to Kerberos. Please note that for Kerberos authentication, Security > Active
 Directory/Kerberos²⁸ must be enabled, and the domain must be configured there.

IGEL OS Base System 174 / 647

^{27.} https://social.technet.microsoft.com/wiki/contents/articles/9063.active-directory-certificate-services-ad-cs-network-device-enrollment-service-ndes.aspx



Certificate renewal period (days)

Time interval before certificate expiry during which renewal attempts are performed. (Default: 30)

Certificate expiry check interval (days)

Specifies how often the certificate is checked against its expiry date. (Default: 1)



31.12. of a year. If the period for renewal is set to 10 days, a new certificate will be requested for the first time on 21.12. of the same year.

175 / 647 IGEL OS Base System


^{28.} https://kb.igel.com/en/igel-os-base-system/current/active-directory-kerberos



Certificate

This article shows how to specify the basic data for the certificate to be issued by the certification body for SCEP in IGEL OS. Here you can set the data for the Certificate Signing Request (CSR).

Menu path: Network > SCEP Client (NDES) > Certificate



Type of CommonName/SubjectAltName

The characteristic for linking the certificate to the device.

- IP address: The IP address of the device.
- **DNS name**: The DNS name of the device. (Default)
- if the client automatically obtains its network name, **DNS name (auto)** is a good type for the client certificate.
 - IP address (auto): The IP address of the device (inserted automatically).
 - **DNS name (auto)**: The DNS name of the device (inserted automatically).
- If you use **DNS name (auto)** and the hostname gets changed, the network authentication will usually continue to function using the certificate with the old hostname. This can later lead to client certificate renewal failure, with the notification: "Renewal of client certificate failed subject has changed OLDNAME > NEWNAME ". You can change the behavior through the **network.scepclient.cert%.hostname_change_handling** registry key. For details and troubleshooting, see Troubleshooting: SCEP Certificate Renewal Failure due to Hostname Change (see page 522).
 - Email address: An email address.
 - DNS name as UPN (auto)

IGEL OS Base System 176 / 647



• **UPN** (Microsoft User Principal Name)

CommonName/SubjectAltName

The parameter is available if **Type of CommonName/SubjectAltName** is set to **IP address**, **DNS name**, **UPN**, or **Email address**. Give a designation that matches the **Type of CommonName/SubjectAltName**. For certain types, this occurs automatically. No entry is then required.

CommonName/SubjectAltName Suffix

The parameter is available if **Type of CommonName/SubjectAltName** is set to **IP address (auto)**, **DNS name (auto)**, or **DNS name as UPN (auto)**. Specifies a suffix that will be added to CommonName/SubjectAltName. Possible values:

- None: No suffix will be added.
- **Dot + DNS domain (auto)**: The system's current DNS domain name, separated with a dot, will be added. Example: .igel.local
- Free text entry: The manually entered suffix will be added. Take notice that the percent symbol "%" is used for introducing the escape sequence, and thus the following replacements take place automatically:
 - % D is replaced by the system's DNS domain name at the time the certificate signing request (CSR) is created. Example: @% D will be changed into @ igel.de if the system's current DNS domain name is igel.de.
 - %% will be replaced by %. Example: A %% B will be changed into A % B.
 - Other combinations with % are currently discarded. Example: A % BC will be changed into A C.
- 1 If you have to specify the suffix manually, make sure you enter the separator.
- You can configure 4 additional Subject Alternative Names (SANs) in the Certificate Signing Request (CSR) using the following registry keys:

CommonName/SubjectAltName (+N)

|Registry| network.scepclient.cert%.subjectaltname_otherN |

Type of CommonName/SubjectAltName (+N)

|Registry| network.scepclient.cert%.subjectaltname_otherN_type |

CommonName/SubjectAltName Suffix (+N)

|Registry| network.scepclient.cert%.subjectaltname_otherN_suffix |

N refers to a slot number in the range {1, 2, 3, 4}. The slot is ignored if

network.scepclient.cert%.subjectaltname_otherN_type isset to none.

Organizational unit

IGEL OS Base System 177 / 647



Stipulated by the certification authority

Organization

A freely definable designation for the organization to which the client belongs

Locality

Details regarding the device's locality. Example: "Augsburg".

State

Details regarding the device's locality. Example: "Bayern".

Country

Two-digit ISO 3166-1 country code. Example: "DE".

RSA key length (bits)

Defines the key length (one suited to the certification authority) for the certificate that is to be issued. Possible values:

- 1024
- 2048
- 4096



1 The RSA key length specified here must not be lower than the minimum key length configured on the server.

IGEL OS Base System 178 / 647



Certification Authority Configuration in IGEL OS12

This article shows how to configure the details of the certification authority in IGEL OS. If the CA certificate fingerprint is specified, the client will use it to check the integrity of the CA certificate it receives from the SCEP server.

Menu path: Network > SCEP Client (NDES) > Certification Authority




The details for the following fields can be obtained from the certification authority:

CA identifier

FQDN (Fully Qualified Domain Name) of the CA

CA certificate fingerprint (MD5)

MD5 fingerprint of the root certificate in the form 01:02:03:04:05:06:07:08:09:0A:0B:0C:0D:0E:0F:10




IGEL OS Base System 179 / 647



VPN Settings in IGEL OS 12

Remote users securely access company networks via virtual private network (VPN) protocols. This article shows how to configure the tray icon, the context menu, and the dialog window for VPN in IGEL OS.

Menu path: Network > VPN



Enable tray icon

✓ A tray icon for the network interface will be shown. (Default)

Enable context menu

✓ A context menu will be shown when you click on the tray icon. (Default)

Enable network info dialog

✓ A dialog window with information regarding the network connection will be shown when you click on the context menu. (Default)

IGEL OS Base System 180 / 647



• OpenVPN in IGEL OS 12 (see page 182)

IGEL OS Base System 181 / 647




OpenVPN in IGEL OS 12

The OpenVPN client puts in place a virtual private network using TLS encryption and requires OpenVPN 2.x as a VPN server. This article shows how to configure OpenVPN connection in IGEL OS.



If problems occur with OpenVPN, read the /var/log/syslog file with the System Log Viewer. For more information, see System Log Viewer in IGEL OS 12²⁹.

Menu path: Network > VPN > OpenVPN



Enable autostart during boot

- ✓ Autostart will be enabled for the session selected under **Autostart session ID**.
- ☐ Autostart is disabled. (Default)

Restart connection when disconnected

✓ The connection is restarted automatically when a disconnect occurs.

29. https://kb.igel.com/en/igel-os-base-system/12.6.1/system-log-viewer-in-igel-os-12

IGEL OS Base System 182 / 647



☐ The connection is not restarted automatically when a disconnect occurs. (Default)

Autostart session ID

Select the desired session from the list of OpenVPN sessions to enable this connection to be established during the boot procedure.


To manage the list of OpenVPN sessions, proceed as follows:

- Click to create a new entry.
- Click to remove the selected entry.
- Click / to edit the selected entry.
- Click to copy the selected entry.

Clicking • opens the configuration pages for the OpenVPN session.

OpenVPN Session Configuration

Menu path: Network > VPN > OpenVPN > [OpenVPN Session Name]



IGEL OS Base System 183 / 647



Session name: Name for the session.



The session name must not contain any of these characters: \ / : * ? " < > | [] { } ()

Starting Methods for Session

Start menu

✓ The session can be launched from the start menu.

If you specify a folder name or a path comprising a number of folder names separated by "/", a menu path will be created for the session. The menu path will be used in the start menu and in the desktop context menu.

Start menu's system tab

✓ The session can be launched with the start menu's system tab.

Application Launcher

✓ The session can be launched with the Application Launcher.

Application Launcher folder

If you specify a folder name or a path comprising a number of folder names separated by "/", a menu path will be created for the session. The menu path will be used in the Application Launcher.

Desktop

✓ The session can be launched with a program launcher on the desktop.

Desktop folder

If you specify a folder name or a path comprising a number of folder names separated by "/", a menu path will be created for the session. The menu path will be used for the program launcher on the desktop.

Desktop context menu

✓ The session can be launched with the desktop context menu.

Quick start panel

✓ The session can be launched with the quick start panel.

IGEL OS Base System 184 / 647



Password protection

Specifies which password will be requested when launching the session.

Possible values:

- **None**: No password is requested when launching the session.
- Administrator: The administrator password is requested when launching the session.
- **User**: The user password is requested when launching the session.
- **Setup user**: The setup user password is requested when launching the session.



Password protection only works if the selected password is configured under Security > Password. Without the password configuration, the session will launch without requesting a password. For more information, see Password and User Types in IGEL OS 12 (see page 233).

Hotkey Configuration

Hotkey

 $|\vec{v}|$ The session can be started with a hotkey. A hotkey consists of one or more **modifiers** and a **key**.

Modifiers

A modifier or a combination of several modifiers for the hotkey. You can select a set key symbol/combination or your own key symbol/combination. A key symbol is a defined chain of characters, e.g. Ctrl.



△ Do not use [AltGr] as a modifier (represented as Mod5). Otherwise, the key that is configured as a hotkey with AltGr cannot be used as a regular key anymore. Example: If you configure [AltGr] + [E] as a hotkey, it is impossible to enter an "e".

These are the pre-defined modifiers and the associated key symbols:

- (No modifier) = None
- fi = Shift
- [Ctrl] = Ctrl
- **#** = Mod4



When this keyboard key is used as a modifier, it is represented as Mod4; when it is used as a key, it is represented as Super_L.

• [Alt] = Alt

Key combinations are formed as follows with |:

IGEL OS Base System 185 / 647



• Ctrl+ = Ctrl|Super_L

Key

Key for the hotkey



To enter a key that does not have a visible character, e. g. the [Tab] key, open a terminal, log on as user and enter xev -event keyboard. Press the key to be used for the hotkey. The text in brackets that begins with keysym contains the key symbol for the **Key** field.

Example: Tab in (keysym 0xff09, Tab)

- IPv4 Settings for OpenVPN in IGEL OS 12 (see page 187)
- Options for OpenVPN in IGEL OS12 (see page 189)
- Proxy (see page 192)
- Network Route in IGEL OS 12 (see page 194)
- OpenVPN Session in IGEL OS12 (see page 196)
- TLS-Options (see page 200)


IGEL OS Base System 186 / 647



IPv4 Settings for OpenVPN in IGEL OS 12

This article shows how to configure DNS and routing settings for OpenVPN connections in IGEL OS. By default, OpenVPN uses the server's DNS and routing settings.

Menu path: Network > VPN > OpenVPN > [OpenVPN Connection] > IPv4



Automatic DNS

✓ The nameserver(s) will be carried over by the OpenVPN server. (Default)

☐ The nameserver(s) specified under **Extra nameserver(s)** will be used.

Extra nameserver(s)

One or more nameservers, IP addresses separated by commas.

Extra search domains

One or more search domains, separated by commas.

IGEL OS Base System 187 / 647

Automatic routes

 \square Extra routes will be configured.



✓ The routing table will be carried over by the OpenVPN server. (Default)
☐ Extra routes will be configured.
VPN is the default route

For details on extra route configuration, see Network Route in IGEL OS 12 (see page 194).

✓ All the traffic is routed through the VPN by default. (Default)

IGEL OS Base System 188 / 647




Options for OpenVPN in IGEL OS12

This article shows how to configure the options for the OpenVPN client in IGEL OS in order to ensure interaction with the server.



Further information regarding the options can be found in the OpenVPN documentation³⁰ which is maintained by the OpenVPN project.

Menu path: Network > VPN > OpenVPN > [OpenVPN Connection] > Options



Gateway port

Local gateway port. (Default: 1194)

30. https://openvpn.net/index.php/open-source/documentation.html

IGEL OS Base System 189 / 647



Custom renegotiation interval

Renegotiate data channel key after given number of seconds. (Default: 0)

Use LZO data compression

✓ The client will use LZO compression. Necessary if the server uses compression.

☐ The client will not use LZO compression. (Default)



If establishing a tunnel fails, try again with Use LZO data compression enabled.



The --comp-lzo option is considered deprecated from OpenVPN v2.4 and should not be used any more. For more information, see https://community.openvpn.net/openvpn/wiki/DeprecatedOptions#Option:-comp-lzoStatus:Pendingremoval.

Protocol used for communication to the host

- UDP: UDP will be used. (Default)
- TCP-client: TCP will be used.



If you use a proxy, select TCP-client.

Virtual network type

- TUN: Routing will be used. (Default)
- **TAP**: Bridging will be used.

Use custom tunnel Maximum Transmission Unit (MTU)

The MTU of the TUN device will be used as a given value. The MTU of the interface will be derived from it.

UDP fragment size

Allow internal data fragmenting up to this size in bytes. Leave this field empty to keep the default value.

Restrict tunnel TCP Maximum Segment Size (MSS)

✓ The TCP segment size (MSS) of the tunnel will be restricted.

☐ The TCP segment size (MSS) will not be restricted. (Default)

Randomize remote hosts

The remote gateways will be ordered randomly as a simple type of load balancing.

IGEL OS Base System 190 / 647 Hashing algorithm for packet authentication (Default: SHA1)



☐ The remote computers will not be ordered randomly. (Default)
Cipher Encryption algorithm for data packets. (Default: BF-CBC - Blowfish in the Cipher Block Chaining Mode)
HMAC authentication

IGEL OS Base System 191 / 647




Proxy

This article shows how to set up an optional proxy server for the VPN connection in IGEL OS.

0

If you use a proxy, set the **Communication protocol to the host** as **tcp-client** under **OpenVPN >** [**OpenVPN Connection**] > **Options**. For detailed information on options settings, see Options for OpenVPN in IGEL OS12 (see page 189).

Menu path: Network > VPN > OpenVPN > [OpenVPN Connection] > Proxy



Proxy type

- **None**: Direct connection to the Internet. (Default)
- **HTTP**: HTTP proxy will be used.
- **SOCKS**: SOCKS proxy will be used.

IGEL OS Base System 192 / 647



Proxy address

Name or IP address of the proxy server

Proxy port

Port on which the proxy service is available

Retry indefinitely when errors occur

✓ In the event of errors, repeated attempts to establish a connection via proxy will be made.

 \square No further attempts to establish a connection will be made. (Default)

The following credentials are for the **HTTP** proxy type:

Proxy user name

User name for the proxy server

Proxy password

Password for the proxy server


IGEL OS Base System 193 / 647



Network Route in IGEL OS 12

This article shows how to configure extra routes for the network in IGEL OS.

Menu path: Network > VPN > OpenVPN > [OpenVPN Connection] > Route [0,1,2]



Enable

✓ This route is enabled.

☐ This route is not enabled. (Default)

Network route / Host route

- **Network route**: The routing relates to a (sub) network. (Default)
- Host route: The routing relates to the address of a computer.

Network/Host IP

The address of the network (for a network route) or the IP address or the name of the host (for a host route).

IGEL OS Base System 194 / 647



Network mask

Mask for the desired IP range, e.g. 255.255.255.0

Gateway

Gateway that routes the packets to the target network.

Metric

The numerical quality assessment for routing decisions, 0 is the best value.


IGEL OS Base System 195 / 647



OpenVPN Session in IGEL OS12

This article shows how to configure the authentication of the OpenVPN session in IGEL OS.

Menu path: Network > VPN > OpenVPN > [OpenVPN Connection] > Session



OpenVPN server(s)

Name or public IP address of the OpenVPN server. You can enter multiple values separated by commas.

Authentication type

- TLS-Certificates: Authentication with user certificate and private key.
- Name/Password: Authentication with user name and password.
- Name/Password with TLS-Certificates: Combines name/password with user certificate.
- Static Key: Authentication with a private key. No PKI infrastructure is needed for this.

IGEL OS Base System 196 / 647



TLS Certificates Authentication Type



• Persistent storage of files is possible in the folder /wfs resp. subfolders of /wfs only. Files stored under other paths will be lost when the device is rebooted.

Client certificate file

File with the client certificate. Enter a path relative to /wfs/OpenVPN.

CA certificate file

File with the CA certificate. Enter a path relative to /wfs/OpenVPN.

Private key file

File with the private key. Enter a path relative to /wfs/OpenVPN.

Private key password

Password in case one is set for the private key.



If you have a PKCS#12 file which contains the client certificate, CA certificate and private key, always enter its name in the three file fields. The advantage lies in the fact that only a single file needs to be distributed.



🛕 When you leave the **Private key password** option empty, a password dialog pops up when you start your openvpn session to enter the password. On versions below OS 12.4.0, the password dialog only works for keys based on RSA. Starting from OS version 12.4.0, EC keys are also supported.

Name/Password Authentication Type

User name

User name - if you leave this field empty, the user will be asked for it when establishing a connection.

Password required



Password

Password - if you leave this field empty, the user will be asked for it when establishing a connection.

IGEL OS Base System 197 / 647



CA certificate file

File with the CA certificate. Enter a path relative to /wfs/OpenVPN.

Name/Password with TLS-Certificates Authentication Type

User name

User name - if you leave this field empty, the user will be asked for it when establishing a connection.

Password required

✓ The user must enter a password. (Default)

Password

Password - if you leave this field empty, the user will be asked for it when establishing a connection.

Client certificate file

File with the user certificate. Enter a path relative to /wfs/OpenVPN.

CA certificate file

File with the CA certificate. Enter a path relative to /wfs/OpenVPN.

Private key file

File with the private key. Enter a path relative to /wfs/OpenVPN.

Private key password

Password in case one is set for the private key.



If you have a PKCS#12 file which contains the user certificate, CA certificate and private key, always enter its name in the three file fields. The advantage lies in the fact that only a single file needs to be distributed.

Static Key Authentication Type

Private key file

File with the static key. Enter a path relative to /wfs/OpenVPN .

Key Direction

• None: No key direction. (Default)

IGEL OS Base System 198 / 647



- **0**: If the default option is not used, one side of the connection should use Direction 0 and the other Direction 1.
- 1: If the default option is not used, one side of the connection should use Direction 0 and the other Direction 1.

Remote IP address

The VPN IP address of the server

Local IP address

The VPN IP address of the client


IGEL OS Base System 199 / 647



TLS-Options

Transport Layer Security (TLS) is the successor to Secure Sockets Layer (SSL). It is a standard consisting of several protocols that can transmit encrypted data between authenticated communication partners over potentially insecure IP networks such as the Internet. This article shows how to configure TLS options for the OpenVPN protocol in IGEL OS.

Menu path: Network > VPN > OpenVPN > [OpenVPN Connection] > TLS-Options



Subject match

The Subject Match accept/reject the server connection based on a custom test of the server certificate's embedded X509 subject details. The formatting of these fields changed into a more standardized format: **C=** US ,

L= Somewhere, CN= JohnDoe, emailAddress= john@example.com.

For more information, see the Reference manual for OpenVPN 2.6³¹.

Remote peer certificate TLS type

Require that peer certificate was signed with an explicit key usage and extended key usage based on RFC3280 TLS rules.

IGEL OS Base System 200 / 647

^{31.} https://openvpn.net/community-resources/reference-manual-for-openvpn-2-6//



This is a useful security option for clients, to ensure that the host they connect to is a designated server. Or the other way around; for a server to verify that only hosts with a client certificate can connect.

- **Do not verify**: No remote certificate check. (Default)
- Check for server certificate: The --remote-cert-tls server option is equivalent to --remote-certku --remote-cert-eku "TLS Web Server Authentication".
- Check for client certificate: The --remote-cert-tls client option is equivalent to --remote-certku --remote-cert-eku "TLS Web Client Authentication".



1 This is an important security precaution to protect against a man-in-the-middle attack, where an authorized client attempts to connect to another client by impersonating the server. The attack is easily prevented by having clients verify the server certificate using any one of --remote-cert-tls, --verify-x509name, or --tls-verify.

Key file for additional TLS authentication

As the path enter relative to /wfs/OpenVPN or select using the file selection. This adds an additional HMAC legitimization level above the TLS control channel in order to prevent DDOS attacks.

tls-auth (Key Direction) / tls-crypt

- **None**: No key direction. (Default)
- tls-auth 0: If the default option is not used, one side of the connection should use Direction 0 and the other Direction 1.
- tls-auth 1: If the default option is not used, one side of the connection should use Direction 0 and the other Direction 1.
- tls-crypt: In contrast to tls-auth, setting a key direction is not required. Use this option if the version of the OpenVPN server is 2.4 or higher. For more information on tls-crypt, see Reference manual for OpenVPN 2.6³².

IGEL OS Base System 201 / 647


^{32.} https://openvpn.net/community-resources/reference-manual-for-openvpn-2-6//



Proxy Configuration in IGEL OS 12

This article shows how to select the communication protocols for which a system-wide proxy server is to be used in IGEL OS.

Menu path: Network > Proxy



System-wide proxy configuration

Possible options:

• Direct connection to the Internet (Default)

The endpoint device is directly connected to the Internet. No proxy is used.

• Manual proxy configuration

You can configure one or more proxies in the fields from **FTP proxy** up to **SOCKS protocol version**, see Manual Proxy (see page 202).

• Automatic proxy configuration

The proxy settings are dynamically retrieved via a PAC file (Proxy Auto Config) that you specify under **URL**, see Automatic Proxy (see page 204). For more information on PAC, see e.g. https://en.wikipedia.org/wiki/Proxy_autoconfig. If no PAC file can be obtained or no proxy is reachable, a direct connection to the internet is attempted.

Manual Proxy Configuration

FTP proxy / Port

FTP proxy server and port

HTTP proxy / Port

IGEL OS Base System 202 / 647



HTTP proxy server and	port
-----------------------	------

SSL proxy / Port

SSL proxy server and port

SOCKS host / Port

Socks proxy server and port

SOCKS protocol version

Selects the SOCKS protocol version. (Default: SOCKS v5)

No proxy for

List of computers to which the endpoint device is to connect directly, separated by commas. (Default: localhost,127.0.0.1)

Proxy realm for browser

Area in which the browser authenticates itself for the proxy. Together with the user name and password, this information is necessary for authentication.

Authentication at proxy (NTLM/HTTP Basic)

IGEL OS supports NTLM and HTTP Basic authentication at the proxy using the below parameters.

Use passthrough authentication

✓ The logon information saved temporarily when logging on to the OS 12 device will be carried over when logging on to the proxy.

☐ The login information entered under **User name** and **Password** will be used to log in to the proxy server. (Default)

User name

User name with which the system authenticates itself for the proxy.

Password

Password with which the system authenticates itself for the proxy.

Allow HTTP Basic authentication



Please note that the password is sent to the proxy unencrypted if HTTP Basic encryption is used.

IGEL OS Base System 203 / 647



✓ Authentication via HTTP Basic is allowed.	
☐ Authentication via HTTP Basic is disallowed.	Default

Automatic Proxy Configuration

URL

URL of the PAC file for automatic proxy configuration



This field can be left blank for Web Proxy Auto-Discovery (WPAD) via DHCP and well known URLs.

No Proxy for

List of computers to which the endpoint device is to connect directly, separated by commas. (Default: localhost,127.0.0.1)

Proxy realm for browser

Area in which the browser authenticates itself for the proxy. Together with the user name and password, this information is necessary for authentication.

Authentication at proxy (NTLM/HTTP Basic)

IGEL OS supports NTLM and HTTP Basic authentication at the proxy using the below parameters.

Use passthrough authentication

 \checkmark The logon information saved temporarily when logging on to the OS 12 device will be carried over when logging on to the proxy.

☐ The login information entered under **User name** and **Password** will be used to log in to the proxy server. (Default)

User name

User name with which the system authenticates itself for the proxy.

Password

Password with which the system authenticates itself for the proxy.

Allow HTTP Basic authentication



Please note that the password is sent to the proxy unencrypted if HTTP Basic encryption is used.

IGEL OS Base System 204 / 647



 \Box Authentication via HTTP Basic is disallowed. (Default)

IGEL OS Base System 205 / 647



Devices in IGEL OS12

In this chapter, you find information on the configuration of devices in IGEL OS.

- Hardware Info (see page 207)
- Storage Devices (see page 208)
- Bluetooth in IGEL OS 12 (see page 217)
- USB Access Control in IGEL OS 12 (see page 218)
- Audio in IGEL OS 12 (see page 223)
- Webcam Information in IGEL OS 12 (see page 225)

IGEL OS Base System 206 / 647




Hardware Info

The **Hardware info** button provides quick access to information about the endpoint device and the connected devices.

8

The page is only available locally on the device in the IGEL Setup. In order to access the page from the UMS, you need to shadow the device. For detailed information on shadowing, see Shadow Settings in IGEL OS 12 (see page 283) and Universal Management Suite > UMS Reference Manual > Devices - Managing Devices in the IGEL UMS > Shadowing - Observe IGEL OS Desktop via VNC.

Menu path: Devices > Hardware Info



->Click **Hardware info** to view information on the used hardware in the **System Information** dialog. For more information on the dialog, see System Information (see page 26).

IGEL OS Base System 207 / 647




Storage Devices

The **Show attached storage devices** button provides quick access to information about registered storage devices.



The page is only available locally on the device in the IGEL Setup. In order to access the page from the UMS, you need to shadow the device. For detailed information on shadowing, see Shadow Settings in IGEL OS 12 (see page 283) and Universal Management Suite > UMS Reference Manual > Devices - Managing Devices in the IGEL UMS > Shadowing - Observe IGEL OS Desktop via VNC.

Menu path: **Devices > Storage Devices**



->Click **Show attached storage devices** to view a list of registered storage devices in the **Disk Utility** dialog. For more information on the dialog, see Disk Utility (see page 214).

- Storage Hotplug in IGEL OS 12 (see page 209)
- Options (see page 212)
- Disk Utility (see page 214)
- Safely Remove Hardware in IGEL OS 12 (see page 216)

IGEL OS Base System 208 / 647



Storage Hotplug in IGEL OS 12


This article shows how to set up the connection of hotplug storage devices to the device in IGEL OS. These can be, for example, USB mass storage devices or MMC card readers.

0

For related settings options of the Citrix Workspace App, see Configuration of the Citrix Workspace App on IGEL OS .

For related settings in the Devices area, see USB Access Control in IGEL OS 12 (see page 218) and Safely Remove Hardware in IGEL OS 12 (see page 216).

Menu path: Devices > Storage Devices > Storage Hotplug



The following file systems are officially supported:

IGEL OS Base System 209 / 647



ext2, ext3, ext4	Standard Linux file systems
squashfs	a packed read-only file system
vfat	supports all FAT variants
exFAT	supports exFAT (found on SDXC SD-cards)
ISO 9660	CDROM/DVD file systems
udf	CDROM/DVD file systems
ntfs	supported with ntfs-3g (Fuse)

Enable dynamic client drive mapping

Defines the creation of drives in ICA sessions, RDP sessions or Horizon sessions. The mounting of hotplug storage devices to the local file system is not influenced by this parameter.

✓ Drives are created automatically in a session when a hotplug storage device is connected to the device. When the device is removed, the corresponding drive is removed automatically.

☐ Drives are not created automatically in a session when a hotplug storage device is connected to the device.



Before you unplug a hotplug storage device from the endpoint device, you must safely remove it.

Otherwise, data on the hotplug storage device can be damaged. Depending on the configuration, there are several ways to safely remove a hotplug storage device:

- Click in the task bar. The taskbar can be made available in a full-screen session by enabling **Taskbar on top of all windows** under **User Interface > Desktop > Taskbar**. For more information, see Taskbar Configuration in IGEL OS 12 (see page 108).
- Click in the in-session control bar. Depending on the configuration, the in-session control bar may be available in a full-screen session. For further information, see In-Session Control Bar in IGEL OS 12 (see page 124).
- Use the Safely Remove Hardware function. The function can be configured under Devices > Storage Devices > Safely Remove Hardware. For more information, see Safely Remove Hardware in IGEL OS 12 (see page 216).

If the following warning is displayed: **Volume(s) still in use. Don't remove the device.**, then the hotplug storage device must not be removed. First, exit the program concerned or close all files or directories that reside on the hotplug storage device.

Default permission

Default access rights for hotplug storage devices. Possible values:

- Read only
- Read/Write (Default)

IGEL OS Base System 210 / 647



Notification

Hotplug beep

✓ A signal tone will be heard when connecting and disconnecting hotplug storage devices. (Default)

Hotplug message

✓ Hotplug messages will be shown when connecting and disconnecting hotplug storage devices. (Default)

Timeout

Period of time in seconds after which the window with the hotplug messages is hidden. If the parameter is set to **No timeout**, the window will be shown until it is closed manually. (Default: 15)


IGEL OS Base System 211 / 647



Options

This article shows how to specify a directory in which external storage devices are accessible to the user in IGEL OS. The devices are always mounted in the /media directory.

Menu path: **Devices > Storage Devices > Options**



User browse directory

✓ The directory defined under **Browse directory:** / is linked to the /media directory. (Default)

Browse directory: /

IGEL OS Base System 212 / 647



Local directory in which the devices can be found. (Default: userhome/media)

Support for built-in floppy drives

- **✓** Built-in disk drives are active.
- **✓** Built-in disk drives are disabled. (Default)



This option is only valid for drives which are not connected via USB.

IGEL OS Base System 213 / 647




Disk Utility

With the Disk Utility function, you can obtain information regarding the hotplug storage devices connected to your endpoint device in IGEL OS. You can also use the function to safely remove hotplug storage devices.

0

The Disk Utility function can only be started if the automatic mounting of hotplug storage devices is enabled through the **Enable dynamic client drive mapping** option under **Devices > Storage Devices > Storage Hotplug**.

Menu path: Devices > Storage Devices > Disk Utility



The starting methods parameters are described under Starting Methods for Apps (see page 644).




If the **Disk utility in eject menu** option is enabled under **Devices > Storage Devices > Safely Remove Hardware**, the Disk Utility can also be started from the context menu of the eject icon in the taskbar.

IGEL OS Base System 214 / 647



Using Disk Utility

→ Start **Disk Utility**.



To obtain information regarding a hotplug storage device connected to your endpoint device:

→ Select the hotplug storage device in the left-hand column.

The information regarding the hotplug storage device is shown in the right-hand column.

To remove a hotplug storage device safely:

→ Click **Safely Remove Hardware** in the right-hand column.

The hotplug storage device is disconnected from the endpoint device. Once it has been disconnected, the storage device can be removed from the device.

0

If the **Hotplug beep** option is enabled under **Devices > Storage Devices > Storage Hotplug**, a signal tone will signal that the device has been disconnected successfully.

If the **Hotplug message** option is enabled under **Devices > Storage Devices > Storage Hotplug**, a message window will signal that the device has been disconnected successfully.

For more information, see Storage Hotplug in IGEL OS 12 (see page 209).


IGEL OS Base System 215 / 647



Safely Remove Hardware in IGEL OS 12

With the Safely Remove Hardware function, you can remove a hotplug storage device connected to your endpoint device safely, without the risk of losing data. This article shows how to configure the starting methods for the function in IGEL OS.

Menu path: Devices > Storage Devices > Safely Remove Hardware



The starting methods parameters are described under Starting Methods for Apps (see page 644).

Disk utility in eject menu

✓ The **Disk Utility** can be started from the context menu of the eject icon in the taskbar. (Default)

To start the function, click on and select **Disk Utility**. For more information on using the function, see Disk Utility (see page 214).

IGEL OS Base System 216 / 647



Bluetooth in IGEL OS 12

This article shows how to set up a Bluetooth service in IGEL OS. For details on the settings options for Bluetooth devices, see Tray Applications in IGEL OS 12 (see page 358).

Menu path: **Devices > Bluetooth**



Bluetooth

✓ The Bluetooth service is active. (Default)

Autopair input devices if no input devices are connected

✓ If neither a mouse nor a keyboard is connected to the device, autopairing with Bluetooth input devices will be attempted. (Default)


IGEL OS Base System 217 / 647



USB Access Control in IGEL OS 12

This article shows how to control USB access to the endpoint device in IGEL OS. You can allow or prohibit the use of USB devices on your endpoint. Specific rules for individual devices or device classes are possible.

Menu path: Devices > USB Access Control



Enable

✓ USB access control is enabled and the following settings can be configured.

☐ USB access control is inactive. (Default)

IGEL OS Base System 218 / 647



The activation of USB Access Control and setting the Default rule to Deny will block the use of USB devices locally and in the session and, thus, might disable devices needed for the users. Therefore, activate the USB access control only if your security policy requires that. In this case, set **Default rule** to **Deny** and configure **Allow** rules for the required USB devices and USB device classes.

It is recommended to make settings for **USB Access Control** as the last step in the device configuration. Before activating the USB access control, check that all your other settings for printers, Unified Communication, USB redirections, mapping settings for USB devices are working as expected. Note that the USB access control is completely separate than USB redirection for remote sessions. Take also notice that the feature does not disable a USB port physically, i.e. power delivery will still work.

Default rule

Specifies whether the use of USB devices is allowed or prohibited.

- Allow (Default)
- Deny

Default permission

Default access rights for USB devices.

- Read Only
- Read/Write (Default)

Class Rules

Class rules apply to USB device classes. To manage the list of class rules:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking brings up the **Add** dialogue, where you can define the following settings:

• Rule

Specifies whether the use of the device class defined here is allowed or prohibited.

- Allow
- -Deny (Default)
- Class ID

Device class for which the rule should apply. (Examples: Audio, Printers, Mass Storage).

Name

IGEL OS Base System 219 / 647



Name of the rule

Device Rules

Device rules apply to specific USB devices. To manage the list of device rules:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking brings up the **Add** dialogue, where you can define the following settings:

• Rule

Specifies whether the use of the device defined here is allowed or prohibited.

- -Allow
- -Deny (Default)
- Vendor ID

Hexadecimal ID of the device manufacturer

Product ID

Hexadecimal ID of the device




Getting USB Device Information

To find out the **Class ID**, **Subclass ID**, **Vendor ID** and **Product ID** of the connected USB device, you can use the **System Information** tool. For further information, see System Information (see page 26). System Information example:

IGEL OS Base System 220 / 647





Device UUID

IGEL OS Base System 221 / 647



Universal Unique Identifier (UUID) of the device

• Permission

Authorizations for access to the device Possible values:

- -Global setting: The default setting for hotplug storage devices is used; see the **Default** permission parameter under **Devices > Storage Devices > Storage Hotplug**. For more information, see Storage Hotplug in IGEL OS 12 (see page 209).
- -Read only
- -Read/Write
- Name

Name of the rule


IGEL OS Base System 222 / 647



Audio in IGEL OS 12

This article shows how to configure presets for the audio system in IGEL OS. The settings can also be changed using the Sound Tray App. For details, see Tray Applications in IGEL OS 12 (see page 358).

Menu path: Devices > Audio > Options



Use volume setting supplied by UMS

✓ The settings for the below parameters **Mute**, **PCM volume**, **Input mute**, and **Input volume** are restored after each system restart. The settings set in **Sound Preferences** or in the taskbar will only remain until system restart.

☐ The settings set in **Sound Preferences** or in the taskbar will be restored after system restart. (Default)

Mute

✓ Audio playback is muted.

☐ Audio playback is on. (Default)

PCM volume

Preset volume in percent. (Default: 50)

Input mute

✓ The audio input is muted. Sounds from a microphone that are recorded are not transferred to the endpoint device.

IGEL OS Base System 223 / 647



\square The audio input is switched on. Sounds from a microphone that are recorded can be transferred to the endpoi device. (Default)
Input volume
Volume of recorded sounds at the audio input device in percent. (Default: 100)
Overamplification
Enable volume overamplification
✓ Allows to set the volume up to 150%.
□ The volume cannot be overamplified. (Default)
Enable input volume overamplification
✓ Allows to set the input volume up to 150%.
□ The input volume cannot be overamplified. (Default)

Default audio output

Default Sound Output

Name of the output port Possible options:

- **Automatic**: The audio output is automatically assigned to a device. Not connected ports will be ignored.
- HDMI / DisplayPort
- Speakers
- Headphones

Default Sound Input

Default audio input

Name of the input port Possible options:

- **Automatic**: The audio input is automatically assigned to a device. Not connected ports will be ignored. The following order applies here:
 - 1. USB devices
 - 2. PCI devices
- Microphone
- Headset microphone


IGEL OS Base System 224 / 647



Webcam Information in IGEL OS 12

With the Webcam Information function, you can select and test a webcam in IGEL OS 12. If required, you can adjust the width and height via the command line.

Menu path: **Devices > Webcam Information**



The starting methods parameters are described under Starting Methods for Apps (see page 644).

Using Webcam Information


Selecting the Camera

1. Start the **Webcam Information** tool.

IGEL OS Base System 225 / 647




2. Select the camera you want to use and click **OK**.




The live image of the selected camera is shown on your device.

You can switch between cameras anytime by clicking on the camera selector.



IGEL OS Base System 226 / 647





Changing the Width and Height

By default, the Webcam Information tool uses the camera's default width and height.

→ To change the width and height of the camera image, start the program from the command line like this:

qcam -s width=<WIDTH IN PIXELS>,height=<HEIGHT IN PIXELS>

Example:

qcam -s width=800,height=600

- You can determine the values supported by the webcam in the local terminal with the command webcam-info -1.
- In order to check whether the webcam is functioning in a session (e.g. redirected via Citrix HDX Webcam Redirection), open https://www.onlinemictest.com/webcam-test/ in your browser within the session.

IGEL OS Base System 227 / 647



Security Configuration in IGEL OS 12

In this chapter, you find information on security configuration in IGEL OS.

- Device Encryption in IGEL OS 12 (see page 229)
- Password and User Types in IGEL OS 12 (see page 233)
- Logon Settings in IGEL OS 12 (see page 238)
- Active Directory/Kerberos (see page 254)
- Smartcard Services in IGEL OS 12 (see page 260)
- Change Password in IGEL OS 12 (see page 262)
- Update (see page 266)
- Certificates Enrolled via the UMS as CA Proxy (see page 267)


IGEL OS Base System 228 / 647



Device Encryption in IGEL OS 12

If you want to strengthen the security of your endpoint device, you can deploy strong device encryption that is derived from a user password. The encryption is applied to all partitions that can contain user data, e.g. browser history or Custom Partitions.

Menu path: Security > Device Encryption



Device encryption mode

Possible options:

• **Keep:** The default encryption scheme is maintained. If a password has been set, it will remain unchanged. (Default)

IGEL OS Base System 229 / 647



- Activate: The device will be re-encrypted using strong encryption methods when the user enters the password for the first time. It is strongly recommended to enforce the use of a strong password; see Minimum password length (see page 231) and the subsequent password settings. The re-encryption may take about 10 to 60 seconds; the duration depends on the hardware performance and the size of the Custom Partition.
- Deactivate: The device will be re-encrypted back to the default device encryption scheme on the next boot. The re-encryption may take about 10 to 60 seconds.



If you want to switch back to the default device encryption, you must have the password. If the password gets lost, you must reinstall IGEL OS on the device, for example, using the OS Creator. For detailed instruction, see How to Start with IGEL > Installing the Base System via IGEL OS Creator (OSC).

Change password

Only applicable if device encryption is activated. Click the button to change the password for device encryption.

Authentication type

Possible options:

- PW: Password only authentication.
- TPM+PIN: TPM is a physical chip in the device, specifically designed to securely store cryptographic keys (and other data). IGEL supports the TPM 2.0 implementation, so the used hardware device is also required to support TPM 2.0. If TPM is used then you will need a further authentication method in order to finish booting and unencrypting the device. In order to access the key in the TPM, the user needs to insert a PIN first.
- TPM PCR: The TPM chip automatically validates the integrity of the hardware. Only supported by a
- TPM PCR+PIN: The above mentioned methods combined.



Devices That Support TPM PCR

Trusted Platform Module (TPM) Platform Configuration Register (PCR) is only supported by the following devices:

- HP T640
- IGEL UD 3 (M350C with Bios version V:3.D.13A-05232022 or higher)
- IGEL UD 7 (H860C with Bios version 3.6.13A-05202022 or higher)

If TPM PCR is selected on a device that does not support it, the authentication type falls back to PW (password authentication).

If TPM PCR+PIN is selected on a device that does not support it, the authentication type falls back to TPM+PIN.

Security level

Possible options:

230 / 647 **IGEL OS Base System**



- Auto, constant-time: The password aggregation function that fits best with the defined Target time delay (ms) is selected and the manual selection under Password aggregation function is ignored. (Default)
- Auto, at least level: The security level will be at least as high as the value selected by Password
 aggregation function; if the Target time delay (ms) allows for a higher security level, the higher
 security level will be used.
- Manual: The Password aggregation function can be set manually, irrespective of the delay time specified by Target time delay (ms).

Target time delay (ms)

Maximum time that should be consumed by the password aggregation function. This delay is effective when the user enters the device encryption password on boot or changes the device encryption password. (Default: 700)

Password aggregation function

Security level of the encryption. Possible options:

- I: Argon2id, 8M/7 ops
- II: Argon2id, 128M/3 ops (Default)
- III: Argon2id, 256M/3 ops
- IV: Argon2id, 512M/3 ops
- V: Argon2id, 1024M/4 ops
- VI: Argon2id, 128M/4 ops

Minimum password length

Minimum number of characters the password must be composed of. (Default: 8)

Unwanted strings in password (comma separated)

Comma-separated list of strings that must not be in the password

The password must contain

Defines how many of the subsequent minimum requirements (minimum amount of lower case letters, etc.) must be fulfilled.

Possible options:

- All (Default)
- 2 of
- 3 of

Minimum amount of lower case letters

Defines at least how many lower case letters must be in the password.

Minimum amount of upper case letters

IGEL OS Base System 231 / 647



Defines at least how many upper case letters must be in the password.

Minimum amount of numbers

Defines at least how many numbers must be in the password.

Minimum amount of special characters

Defines at least how many special characters must be in the password.

Special characters allowed

Lists all the non-alphanumerical characters without separators that are allowed in the password.


IGEL OS Base System 232 / 647



Password and User Types in IGEL OS 12

The following article provides details on the user types and their roles in IGEL OS. You can configure passwords for the user types to protect your endpoint devices against unwanted changes.

Menu path: Security > Password



IGEL Setup Password Protection

Configure the administrator password to create the password protection for the IGEL Setup. You can also configure the setup administrator and the setup user to allow additional access to the IGEL Setup. For more information, see Setup (see page 32).

IGEL OS Base System 233 / 647





The assignment of the administrator password is a prerequisite for all other rights assignments. Even if the administrator wants to leave the administration of the IGEL Setup to the setup administrator, the administrator password must be set.



If you do not configure any password, the IGEL Setup can be opened without password protection.

User Rights

The user types have the following access rights:

- Administrator: If configured, the administrator password protects the following critical actions/ areas from unauthorized access:
 - IGEL Setup
 - Reset to factory defaults boot mode. (For more information, see Boot Menu in IGEL OS 12 (see page 390) .)
 - Accessing the local terminal as root. (For more information, see Terminals in IGEL OS (see page 13) .)
 - Virtual console access. (For more information, see Access Control to the Display in IGEL OS 12 (see page 52) .)
 - sessions, for which **Administrator** is set under **Password protection**. (For more information, see Starting Methods for Apps (see page 644).)

If configured, the administrator can access the following with a password:

- Unlocking the screenlock. (For more information, see Options (see page 58).)
- Secure Shell (SSH). (For more information, see SSH Access in IGEL OS 12 (see page 280).)
- Setup administrator: If configured, the setup administrator can access the following with a password:
 - IGEL Setup
- **Setup user**: If configured, the setup user can access the following with a password:
 - IGEL Setup. (Unlike in OS 11, in OS 12 the Setup User can access all parts of Setup.)
 - sessions, for which **Setup user** is set under **Password protection**. (For more information, see Starting Methods for Apps (see page 644) .)



If you configure a Setup user in OS 12, they have effectively the same Setup permissions as the Administrator. This includes running Custom Commands (command execution with privilege escalation).

- **User**: If configured, the user can access the following with a password:
 - the terminal session as user. (For more information, see Terminals in IGEL OS (see page 13).)

IGEL OS Base System 234 / 647



• sessions, for which **User** is set under **Password protection**. (For more information, see Starting Methods for Apps (see page 644) .)



 You can also use the User password for starting the screenlock: User Interface > Screenlock / Screensaver > Starting Methods for Session > Password protection. For details, see Screenlock / Screensaver in IGEL OS 12 (see page 57).

However, note the following:

The **User** is not the same as the local user configured under **Security > Logon > Local User**. For unlocking the screenlock, the local user password (not the user password) is used. For details, see Local User Login in IGEL OS 12 (see page 248) and Options (see page 58).

• User account for remote access: If configured, the ruser can access the device via Secure Shell (SSH). (For more information, see SSH Access in IGEL OS 12 (see page 280).)

Administrator

Use password

 $| \vec{V} |$ Administrator password protection is enabled and further user types can be configured. The password is set by clicking Set password.

☐ Administrator access is granted without password protection. No password can be configured for the user (user), the setup user, and the setup administrator. (Default)

Change password

Click the button to set a new password.



Effects on local terminal access

Setting an administrator password has the following effects on the access to local terminals:

- For logging in as root, the administrator password must be entered.
- Logging in as user is no longer possible by default. However, you can allow access for user by making the following settings:

- Enable the registry key system.security.usershell (Default: Disabled).
- Set a user password.

For logging in as user, the user password will have to be entered.

IGEL OS Base System 235 / 647



Setu	$n \wedge a$	min	ictr	つナヘド
70111	I) A(41 CH

Setup Administrator
Setup administrator access
This option is only available if an administrator password is set.
✓ The setup administrator can access the IGEL Setup with a password. The password is set by clicking Set password .
\square The setup administrator cannot access the IGEL Setup. (Default)
Change password
Click the button to set a new password.
Setup User
Setup user access
This option is only available if an administrator password is set.
✓ Setup user password protection is enabled. The password is set by clicking Set password .
☐ The setup user cannot access the IGEL Setup. Sessions, for which Setup user is set under Password protection will not have password protection. (Default)
Change passward
Change password
Click the button to set a new password.
User
Use password
This option is only available if an administrator password is set.
✓ User password protection is enabled. The password is set by clicking Set password .

Change password

Click the button to set a new password.

User Account for Remote Access

Enable login

✓ The remote user (ruser) can log in to the device via SSH. (Default)

236 / 647 IGEL OS Base System

☐ If an administrator password is set, the user (user) cannot log in to the device via the local terminal. Sessions,

for which **User** is set under **Password protection** will not have password protection. (Default)



□ Logging in via SSH is not possible. For further SSH access settings, see SSH Access in IGEL OS 12 (see page 280).
Use password ✓ A password is needed to log in via SSH. The password is set by clicking Set password.
□ No password is needed to log in via SSH. (Default) Change password Click the button to set a new password.

IGEL OS Base System 237 / 647



Logon Settings in IGEL OS 12

The following logon settings are available in IGEL OS.

- Taskbar (see page 239)
- Active Directory/Kerberos Enable Login in IGEL OS 12 (see page 242)
- Single Sign-On in IGEL OS 12 (see page 244)
- Local User Login in IGEL OS 12 (see page 248)
- Guest Passwordless Access to IGEL OS 12 (see page 250)
- UMS as Identity Broker with IGEL OS 12 (see page 252)


IGEL OS Base System 238 / 647



Taskbar

This article shows how to configure the taskbar for the login dialog and for when the screen is locked in IGEL OS.

Menu path: Security > Logon > Taskbar



Taskbar Settings for the Login Dialog

Show taskbar in login screen

✓ A taskbar is shown in the login screen. (Default)

Show clock

IGEL OS Base System 239 / 647



✓ A clock is shown in the taskbar in the login screen. (Default)
Show keyboard layout switcher
✓ A keyboard layout switcher is shown in the taskbar in the login screen. (Default)
Show on-screen keyboard button
✓ A button to start an on-screen keyboard is shown in the taskbar in the login screen.
☐ The button is not shown. (Default)
Start on-screen keyboard automatically
✓ The on-screen keyboard is started automatically with the login screen.
☐ The on-screen keyboard is not started automatically. (Default)
Show reboot button
✓ Reboot button is shown in the taskbar in the login screen.
☐ The button is not shown. (Default)
Show shutdown button
✓ Shutdown button is shown in the taskbar in the login screen. (Default)
Taskbar Settings When the Screenlock Is Active
Show taskbar in screenlock
✓ A taskbar is shown when the screen is locked. (Default)
Show clock
✓ A clock is shown in the taskbar when the screen is locked. (Default)
Show keyboard layout switcher
✓ A keyboard layout switcher is shown in the taskbar when the screen is locked. (Default)
Show on-screen keyboard button
✓ A button to start an on-screen keyboard is shown in the taskbar when the screen is locked.
☐ The button is not shown. (Default)

IGEL OS Base System 240 / 647



Start on-screen keyboard automatically
${\color{red} {\not \! \! \! \! \! \! \! \! \! \! \! \! \! \! \! \! \! \! $
\square The on-screen keyboard is not started automatically. (Default)
Show reboot button
✓ Reboot button is shown in the taskbar when the screen is locked.
\square The button is not shown. (Default)
Show shutdown button
${m ec{\!$
\square The button is not shown. (Default)
Show logoff button
✓ Logoff button is shown in the taskbar when the screen is locked.
☐ The button is not shown. (Default)

IGEL OS Base System 241 / 647




Active Directory/Kerberos - Enable Login in IGEL OS 12

This article shows how to enable local login to the device via the Kerberos protocol in IGEL OS.



Active Directory/Kerberos must be configured as a prerequisite, see Active Directory/Kerberos (see page 254).

Menu path: Security > Logon > Active Directory/Kerberos



The login can be used for single sign-on in a number of session types (ICA, RDP).

Login to Active Directory domain

- ✓ You can log in to the device via Active Directory.
- ☐ You cannot log in to the device via Active Directory. (Default)

Login Methods

Explicit

- ✓ You can log in with a user name and password. (Default)
- ☐ You cannot log in with a user name and password. If logging in with a smartcard is set up, you can log in with a smartcard.

Remember last user name

- The login dialog will be pre-populated with the last user name that logged on. **Explicit** must be enabled for this.
- ☐ The login dialog will not be pre-populated. (Default)

Smartcard

✓ You can log in using a smartcard.

IGEL OS Base System 242 / 647



☐ You cannot	log in	using a	smartcard.	(Default)
--------------	--------	---------	------------	-----------

Smartcard removal action

Specifies what action is performed when the smartcard via which the user is logged in is removed. Possible actions:

- Log out: The user is logged out from the device. (Default)
- Lock device: The screen is locked.



if the login method is configured and the Allow system logoff option is enabled under System > Power **Options > Shutdown**, the user can log off the device through the shutdown menu. For information on how to access the shutdown menu, see Commands Session in IGEL OS 12 (see page 126) . For information on how to configure the shutdown menu, see Shutdown Settings in IGEL OS 12 (see page 300).

Automatically perform login

✓ The device performs the login automatically on startup. The credentials provided in **Username for autologin** and **Password for autologin** are used for Microsoft Active Directory (AD).

☐ The login is not performed automatically; a login dialog is displayed.

Username for autologin

The username that is used for automatic login.

Password for autologin

The password that is used for automatic login.

IGEL OS Base System 243 / 647




Single Sign-On in IGEL OS 12

Single Sign-On (SSO) is an authentication method that can be used via a cloud-based identity provider (IdP) to access the local device and apps. This article describes the options used for configuring SSO in IGEL OS.



See How to Configure Single Sign-On (SSO) on IGEL OS 12 (see page 547) for a detailed description of the entire SSO configuration process.

Menu path: Security > Logon > Single Sign-On



Single Sign-On with identity provider

SSO is used as the authentication method.



To have a fallback option if something goes wrong with SSO, e.g. a network failure, it is recommended to configure local login in addition under **Security > Logon > Local User**. For more information, see Local User Login in IGEL OS 12 (see page 248).

☐ SSO is not used. (Default)

Identity provider

The identity provider used for the SSO configuration.

Possible options:

- Microsoft Entra ID
- Okta
- OpenID Connect
- Ping Identity | PingOne

IGEL OS Base System 244 / 647



• VMware Workspace ONE Access

Identity Provider Is Set to "Microsoft Entra ID"

Microsoft Entra ID

The value you have obtained as **Directory (tenant) ID** in the Microsoft Entra ID Portal.

Application (client) ID

The value you have obtained as **Application (client) ID** in the Microsoft Entra ID Portal.

Client secret

The client secret that was created in the Microsoft Entra ID Portal.

Identity Provider Is Set to "Okta"

Okta URL

The URL of the Okta identity provider.

Client ID

The client ID that was created in Okta.

Client secret

This is a value created by the identity provider. The value can be copied from the Identity Provider Admin Console.

Identity Provider Is Set to "OpenID Connect"

This option can be used for various identity providers that support OpenID Connect.

Issuer URL

The URL at the identity provider's site where the OpenID configuration document for your application can be found. This is the part of the path that precedes /.well-known/openid-configuration

Client ID

The client ID that is registered in your identity provider.

Client secret

The client secret that has been created by your identity provider.

IGEL OS Base System 245 / 647



Identity Provider Is Set to "Ping Identity | PingOne"

PingOne issuer URL

The URL at the Ping Identity / PingOne site where the OpenID configuration document for your application can be found. This is the part of the path that precedes /.well-known/openid-configuration

Client ID

The client ID that is registered in Ping Identity / PingOne for your application.

Client secret

The client secret that has been created in Ping Identity / PingOne for your application.

Identity Provider Is Set to "VMware Workspace ONE Access"

Workspace ONE Access issuer URL

The URL at the Workspace ONE Access site where the OpenID configuration document for your client can be found. This is the part of the path that precedes /.well-known/openid-configuration

Client ID

The client ID that is registered in Workspace ONE Access for your client.

Client secret

The client secret that has been created in Workspace ONE Access for your client.

Federated Identity Across IdPs

A federation can be set up between IdPs. For example, if Okta and Microsoft Entra ID are federated, Okta offers access/authentication against Microsoft Entra ID and vice versa. In the case of federated IdPs, the login screen contains a host that differs from the primary IdP. As IGEL OS only allows the primary IdP by default (e.g. "login.microsoftonline.com"), you must explicitly allow any further hosts.

List of allowed hosts for redirection

Hostnames that will be allowed by IGEL OS

Format:

- Only the hostnames (no protocol specification, like "https://")
- Several entries are separated by semicolons ";"

Example: "login.microsoftonline.com"

IGEL OS Base System 246 / 647



Scopes for OpenID Connect

You can define a list of scopes to which the client will request access. In addition to the standard scopes of OpenID Connect, custom scopes can be defined.

OpenID Connect scope

List of OpenID Connect scopes to which the client will request access

Format:

- Space separated list
- US ASCII only, no special characters or spaces within one scope

Example: "openid profile email custom_scope"

Automatic Desktop Login

As an alternative to the interactive desktop login, predefined user credentials can automatically be provided to the IdP on startup. The credentials are stored securely on the endpoint device.



Please be aware that after the automatic desktop login, a fully unlocked desktop session will run on your endpoint device. This feature should only be used for use cases where no interactive login is possible. It is good practice to restrict this user's access to only the relevant components and data that are necessary for the specific use case.

Please also note that Multi-Factor Authentication (MFA) is not possible when automatic login is enabled.

Automatic login is available for the following IdPs:

- Okta
- Microsoft Entra ID (formerly known as Microsoft Azure AD)
- Ping Identity | PingOne
- VMware Workspace ONE Access

Automatically perform login

✓ After startup, the endpoint device performs the login automatically using the **Username for autologin** and the **Password for autologin**.

Username for autologin

The name of a user known to the IdP used.

Password for autologin

The password of the user provided in **Username for autologin**.

IGEL OS Base System 247 / 647




Local User Login in IGEL OS 12

This article shows how to configure the local login authentication in IGEL OS.

f several login methods are enabled, the login method can be selected on the login screen.

Menu path: Security > Logon > Local User



Login with local user password

✓ Upon the start of the device, a login screen is shown and authentication with a local user password is required. The password specified under **Password** is deployed to log in.

☐ No authentication is required upon device startup. (Default)

Password

The password deployed to log in. This password is also required for unlocking the screen if the **Require password to unlock (screenlock)** option is enabled under **User Interface > Screenlock / Screensaver > Options**. For more information, see Options (see page 58).

IGEL OS Base System 248 / 647




f the login method is configured and the **Allow system logoff** option is enabled under **System > Power Options > Shutdown**, the user can log off the device through the shutdown menu. For information on how to access the shutdown menu, see Commands Session in IGEL OS 12 (see page 126) . For information on how to configure the shutdown menu, see Shutdown Settings in IGEL OS 12 (see page 300).

249 / 647 IGEL OS Base System




Guest - Passwordless Access to IGEL OS 12

This article shows how to configure a passwordless guest user with limited access to applications in IGEL OS.



Menu path: Security > Logon > Guest



Login as guest

IGEL OS Base System 250 / 647



✓ Pre-configured sessions can be accessed	I without a password through the guest user.
---	--

☐ The guest user is disabled. (Default)

Configuring Access for the Guest User

Each session can be made available for the normal user, the guest user, or both through the Registry parameters:

- sessions.<instance>.login_method
- app.<app-name>.sessions.<instance>.login_method

By default, all the sessions are available for the normal user only.

→ To configure access for passwordless guest login, choose applications which should be available in a guest session by setting the above parameters to **Guest** or **All**.



On command-line use nodelist sessions to get a currently defined list of sessions.

IGEL OS Base System 251 / 647




UMS as Identity Broker with IGEL OS 12

You can use the IGEL Universal Management Suite (UMS) as identity broker for IGEL OS 12 devices. With this configuration, the user can log in to the IGEL OS device using the company Active Directory (AD) credentials even if they are outside of the company network. The device then reaches out to the UMS and authenticates through the UMS itself.

For details on how to configure the UMS as Identity Broker, see How to Configure IGEL UMS As Identity Broker³³.

- The user can change the AD password from the IGEL OS 12 device, as described in Change Password in IGEL OS 12 (see page 262).
- This authentication method can also be used for SSO, for example, in an IGEL Remote Desktop session. For details, see Configuration of IGEL Remote Desktop on IGEL OS³⁴.

Menu path: Security > Logon > UMS as Identity Browser



Login with UMS as Identity Broker

- ✓ Users can authenticate through AD credentials on the IGEL OS device.
- Users cannot authenticate. (Default)
- Once the UMS is configured as identity broker, the user of the OS device can change the AD password as described in Change Password in IGEL OS 12 (see page 262).

IGEL OS Base System 252 / 647

^{33.} https://kb.igel.com/en/universal-management-suite/12.07.100/how-to-configure-igel-ums-as-identity-broker

^{34.} https://kb.igel.com/en/igel-apps/current/configuration-of-igel-remote-desktop-on-igel-os



Skip UMS as Identity Broker if UMS server is unavailable

~	When the UMS server is not available, the user can log in via Active Directory/Kerberos. In order to
	do this, logging in via Active Directory/Kerberos must be configured; further information can be
	found under Active Directory/Kerberos - Enable Login in IGEL OS 12 (see page 242).
	The authentication is not skipped. (Default)

Remember last user name

	No pre-populated user name is offered in the login dialog. (Default)
	to provide the password to log in.
1	The login dialog will be pre-populated with the last user name that logged in. The user only needs

Automatically perform login

~	After boot, the device automatically logs in with the credentials defined under Username for
	autologin and Password for autologin.
	The login is not performed automatically; a login dialog is displayed. (Default)

Username for autologin

The username that is used for automatic login.

Password for autologin

The password that is used for automatic login.


IGEL OS Base System 253 / 647



Active Directory/Kerberos

This article shows how to configure the options for Active Directory with Kerberos in IGEL OS.

Menu path: Security > Active Directory/Kerberos



Enable

✓ The Kerberos basic configuration will be carried out.

☐ The Kerberos basic configuration will not be carried out. (Default)

Default domain (fully qualified domain name)

IGEL OS Base System 254 / 647



This value must match the Windows domain on which the logon is to take place. The value must be entered in upper case letters. e.g. EXAMPLE.COM.

DNS lookup for domain controller

V	I In order to find the Key Distribution Centers (KDCs, domain controllers) and other servers for a realm, i	if they are
no	ot explicitly indicated, DNS SRV records are used. (Default)	

☐ The KDCs entered under **Security > Active Directory/Kerberos > Domain 1** ... **Domain 4** will be used.

DNS lookup for domain

- ✓ In order to determine the Kerberos realm of a host, DNS TXT records are used. (Default)
- ☐ The details under **Setup > Security > Active Directory/Kerberos > Domain Realm Mapping** are used.

Obtain Addressless Tickets

✓ The first Kerberos ticket is addressless. This may be necessary if the client is located behind an Network Address Translation (NAT) device. (Default)

- Domain Configuration for Active Directory/Kerberos in IGEL OS 12 (see page 256)
- Domain Realm Mapping in IGEL OS 12 (see page 258)


IGEL OS Base System 255 / 647



Domain Configuration for Active Directory/Kerberos in IGEL OS 12

This article shows how to configure domains for the Active Directory/Kerberos configuration in IGEL OS. Up to four domains can be configured.

Menu path: Security > Active Directory/Kerberos > Domain [1-4]



Fully qualified domain name

Name of the domain

Domain Controller List

IGEL OS Base System 256 / 647



To manage the list of domain controllers:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

To configure a domain, proceed as follows:

- 1. Under **Fully qualified domain name**, give the name of the domain (Kerberos realm).
- 2. Click to create a new entry.
- 3. Under **Domain Controller**, give the name or IP address of the domain controller (Kerberos Key Distribution Center). A port number can be added to the host name; the port name must be preceded by a colon.
- 4. Click Confirm.

The domain controller will be added to the **Domain Controller List**.


IGEL OS Base System 257 / 647



Domain Realm Mapping in IGEL OS 12

With domain realm assignment, a host name is translated into the corresponding Kerberos realm name. This article shows how to configure domain realm mapping in IGEL OS.

Menu path: Security > Active Directory/Kerberos > Domain Realm Mapping



Use default DNS domain - Active Directory domain mapping

✓ The DNS name and Active Directory domain name match. (Default)

☐ DNS name and Active Directory domain name assignments must be set up.

IGEL OS Base System 258 / 647



Domain Realm Mapping

To manage the list of realm mappings:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

To set up a DNS name to Active Directory domain name assignment proceed as follows:

- 1. Click to create a new entry.
 The Add dialog is displayed.
- 2. Under **DNS host or domain name**, enter the lower case FQDN name of a host or a domain that is to be assigned to an Active Directory domain name. Example: .example.com
- 3. Under **Active Directory domain name**, enter the Active Directory domain name that is to be assigned to the host name.
- 4. Click **Confirm**.

The data entered will be added to the **Domain Realm Mapping** list.

IGEL OS Base System 259 / 647




Smartcard Services in IGEL OS 12

Smartcard services need to be configured in order to use smartcard readers. This article shows the settings options of smartcard services in IGEL OS.



You will find a list of supported smartcard readers in the https://www.igel.com/ready/showcase-categories/security/.

Menu path: Security > Smartcard > Services



Activate PC/SC daemon

IGEL OS Base System 260 / 647



The PC/SC daemon enables the smartcard reader to connect to the device, so that the smartcard is available to an application. This can be a server-side application where data is forwarded via an RDP or ICA connection or a local application, e.g. the browser.

✓ The PC/SC service is enabled. The card reader is available for applications. (Default)

 $\hfill\square$ The PC/SC service is disabled. The card reader is not available.

PC/SC devices

List of smartcard readers currently connected to the device. Internal smartcard readers and a variety of USB smartcard readers are supported.

Refresh device list

Click the button to refresh the list of available PS/SC devices.


IGEL OS Base System 261 / 647



Change Password in IGEL OS 12

This article shows how to set up and use the Change Password function in IGEL OS.

Menu path: Security > Change Password



With this function, the user can change the password or PIN for the login method he used for the last login, provided one of the following login methods was used:

- Active Directory with username and password
- Active Directory with third-party smartcard
- Local user password
- Active Directory with UMS as identity broker

The starting methods parameters are described under Starting Methods for Apps (see page 644).


if autostart is enabled in the starting methods, the **Change Password** function is presented after login.

When the AD/Kerberos password is about to expire, a dialog is presented after login to inform the user about the required password change. When the user clicks the password change button in this dialog, the **Change Password** function starts automatically.

If the password is already expired when the user tries to log in, the user is required to change the password in the login dialog. After entering the new password, the password gets changed and the user is logged in.

IGEL OS Base System 262 / 647






Using Change Password

To change your password for your current login method, proceed as follows:

1. Start the **Change Password** function in one of the configured ways, for example, through a desktop icon, or through the start menu.

IGEL OS Base System 263 / 647






2. Enter the old and new password or PIN in the dialog. The dialog differs according to the login method that is currently used.

IGEL OS Base System 264 / 647



3. Click **OK**.

If the password change is successful, a confirmation dialog is shown.




IGEL OS Base System 265 / 647



Update

This article shows how to enable local app installation in IGEL OS. For more information on local app installation, see (en) Installing IGEL OS Apps Locally on the Device. For more information on app updates, see Update - App Update Settings in IGEL OS 12 (see page 349).

Menu path: Security > Update



Permit local app installation

✓ Enables the local app portal and the installation of apps by the user. (Default)

IGEL OS Base System 266 / 647




Certificates Enrolled via the UMS as CA Proxy

With the CA Proxy feature, you can use the IGEL Universal Management Suite (UMS) to enroll endpoint device certificates from an external PKI via the EST protocol.

When your UMS is configured as a CA proxy, you can provide the data for the desired certificate here. For details, see UMS as a Certificate Authority (CA) Proxy³⁵.

Menu path: Security > Certificates



IGEL OS Base System 267 / 647

^{35.} https://kb.igel.com/en/universal-management-suite/current/ums-as-a-certificate-authority-ca-proxy



System Configuration in IGEL OS 12

In this chapter, you find information on system configuration in IGEL OS.

- Time and Date in IGEL OS 12 (see page 269)
- Remote Management in IGEL OS 12 (see page 272)
- Remote Access in IGEL OS 12 (see page 279)
- Logging in IGEL OS 12 (see page 288)
- Power Options in IGEL OS 12 (see page 292)
- System Customization in IGEL OS 12 (see page 303)
- Update App Update Settings in IGEL OS 12 (see page 349)
- Registry in IGEL OS 12 (see page 353)
- Notification User Notifications in IGEL OS 12 (see page 356)


IGEL OS Base System 268 / 647



Time and Date in IGEL OS 12

This article shows the time and date settings options in IGEL OS.

Menu path: System > Time and Date



Timezone


Sets the timezone the device is located in.

Timezone systray settings

✓ You can set the timezone by clicking on the taskbar clock and selecting from the **Timezone** dropdown menu. The taskbar clock can be activated under **User Interface > Desktop > Taskbar Items**. (Default)

IGEL OS Base System 269 / 647





☐ The **Timezone** dropdown menu is not available through the taskbar clock.

Use NTP time server

- ✓ The system clock is set via Network Time Protocol (NTP) during boot.
- ☐ The system clock is not set via NTP. (Default)

NTP time server

IP address or name of the NTP time server. If you would like to enter a list of NTP time servers for redundancy purposes, separate the names / IP addresses by spaces.

Manual Date and Time Configuration

Carries over the time and date and sets the hardware clock. Once the date and time is set, click **Change date and time** to save the change.



You can set the date by selecting from the calendar, or using the arrow keys to adjust the date. You can set the time by typing it in, or using the arrow keys to adjust the time.

HW clock timezone

Sets the hardware clock. Possible options:

• Auto (default)

IGEL OS Base System 270 / 647





iGEL OS and Windows have different default time settings, IGEL OS using UTC and Windows using local time. When using IGEL UD Pocket with Windows, this would lead to Windows interpreting the real time clock as set to local time and show the wrong time. To avoid this, the **Auto** setting looks for Windows partitions and, if present, assume that Windows is installed and the real time clock is automatically set to local time.

- UTC
- Localtime


271 / 647 IGEL OS Base System



Remote Management in IGEL OS 12

In IGEL OS, endpoint devices are managed using the Universal Management Suite (UMS). This article shows the settings related to the remote management, for example, the configuration of UMS servers and user information dialogs on UMS updates.

Menu path: System > Remote Management



Universal Management Suite

If the device is registered on a **UMS Server**, its IP address / hostname and **Port number** will be shown in the list.



The list can contain more than one UMS instance. If the device cannot contact a UMS Server under the hostname <code>igelrmserver</code>, and the DHCP option 244 is not set, the device will go through the entries in the list until it can contact a UMS Server successfully.

To manage the list of servers:

- Click to create a new entry.
- Click to remove the selected entry.
- Click o edit the selected entry.
- Click to copy the selected entry.

IGEL OS Base System 272 / 647



Clicking brings up the **Add** dialogue, where you can define the following settings:

UMS server

Name or IP of the UMS Server

Port number

Port number of the UMS Server (Default: 8443)

Connector type

The value is automatically defined by the UMS. You can use the **Ranking of connectors** option under **System > Remote Management > Options** to define which connection the device should try to establish first based on the connector types.

Possible values:

- undefined (default)
- ums

Direct connection to the Universal Management Suite.

icg

Connection to the IGEL Cloud Gateway (ICG).

Display "Apply changes" dialog on boot

If new settings were made in the UMS, the device may receive them during the boot procedure.

During the boot procedure, the **Apply changes** dialog is displayed and the user can decide whether the new settings are applied immediately. If the user does not allow them to be applied immediately, they will automatically be applied next time the system is restarted. (Default)

☐ The **Apply changes** dialog will not be shown. The new settings will be applied or ignored depending on the setting under **Default action on boot**.

Timeout

Number of seconds for which the **Apply changes** dialog is shown. If the timeout is exceeded, the received settings will automatically be applied. (Default: 20)

Setting the value to 0 disables the timeout, and the dialog is shown until the user clicks a button.

Default action on boot

Configure the action that is to be performed if the dialog exceeds the timeout or if the timeout is disabled. Possible values:


- **Apply changed configuration immediately**: New settings will take effect immediately, and programs that are running may be restarted. (Default)
- **Ignore changed configuration**: New settings will not be applied. The new configuration will be saved on the device, and applied the next time a new configuration is applied.

Prompt user on UMS actions

The user is informed through a message window when UMS actions are performed on the device. (Default)

IGEL OS Base System 273 / 647





 \Box The user is not informed when UMS actions are performed on the device.

Timeout

Number of seconds for which the UMS actions information dialog is shown. If the timeout is exceeded, the received settings will automatically be applied. (Default: 20)

Setting the value to 0 disables the timeout, and the dialog is shown until the user clicks on a button.

Structure tag

The structure tag is used to sort the device into a directory in accordance with the UMS directory rules. For details see (12.06.100-en) Using Structure Tags with IGEL OS Devices.

instead of setting the structure tag using this option, the preferable way to manually set the structure tag in the OS12 is using the command tool: /sbin/rmagent-set-structure-tag -t <TAG> Instead of checking the structure tag here, use the command tool /sbin/rmagent-getstructure-tag for retrieving of the current value of the structure tag in the OS12. Because if the structure tag is set via Setup Assistant or via DHCP tag, the value in the Setup will be empty, but the command will always retrieve the value.



The command line tool /sbin/rmagent-register provides the possibility to set the structure tag using the option -u <TAG> . This tool is used for some scenarios of automatic register with custom scripts.

Log message severity

Select the severity level above which device errors are to be transferred to the UMS. Messages with a lower severity are suppressed.

Possible options:

- off (Default)
- error
- warn
- info
- debug

IGEL OS Base System 274 / 647



Show UMS connection status tray icon on desktop

✓ The icon is displayed in the taskbar, showing the status of the UMS connection. Clicking the icon displays information about the connected UMS server.


IGEL OS Base System 275 / 647



Options of Remote Management in IGEL OS 12

This article shows the configuration of remote management options in IGEL OS 12.

Menu path: System > Remote Management > Options



Log login and logoff events

- Details of logon and logoff events of the following logon types are sent to the UMS:
 - Active Directory/Kerberos
 - Single Sign-On
 - Local User
 - Guest User
 - UMS Identity Broker
- Events are only logged if the **Enable user logon history** parameter is enabled in the UMS Console, under **UMS Administration > Global Configuration > Misc Settings.** For more information, see (12.05.100-en) Misc Settings in IGEL UMS.
- Login and logoff events are not sent to the UMS. (Default)
- The logged events can be found both in the UMS Console and the UMS Web App. For more information, see (12.05.100-en) View Device Information in the IGEL UMS.

Delay session start at boot time in order to apply new UMS settings

IGEL OS Base System 276 / 647



If new settings were made in the UMS, the device may receive them during the boot procedure. After the device connects to the UMS at boot time, new settings might be transferred to the device.

~	The start of the sessions will be delayed until the settings have been transferred or the time limit
	defined under Timeout has been exceeded.

The start of the sessions is not delayed. (Default)

Timeout

Delay in seconds after which the sessions get started during the boot procedure. (Default: 10)

Ranking of connectors

Defines the order in which the device connects to the configured device connectors based on their connector types. Connector types are listed in **System > Remote Management > Universal Management Suite**. Possible options:

• no preference (default)

The device connects randomly to any configured device connector, regardless of the connector type.

prefer UMS

The device will try to connect to the UMS Servers first (that is, the connections listed with the **ums** connector type are contacted first).

The device will only try to connect to an ICG if UMS Servers are not reachable or configured.

prefer ICG

The device will try to connect to an ICG (that is, the connections listed with the **icg** connector type are contacted first).

The device will only try to connect to a UMS server if no ICG is reachable or configured.



As the default behavior, the igelrmserver address is always used as the preferred server to connect to the UMS if the address could be resolved to an IP address (either with DNS or DHCP). That means that the **prefer ICG** switch will be ignored if there is a DNS entry for 'igelrmserver' in the current network, because the igelrmserver always has the highest priority. In this case, you need to enable **Use "igelrmserver" as fallback** to force ICG preference.

Use "igelrmserver" as fallback

- To connect to the UMS, the device will first try to connect through all the other UMS/ICG addresses, and it will only try to connect through the address of the igeIrmserver as a fallback.
- To connect to the UMS, the device will first try the address of the igelrmserver before all other available UMS/ICG addresses. (Default)

Enable IGEL Asset Inventory Tracking (AIT)



IGEL Asset Inventory Tracking (AIT) has the following requirements:

• Universal Management Suite (UMS) 12.08.100 or later

IGEL OS Base System 277 / 647



Valid Enterprise license

- The endpoint device sends data about all connected USB and Bluetooth devices to the UMS. The data is sent if one of the following applies:
 - The device boots
 - A periphery device is plugged in/off
 - The UMS triggers a refresh of the asset information
- No data is sent to the UMS.

AIT events delay (secs)

The time delay in seconds after which an event, such as connecting a headset, is communicated to the UMS. This can be used to accumulate several events in one message to the UMS, which saves resources: All events that occur after an event has started the delay timer and before the delay timer has expired are sent as one message together with the first event. If the delay is set to 0, each event is sent immediately in a single message to the UMS:

Possible values: 0 ... 180

IGEL OS Base System 278 / 647



Remote Access in IGEL OS 12

To support remote management, the following remote access options can be configured for the device.

- SSH Access in IGEL OS 12 (see page 280)
- Shadow Settings in IGEL OS 12 (see page 283)
- Secure Terminal in IGEL OS 12 (see page 286)


IGEL OS Base System 279 / 647



SSH Access in IGEL OS 12

This article shows how to configure Secure Shell (SSH) access to the device in IGEL OS.

Menu path: System > Remote Access > SSH Access



Enable

- ✓ The SSH service is enabled.
- ☐ The SSH service is disabled. (Default)

If SSH access is enabled, you can configure the following:

Permit empty passwords

- ✓ Logging on without a password is allowed.
- ☐ Logging on without a password is not allowed. (Default)

Permit administrator logon

- ✓ Logging on as an administrator is allowed.
- ☐ Logging on as an administrator is not allowed. (Default)

Port number

Port number for SSH. (Default: 22)

User Access

IGEL OS Base System 280 / 647



List of configured users.



Unlike **root** and **user**, the **ruser** is not intended for real SSH sessions, but only for starting X applications that are listed below under Applications Access for Remote User "ruser".

To manage the list:

User name

Permitted user

Hostname

Name of the host from which SSH access takes place (example: xterm.igel.de)

- Deny
- ✓ Access is denied.
- ☐ Access is allowed. (Default)



• For ruser a password has to be assigned under **Security > Password**. The names root and user work also without passwords. For more information, see Password and User Types in IGEL OS 12 (see page 233).

Permit X11 forwarding

- ✓ X11 forwarding is enabled.
- ☐ X11 forwarding is disabled. (Default)

Applications Access for Remote User "ruser"

The ruser is not intended for real SSH sessions, but only for starting X applications configured below. By default these are localshell and /config/sessions/setup0.



if you try to log on to the device as **ruser** via SSH, then you will never be able to connect. The connection will be closed immediately without anything happening. In this case you must add the parameter "-X" and the program to be started in the session call, like in this example:

ssh -X ruser@192.168.10.203 localshell

To manage the list:

• Click • to create a new entry.

IGEL OS Base System 281 / 647



- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking brings up the **Add** dialogue, where you can define the following settings:

• Command line

Command that is allowed or prohibited for the remote user

• Enable application

- ✓ The application given under **Command line** may be executed by the remote user. (Default)
- \Box The application given under **Command line** may not be executed by the remote user.


IGEL OS Base System 282 / 647



Shadow Settings in IGEL OS 12

IGEL OS offers the ability to observe the endpoint device via shadowing through the IGEL Virtual Network Computing (VNC) Viewer in the Universal Management Suite (UMS) or another VNC client (e.g. TightVNC), see Universal Management Suite > UMS Reference Manual > Devices - Managing Devices in the IGEL UMS > Shadowing - Observe IGEL OS Desktop via VNC. The shadowing of IGEL OS 12 devices through the UMS is always via Unified Protocol, i.e. communication is always encrypted. This article shows the settings for configuring the VNC access to your devices.

Menu path: System > Remote Access > Shadow



Allow remote shadowing

✓ Desktop content can be accessed by remote computers with VNC software.

☐ VNC shadowing is not allowed. (Default)

If **Allow remote shadowing** is activated, you can change the following settings:

Deny shadowing via external VNC tool

IGEL OS Base System 283 / 647



✓ The device can only be shadowed via the UMS. Shadowing of the device by an external VNC viewer is not
possible. For details, see Universal Management Suite > UMS Reference Manual > Devices - Managing Devices in the
IGEL UMS > Shadowing - Observe IGEL OS Desktop via VNC > External VNC Viewer. (Default)

☐ The device can be shadowed by an external VNC viewer, not only the UMS.

Use password


- ✓ The remote user is authenticated with a password before shadowing.
- ☐ The remote user is not authenticated for shadowing. (Default)

Password

Password for the VNC connection

Prompt user to allow remote session

✓ The local user will be asked for permission before shadowing. (Default)





In a number of countries, for example, Germany, unannounced shadowing is prohibited by law. Do not disable this option if you are in one of these countries!

Allow user to disconnect remote shadowing

A **Disconnect** button with which the user can terminate the VNC connection is shown. (Default)

Allow input from remote

✓ The remote user can make entries using the keyboard and mouse as if they were the local user. (Default)

Scale frame buffer

- ✓ The screen content of the shadowed device is reduced or enlarged by the **Scale factor** before being transferred.
- \Box The screen content is transferred in the original size. (Default)

Scale factor

IGEL OS Base System 284 / 647



Factor by which the screen content of the shadowed device is enlarged or reduced. Values under 1 reduce the content. (Default: 1.0)

Position of the indicator

Defines the position of the popup notification about being shadowed. Possible options:

- Top right
- Top left
- Bottom left
- **Bottom right** (Default)



Further parameters for the VNC server on the device are accessible under **System > Registry** > network.vncserver.


IGEL OS Base System 285 / 647



Secure Terminal in IGEL OS 12

This article shows how to enable or disable the secure terminal connection on the endpoint device in IGEL OS.

Menu path: System > Remote Access > Secure Terminal



Secure Terminal

✓ Secure terminal connection is enabled between the device and the Universal Management Suite (UMS).

 \square Secure terminal connection is disabled between the device and the UMS. (Default)

For information on how to use the secure terminal from the UMS, see *Universal Management Suite > UMS Reference Manual > Devices - Managing Devices in the IGEL UMS > Accessing Devices via Secure Terminal (Secure Shell) in the IGEL UMS.*

IGEL OS Base System 286 / 647



- You can enable secure terminal connection for all registered devices by activating the **Enable secure** terminal globally option under UMS Console > UMS Administration > Global Configuration > Remote Access.
- For a list of IGEL specific commands collected by the IGEL Community, see Cheatsheet-IGELCommunity³⁶.

IGEL OS Base System 287 / 647

^{36.} https://igel-community.github.io/IGEL-Docs-v02/Docs/Cheatsheet-IGELCommunity/




Logging in IGEL OS 12

This article shows the options to configure local and remote logging for the device in IGEL OS.

0

You can use the System Log Viewer to access system logs. For more information, see System Log Viewer in IGEL OS 12 (see page 34) .

Menu path: System > Logging



Local logging

✓ The log messages are stored locally in /var/log. The format is human-readable. Log rotation is applied.

 $\hfill\square$ The log messages are not stored locally.

IGEL OS Base System 288 / 647



Persistent log partition

This parameter is effective if **Local logging** is activated.

✓ The log messages are stored in a persistent partition on the device. This partition is encrypted.

☐ The log messages are stored in temporary files that are deleted on reboot.

Partition size in MB

Size of the persistent log partition

Remote mode

Possible options:

- **Server**: The device receives log messages from a remote client.
- **Client**: The device sends its log messages to a remote server.
- Off: The device does not send or receive any log messages. (Default)

Remote Mode Switched to Server

You can configure the device to act as a syslog server. Other clients can send log files to this server; you can create a separate server configuration for each client.

Template for log file storage

Pattern from which the file path for storing the received log messages is created. For example, in /var/log/%HOSTNAME%/messages . %HOSTNAME% is the name of the sender which is configured under **Name**.

To manage the **Server** list:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking • brings up the **Add** dialogue, where you can define the following settings:

Local port

Port on which the local server listens for log messages

Transport protocol

Protocol to be used for the transmission of log messages Possible options:

IGEL OS Base System 289 / 647



- TCP (Default)
- UDP

• Name

Hostname of the sender (optional). This is useful for filtering the log messages based on the clients that have sent them.

Local address

Optional parameter; on multihomed machines (i. e. machines with multiple addresses), this specifies to which local address rsyslog is bound. If no address is specified it defaults to 0.0.0.0, so that rsyslog listens on every network interface. For more information, see the official documentation at https://www.rsyslog.com/doc/v8-stable/configuration/modules/imtcp.html.

Remote Mode Switched to Client

You can configure one or more clients, e.g. one server for kernel messages and another server for authentication messages.

To manage the **Clients** list:

- Click to create a new entry.
- Click to remove the selected entry.
- Click / to edit the selected entry.
- Click to copy the selected entry.

Clicking • brings up the **Add** dialogue, where you can define the following settings:

Remote address

IP address or hostname of the remote server

Remote port

Port on which the server listens for log messages

Transport protocol

Protocol to be used for the transmission of log messages Possible options:

- TCP (Default)
- UDP
- Syslog facility

Type of program for which log messages are created. (Default: Any)

• Syslog level

Severity level of the event. (Default: Any)

IGEL OS Base System 290 / 647



• Syslog style template

Format in which the messages are sent Possible options:

- RSYSLOG_TraditionalForwardFormat (Default)
- RSYSLOG_ForwardFormat
- RSYSLOG_SyslogProtocol23Format
- RSYSLOG_StdJSONFmt
- TLS enabled

✓ TLS encryption for the transmiss	sion of log messages is enabled
------------------------------------	---------------------------------

☐ Transmitted log messages are not encrypted. (Default)

• CA certificate

Path to the local CA root certificate file in PEM format which is used to verify the authenticity of the X.509 certificate of your log collector and analyzer. If the UMS is used to transfer the certificate file to devices, the same path and file name as in the UMS must be entered. Example: /wfs/ca-certs/ca.pem For more information, see (en) Logging and Log Evaluation.

IGEL OS Base System 291 / 647



Power Options in IGEL OS 12

The following power option configurations are available in IGEL OS.

- System Power Options in IGEL OS 12 (see page 293)
- Battery Settings in IGEL OS 12 (see page 296)
- Display Power Management in IGEL OS 12 (see page 298)
- Shutdown Settings in IGEL OS 12 (see page 300)

IGEL OS Base System 292 / 647



System Power Options in IGEL OS 12


This article shows how to configure settings for energy saving on your IGEL OS device. You can configure the behavior after a time of inactivity and the CPU power plan.



Display of Energy Star Logo on Selected HP Endpoint Devices

With selected Hewlett-Packard (HP) endpoint devices, the Energy Star certification mark is displayed on this Setup page.

Menu path: System > Power Options > System



System suspend/shutdown on inactivity

Specify how long the user can be inactive before the system switches to standby mode or shuts down, depending on the **System action on inactivity** setting.

- Possible values:
 - Default: The same as Never except for factory preloads, where Default is "After 20 mins".
 (Default)
 - **Never**: The system does not switch to standby mode or shut down on inactivity.
 - After 1 minute
 - ...
 - After 24 hours



A setting of 20 minutes or less is recommended. Otherwise, this may result in increased power consumption and shorter battery runtime. A corresponding message is then displayed.

IGEL OS Base System 293 / 647



System action on inactivity

Possible options:

- Suspend: The system is set to standby mode after the timeout defined under System suspend/ shutdown on inactivity. (Default)
- Shutdown: The system is shut down after the timeout defined under System suspend/shutdown on inactivity.



🛕 Changing the default values for the settings described below may result in higher power consumption and shorter battery runtime.

Without dialog

 \checkmark The user is not asked if the system is to be set to standby mode.

☐ The dialog asking for user confirmation is shown. (Default)

Dialog timeout

Time in seconds, for which the dialog is to be displayed. (Default: 10 seconds)

Plugged In

CPU power plan for AC mode

The CPU power plan (CPU Governor) used in AC mode Possible options:

- High performance: Full performance with maximum processor speed. (Default)
- Balanced: Slower regulation of performance in a balanced manner according to the demands of
- Power saver: Lowest processor speed



i You can also use the battery tray app to set the CPU power plan for the current mode in use (AC or battery). For details, see Battery Settings in IGEL OS 12 (see page 296).

Lid close action while plugged in

The action that is performed when the lid of the device gets closed.

Possible options:

• Suspend: When the lid gets closed, the device goes into suspend mode and applications are closed. When the lid is opened again, the device starts, connections are restarted, and re-login is required. Applications have to be started manually. (Default)

IGEL OS Base System 294 / 647





The suspend action is only performed if there are no external displays connected and activated. When an external display is connected and activated, the internal display is turned off, and if the internal display was the primary display, a new primary display is assigned.

• Turn off display: When the lid gets closed, the internal display is turned off.

On Battery

CPU power plan for battery mode

The CPU power plan (CPU Governor) used in battery mode Possible options:

- **High performance**: Full performance with maximum processor speed
- Balanced: Regulation of performance in a balanced manner according to the demands of programs. (Default)
- Power saver: Lowest processor speed



You can also use the battery tray app to set the CPU power plan for the current mode in use (AC or battery). For details, see Battery Settings in IGEL OS 12 (see page 296).

Lid close action while not plugged in

The action that is performed when the lid of the device gets closed.

Possible options:

• Suspend: When the lid gets closed, the device goes into suspend mode and applications are closed. When the lid is opened again, the device starts, connections are restarted, and re-login is required. Applications have to be started manually. (Default)



The suspend action is only performed if there are no external displays connected and enabled. When an external display is connected and activated, the internal display is turned off, and if the internal display was the primary display, a new primary display is assigned.

• Turn off display: When the lid gets closed, the internal display is turned off.


IGEL OS Base System 295 / 647



Battery Settings in IGEL OS 12

This article shows battery settings options in IGEL OS.

Menu path: System > Power Options > Battery



Battery Notification

Critical battery level (percentage)

Percentage of remaining battery charge deemed critical. (Default: 5)

Critical battery action

Action to be taken in the event of a critical charge level Possible options:

- Do nothing
- Show warning (Default)
- Run command
- Run command in terminal

IGEL OS Base System 296 / 647



Critical command

Command that is executed when a critical charge level is reached. (Default: Shutdown)

Low battery level (percentage)

Percentage of remaining battery charge deemed low. (Default: 10)

Low battery action

Action to be taken in the event of a low charge level Possible options:

- Do nothing
- Show warning (Default)
- Run command
- Run command in terminal

Low command

Command that is executed when a low charge level is reached. (Default: Shutdown)

Battery Tray Icon

Show battery tray icon on desktop

The battery icon is shown in the taskbar. The icon is dynamic and represents the state of the battery charge. For example when the battery is charging:

Hover over the icon to see information on the charge. Clicking the icon displays the battery tray app. For more information on the battery tray app, see Tray Applications in IGEL OS 12 (see page 358). (Default)

IGEL OS Base System 297 / 647




Display Power Management in IGEL OS 12

This article shows how to configure energy-saving stages for the display in IGEL OS.

A

Changing the default settings may result in higher power consumption and shorter battery runtime.

Menu path: System > Power Options > Display > Power Management / Brightness Reduction



Power Management

Handle display power management

✓ The DPMS energy saving functions are enabled. (Default)



The display must support Display Power Management Signaling (DPMS).

On Battery / Plugged In

You can select time frames after which energy-saving modes get activated. The time frames are configured separately for **On Battery** and **Plugged In** use of the device. When **Never** is selected, the energy-saving mode is disabled.

The following energy-saving modes can be configured:

• Standby Time

After this time frame, the device goes to standby mode.

IGEL OS Base System 298 / 647



Suspend Time

After this time frame, the device goes to sleep mode.

• Off Time

After this time frame, the device turns off.



A Chronologically, Standby mode must occur before or simultaneously with Suspend mode, and Suspend mode must occur before or simultaneously with **Off** mode. Therefore, verify that the customized timeout values are greater than or equal to the timeout values of earlier modes: **Standby Time ≤ Suspend Time ≤** Off Time.

Inconsistent values will result in BadValue error.

Brightness Reduction

These settings are relevant for mobile devices resp. for devices with integrated display.

If a device is switched on but not used for some time, energy can be saved by brightness reduction. The values of the reduction are configured separately for **On Battery** and **Plugged In** use of the device.

On Battery / Plugged In

On inactivity reduce to

The percent value to which the brightness is reduced after a period of inactivity.

Reduce after

The period of inactivity after which brightness is reduced. You can set the period between 10-120 seconds. Setting the value to 9 deactivates the reduction.


IGEL OS Base System 299 / 647



Shutdown Settings in IGEL OS 12

This article shows the options to configure the behavior of shutdown menu in IGEL OS. The shutdown menu button can be displayed in the start menu and in the Application Launcher. For more information, see Start Menu in IGEL OS 12 (see page 122) . You can also configure the shutdown menu as a command session and configure various starting methods. For more information, see Commands Session in IGEL OS 12 (see page 126) .

Menu path: System > Power Options > Shutdown



By default, when the user clicks the shutdown button, an information dialog is displayed. The user can select from the enabled actions or cancel the procedure by closing the window by clicking X or by pressing [Esc].

IGEL OS Base System 300 / 647





Global Options

Allow system shutdown

- **✓** The user can shut down the device. The **Shutdown** button is shown in the info dialog. (Default)
- ☐ The user cannot shut down the device. The **Shutdown** button is not shown in the info dialog.

Allow system suspend

- ✓ The user can suspend the device. The **Suspend** button is shown in the info dialog. (Default)
- ☐ The user cannot suspend the device. The **Suspend** button is not shown in the info dialog.

Allow system reboot

- ✓ The user can reboot the device. The **Reboot** button is shown in the info dialog. (Default)
- ☐ The user cannot reboot the device. The **Reboot** button is not shown in the info dialog.

Allow system logoff

- ✓ The user can log off the device, if the user is logged in. The **Logoff** button is shown in the info dialog. (Default)
- ☐ The user cannot log off the device. The **Logoff** button is not shown in the info dialog.



To configure the option, at least one login method needs to be enabled under **Security > Logon**. For more information, see Logon Settings in IGEL OS 12 (see page 238).

Default action

The action that is carried out if the timeout defined under **Dialog timeout** expires. Possible options:

- Shutdown
- Suspend (Default)
- Reboot
- Logoff
- Cancel

IGEL OS Base System 301/647



Dialog timeout

Time (in seconds) after which the info dialog will close and the action specified under **Default action** will be carried out. If the value is set to 0, the dialog will be shown until the user selects one of the possible actions. (Default: 10)

Additional Parameters When Triggered via UMS



Known Issue

For OS version 12.2.0, the parameters of the Additional Parameters When Triggered via UMS are not effective. The parameters will be reworked in a future release.

Allow canceling of shutdown process

✓ The user can cancel the shutdown procedures initiated from the UMS by clicking the **Cancel** button in the info dialog. (Default)

 \Box The user cannot cancel the procedures.



For the manual cancellation to work, the following parameters need to be configured:

- Without dialog needs to be disabled.
- Prompt user on UMS actions under System > Remote Management needs to be enabled. For details, see Remote Management in IGEL OS 12 (see page 272).

Without dialog

✓ The info dialog is not shown. The shutdown procedures initiated from the UMS are carried out without notification.

☐ The info dialog is shown. (Default)

IGEL OS Base System 302 / 647



System Customization in IGEL OS 12

You can use the following configuration to customize your IGEL OS.

- Custom CronJob/Systemd Timer in IGEL OS 12 (see page 304)
- Custom Partition in IGEL OS 12 (see page 307)
- Custom Commands in IGEL OS 12 (see page 312)
- Custom Application in IGEL OS 12 (see page 327)
- Environment Variables in IGEL OS 12 (see page 329)
- Corporate Design Configure the User Interface in IGEL OS 12 (see page 335)


IGEL OS Base System 303 / 647



Custom CronJob/Systemd Timer in IGEL OS 12

You can set timers on your IGEL OS 12 device to execute commands or to install/update apps at defined dates and times. The dates and times are specified in systemd syntax.

Menu path: System > System Customization > Custom CronJob/Systemd timer




Configuring a Timed Custom Command

- 1. Click + to add a new timer.
- 2. Edit the data as follows and then click **Confirm**.
 - **Name job**: Display name for the timed command. It is recommended to use a name that speaks for itself.
 - **User**: User to run the command. The following users are available on IGEL OS 12:
 - root
 - **user**: A user with typical user permissions
 - Type: Select custom command action.
 - **Command**: Enter the command to execute.
 - Date and time for execution of job using systemd timer syntax: Specify the date and time at which the command is to be executed. For examples, see https:// www.freedesktop.org/software/systemd/man/latest/ systemd.time.html#Calendar%20Events
 - Delays the timer by a randomly selected value; default of 0: This parameter is useful when the command consumes many resources, e.g. network resources, and is executed by a great number of devices. Example: If you enter 10, the command will be executed somewhere between the specified time +1 seconds and the specified time +10 seconds.

IGEL OS Base System 304 / 647



• If hardware supports rtc wake and this option is enabled, the system will boot up to initiate the specified job / action: Please note that this feature is still experimental. The functionality depends strongly on the specific hardware and BIOS/UEFI.



Configuring a Timed Update

You can configure the timer to install or update apps on a given date and time. For this, **System > Update > Action after app assignment from UMS** must be set to **Nothing (additional step is needed to download and activate new app(s))**. For a description, see Update - App Update Settings in IGEL OS 12 (see page 349).


- 1. Click + to add a new timer.
- 2. Edit the data as follows and then click **Confirm**.
 - **Name job**: Name for the timed command. It is recommended to use a name that speaks for itself, e.g. "Update".
 - User: Select root.
 - Type: Select update action.
 - Date and time for execution of job using systemd timer syntax: Specify the date and time at which the command is to be executed. For examples, see https://

IGEL OS Base System 305 / 647



www.freedesktop.org/software/systemd/man/latest/systemd.time.html#Calendar%20Events

- **Delays the timer by a randomly selected value; default of 0**: This feature does not work with IGEL OS 12.7.0 or earlier.
- If hardware supports rtc wake and this option is enabled, the system will boot up to initiate the specified job / action



IGEL OS Base System 306 / 647



Custom Partition in IGEL OS 12

In IGEL OS, a custom data partition is available for use as required. A download/update function that loads data from a server and, where appropriate, updates them can be set up for this custom storage area.

Menu path: System > System Customization > Custom Partition



⚠ The IGEL Support Team offers support for the deployment of Custom Partitions. However, it is not possible to offer support for any third-party software that is installed on a Custom Partition.



If the device is reset to the default settings (factory reset), the custom partition and all data stored on it will be deleted.

- Partition Configuring Custom Partition in IGEL OS 12 (see page 308)
- Download Custom Partition in IGEL OS 12 (see page 310)


IGEL OS Base System 307 / 647



Partition - Configuring Custom Partition in IGEL OS 12

This article shows how to configure options to use a custom partition of your own in IGEL OS.

Menu path: System > System Customization > Custom Partition > Partition



Enable partition

✓ The use of custom partitions is enabled.

☐ Custom partitions cannot be used. (Default)

Size

IGEL OS Base System 308 / 647



Size of the partition in bytes. The number can be followed by a multiplicative ending, without a space in between. Example: "100K" stands for 100 Kibibytes, that is, 100 * 1024 bytes.

The following multiplicative endings are possible:

- k for Kilobytes
- K for Kibibytes (number * 1024)
- m for Megabytes
- M for Mebibytes (number * 1024 * 1024)
- g for Gigabytes
- G for Gibibytes (number * 1024 * 1024 * 1024)



• Sensible values are for example "100K" (for 100 KiB = 100 * 1024 bytes) or "100M" (for 100 MiB = 100 * 1024) * 1024 bytes). The size of the partition should be set to at least 100 KiB. However, no more than 300 MiB should be reserved for the customer-specific partition (based on the 1 GB standard CF used in IGEL Linux thin clients). This is because subsequent firmware updates may require more storage space than the current version.

Mount point

Path on which the partition is to be mounted. (Default: /custom)

Partitions Parameters

You can enter name value pairs which are passed on to the custom partition for further processing. To manage the list:

- Click to create a new entry.
- Click 🗍 to remove the selected entry.
- Click
 to edit the selected entry.
- Click 🔲 to copy the selected entry.

Clicking + brings up the **Add** dialogue, where you can define the following settings:

• Name

Name of the parameter

Value

Value of the parameter


IGEL OS Base System 309 / 647



Download Custom Partition in IGEL OS 12

This article shows how to set up data sources for the custom partitions in IGEL OS.

Menu path: System > System Customization > Custom Partition > Download



Partitions Data Sources

In order to load data onto the custom partition, at least one partition data source must be set up here.

To manage the list, proceed as follows:

- Click to create a new entry.
- Click to remove the selected entry.
- Click / to edit the selected entry.
- Click to copy the selected entry.

IGEL OS Base System 310 / 647



Clicking brings up the **Add** dialogue, where you can define the following settings:

• Automatic update

✓ The contents from this source will be updated automatically. ☐ The contents from this source will not be updated automatically. (Default)

URL of the web server

User name

User name for access to the web server

Password

Password for access to the web server. Click **Set password** to save the password. Click **Change password** to change the password.

• Initial action

Action which is performed after mounting the partition (program or script with absolute path). For example, a program downloaded to the partition can be launched.

Final action

Action which is performed before unmounting the partition (program or script with absolute path). For example, a program downloaded to the partition can be ended.

The transfer protocols are the same as the ones for updating the firmware, e.g. HTTP and HTTPS.

An INF file which in turn references a tar archive zipped using bzip2 must be referenced as the target. The structure of the INF file is as follows:

- [INFO], [PART] Header information
- file="test.tar.bz2" File name of the compressed tar archive
- version="1" Version number a higher version results in an update if Update automatically is enabled.

The files to be transferred must therefore be zipped in a tar archive which is then compressed using bzip2. This file is referenced in the INF file which is the target of the URL.

The tar archive can be created under Windows, e.g. with the open source program 7-Zip (www.7-zip.de³⁷).

This program also allows bzip2 compression. Under Linux, tar and bz2 files can be created using onboard resources.

The procedure makes it possible to replace the file(s) on the server with a new version which the thin client loads the next time it is booted. The Version parameter in the INF file must be increased for this purpose.

37. http://www.7-zip.de/

311 / 647 **IGEL OS Base System**



Custom Commands in IGEL OS 12

Custom commands are executed at specific points of the system startup process.

You can use environment variables in your custom commands. For more information on environment variables, see Environment Variables (see page 329).

The timeout in seconds for custom commands can be configured in **System > Registry > userinterface > rccustom > timeout** (Registry key: **userinterface.rccustom.timeout**). The default is 10.



The content of custom scripts used in the custom command fields cannot be supported by IGEL. Therefore, you may be requested to remove custom scripts as part of the troubleshooting/support process.



Custom commands are executed as root.

You can define custom commands for the following startup processes:

- Base Custom Commands in IGEL OS 12 (see page 313)
- Desktop (see page 315)
- Network Custom Commands in IGEL OS 12 (see page 317)
- Reconfiguration Custom Commands in IGEL OS 12 (see page 319)
- Post-session Custom Commands in IGEL OS 12 (see page 320)


IGEL OS Base System 312 / 647



Base Custom Commands in IGEL OS 12

The commands defined here are executed at the specific execution times during the boot process.

Menu path: System > System Customization > Custom Commands > Base



You can define commands for the following execution times:

Initialization

The command is executed during boot, at the beginning of initialization. At this point:

- Not all drivers are loaded, not all devices are available
- Network scripts are not launched, network is not available
- Partitions are available, except for firefox profile, scim data, ncp data, custom partition

IGEL OS Base System 313 / 647



Before session configuration

The command is executed during boot, before the session configuration. At this point:

- Not all drivers are loaded, not all devices are available
- Network scripts are not launched, network is not available
- Partitions are available, except for firefox profile, scim data, ncp data, custom partition
- Sessions are not configured

After session configuration

The command is executed during boot, after the session configuration. At this point:

- All drivers are loaded, all devices are available
- Network is available
- Partitions are available, except for *custom partition*
- System daemons are not launched (CUPS, ThinPrint etc.)
- Sessions are configured
- UMS settings are retrieved but not yet effective

Final initialization command

The command is executed during boot, after the initialization. At this point:

- All partitions are available
- All system daemons are launched
- UMS settings are effective


IGEL OS Base System 314 / 647



Desktop

The commands defined here are executed at the specific execution times when the X server is launched.

Menu path: System > System Customization > Custom Commands > Desktop



You can define commands for the following execution times:

Desktop initialization

The command is executed during the boot process, before the X server is started. At this point:

- Desktop environment is configured but not launched
- User is not logged on (Kerberos, smartcard etc.)

Before desktop start

IGEL OS Base System 315 / 647



The command is executed before the windowmanager and the autostart sessions are started. At this point:

- Desktop environment is launched
- Message service is launched
- Session D-Bus is launched
- User is not logged on (Kerberos, smartcard etc.)

Final desktop command

The command is executed after each user logon and desktop restart. At this point:

- User is logged on (Kerberos, smartcard etc.)
- User desktop is launched


IGEL OS Base System 316 / 647



Network Custom Commands in IGEL OS 12

You can define commands for network-related execution times.

Menu path: System > System Customization > Custom Commands > Network



You can define commands for the following execution times:

Network initialization

The command is executed at the beginning of the network configuration.

The commands in the below fields are executed each time the relevant network interface starts.

The INTERFACE environment variable contains the name of the network interface started.

IGEL OS Base System 317 / 647



After network DNS

The command is executed after each change in the IP address or host name / after each DNS configuration. At this point:

• IP address / name server settings are used (e.g. via DHCP)

Before network services

The command is executed before network services are started. At this point:

- IP address / name server settings are used
- VPN is connected (if VPN autostart was enabled in the setup)
- No network / host routing settings used

Final network command

The command is executed after network configuration is finished. At this point:

- Network / host routing settings are used
- NFS and SMB drives are available
- System time is synchronized with the time server
- UMS settings are retrieved but not effective yet


IGEL OS Base System 318 / 647



Reconfiguration Custom Commands in IGEL OS 12

The command defined here is executed after settings relating to the local setup or the UMS have been changed.

Menu path: System > System Customization > Custom Commands > Reconfiguration



After reconfiguration

The command is executed after an effective change in the endpoint device settings (local setup, UMS).

IGEL OS Base System 319 / 647




Post-session Custom Commands in IGEL OS 12

You can define an action to be performed when a process or group of processes has ended. The following will refer to this as a global post-session command. You can use the pre-defined actions **Logoff** or **Shutdown** or define a custom command.

The main purpose of this function is to monitor the processes of the Base System, but it can also be used for apps. However, typically, apps bring their own post-session commands. The global post-session command can be given priority over the app-specific post-session commands.

You can specify a list of return codes that indicate that the session has ended successfully. Moreover, you can define which command parameters should be ignored; herewith, you can prevent a command like wfica -version from triggering a post-session command.



Menu path: System > System Customization > Custom Commands > Post Session

Activate generic base_system post-session command

The action defined under **The post-session command to be executed** will be performed when all processes set as a trigger have been ended successfully.

IGEL OS Base System 320 / 647



No actio	n will be r	erformed	when the	process	ends.	(Default)
 1 10 actio	II WILL DC P	CHOINICA	WITCH CITC	process	ciias.	(Delautt)

The post-session command to be executed

This command will be executed when all monitored processes have finished successfully.

Possible options:

- Logoff
- Shutdown
- Enter custom command here: Enter the command you want to have executed.

This session will have priority in executing the post-session command

This setting is relevant if app-specific post-session commands are enabled.

Example: An IGEL Azure Virtual Desktop (AVD) session that has post-session command priority is running. Now, a Citrix Workspace App session that has its own post-session command is started and ended while the AVD session is still running. Because the priority is assigned to the AVD session, the post-session command of the Citrix Workspace App session is ignored.

~	The global post-session command has priority over any app-specific post-session command.
	The global post-session command has no priority.


How to Assign Post-Session Command to a One or More Processes

1. Click	+	to add a	process

2. Enter the **Process name**. This is the name of the binary that is being executed; it also appears when you monitor your processes with ps or top. In our example, the process a local terminal.

IGEL OS Base System 321 / 647






3. Enter the **Valid return codes** for the session. When the process returns one of these return codes, it will be considered as ended successfully. The post-session command will only be executed if the process ends successfully.

The return codes must be comma-separated. You can define ranges using ".."; for example, a range between 10 and 20 is written as 10..20.

IGEL OS Base System 322 / 647






4. With **Ignore command lines**, you can ensure that the post-session command will only be triggered if the program runs normally, not with parameters like --version, or --help, for instance. The command lines must be comma-separated.

IGEL OS Base System 323 / 647






5. Click **Confirm**, then **Save and Close** (or **Save**), and decide whether the change should be sent to the device immediately or after the next reboot.


IGEL OS Base System 324 / 647





IGEL OS Base System 325 / 647





IGEL OS Base System 326 / 647




Custom Application in IGEL OS 12

You can add custom applications to call up commands through the defined starting methods. For example, you can create a desktop shortcut to run a command.



Custom application commands are executed as user.

Menu path: System > System Customization > Custom Application



To manage the list of custom applications:


- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.
- → Click to add a new custom application session.

The starting methods parameters are described under Starting Methods for Apps (see page 644).

Under **Custom Application > [Custom Application Name] > Settings**, you can define the command to be run and the icon for the shortcut.

IGEL OS Base System 327 / 647





Icon large

Select an icon provided. (Default: applications-other)



Only the desktop icon of a session is customizable. The taskbar icon of a session cannot be customized and will remain the default icon. Complete customization is not possible.

Command

Give the name and path of the application. (Example: /usr/bin/gpicview)


IGEL OS Base System 328 / 647



Environment Variables in IGEL OS 12

Environment variables allow you to use dynamic parameter values for a number of session types, e.g. so as not to have to enter ICA or RDP servers for every session. Predefined variables can also be allocated and distributed via the IGEL UMS. Additional variables can only be used locally on the device and may be overwritten by a UMS configuration.

Menu path: System > System Customization > Environment Variables



Enable variable substitution in session

✓ The use of variables in sessions such as ICA and RDP is enabled. If specific parameters contain a \$, shell substitution will be carried out.

☐ The use of variables in sessions is not enabled. (Default)

IGEL OS Base System 329 / 647



You can use environment variables in custom commands. For more information on these, see Custom Commands in IGEL OS 12 (see page 312) .

In addition, the following session parameters can be updated through variables:

- Legacy ICA sessions: Citrix Server or published application
- Legacy ICA sessions: User
- RDP session: ServerRDP session: User
- Predefined Environment Variables (see page 331)
- Additional Environment Variables (see page 333)


IGEL OS Base System 330 / 647



Predefined Environment Variables

This article shows the options to configure predefined environment variables in IGEL OS.

Menu path: System > System Customization > Environment Variables > Predefined



Variable name

Name for the variable

Value

Value for the variable

Using Environment Variables in Sessions

To use environment variables in sessions, proceed as follows:

IGEL OS Base System 331 / 647



1. Enable environment variables under **System > System Customization > Environment Variables** > Enable variable substitution in session.

2. Define the variable name and content, e.g.

• Variable name: SERVERNAME

• Value: testServer

3. Enter the variable name in the parameter field of the session with the \$ symbol before it.

Example: \$SERVERNAME



1 In the case of RDP and ICA sessions, the value is entered in the session file after saving. With XenApp, the setting is not implemented until a session starts and is running.


IGEL OS Base System 332 / 647



Additional Environment Variables

This article shows how to define other environment variables in addition to the predefined ones.

Menu path: System > System Customization > Environment Variables > Additional



To manage the list of **Additional** variables:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking brings up the **Add** dialogue, where you can define the following settings:

IGEL OS Base System 333 / 647



• Variable name

Name for the variable

• Value

Value for the variable

IGEL OS Base System 334 / 647



Corporate Design - Configure the User Interface in IGEL OS 12

In this area, you can configure settings allowing you to adapt the user interface to your needs.

Use the settings on the following pages to create your design:

- Custom Bootsplash in IGEL OS 12 (see page 336)
- Background (1st Monitor) for Corporate Design in IGEL OS 12 (see page 339)
- Company Logos in IGEL OS 12 (see page 346)

IGEL OS Base System 335 / 647




Custom Bootsplash in IGEL OS 12

With a bootsplash, you can show your company logo or a specific image during the booting procedure. The bootsplash will be shown instead of the console messages. You need to provide an image file for your custom bootsplash on a download server.



The file types JPG, JPEG, BMP, PNG, SVG, GIF, and TIFF can be used for a bootsplash. A total storage area of 25 MB is available for all user-specific images. The image is 800 x 600 pixels in size (aspect ratio remains unchanged). It can be positioned vertically and horizontally.

Menu path: System > System Configuration > Corporate Design > Custom Bootsplash



Custom Bootsplash

Enable custom bootsplash

IGEL OS Base System 336 / 647



✓ A custom bootsplash can be configured.
\square No custom bootsplash is configured. (Default)

Custom Bootsplash - Server Location

Protocol

Access method for the image Possible options:

- HTTP: Download from a web server
- HTTPS: Download from a TLS/SSL-secured web server
- FTP: Download from an FTP server. (Default)
- Secure FTP: Download via SSH-secured FTP
- FTPS: Download from a TLS/SSL-secured FTP server
- **FILE**: The image file lies in the file system of the device, possibly as a shared NFS or Windows update. You can enter the location under **Local path**.

Local path

The path to the background image. The parameter is shown when **FILE** is selected as protocol.

Server name

Name or IP address of the server

Server path

Path to the directory with the image file on the server

Port

Port of the server on which the service is provided. The field is populated by protocol specific default values.

User name

User name on the server

Password

Password for the user account on the server

Custom Bootsplash - Settings

Custom bootsplash file

Filename of the custom image

Custom bootsplash style

• Original (Default)

IGEL OS Base System 337 / 647



- Stretched
- Scaled
- Zoomed

Background color

The background color of the bootsplash. Click the color preview square to open the color selector.

Horizontal position of the bootsplash image

The following applies: 0 = left-justified, 50 = centered, 100 = right-justified. (Default: 50)

Vertical position of the bootsplash image

The following applies: 0 = aligned on top, 50 = centered, 100 = aligned on bottom. (Default: 50)

Size of progress indicator

Valid range is 72-256. (Default: 72)

Horizontal position of the progress indicator

The following applies: 0 = left-justified, 50 = centered, 100 = right-justified. (Default: 90)

Vertical position of the progress indicator

The following applies: 0 = aligned on top, 50 = centered, 100 = aligned on bottom. (Default: 90)

Bootsplash update

When clicked the user-specific bootsplash is downloaded from the given server.



if you change the image file or even just one of the settings for an existing bootsplash, be sure to click **Bootsplash update** in order to regenerate the system files used.


IGEL OS Base System 338 / 647



Background (1st Monitor) for Corporate Design in IGEL OS 12

This article shows how to configure the desktop background for a corporate design in IGEL OS. You can use predefined IGEL backgrounds, a fill color/color gradient, or a background image of your own. You can set up different background images for each monitor connected to the device.

Menu path: System > System Customization > Corporate Design > Background (1st Monitor)



Wallpaper

Provides a selection of predefined IGEL backgrounds. Possible options:

- Neutral
- Off
- **IGEL** (default)

Wallpaper style

IGEL OS Base System 339 / 647



Provides various design versions. Possible options:

- Auto
- Centered
- Tiled
- Stretched (Default)
- Scaled
- Zoomed

Color style

Sets a fill color or a color gradient. Possible options:

- Solid color
- Horizontal gradient (Default)
- Vertical gradient

Desktop color

The desktop color if **Wallpaper** is set to **Off**. Click the color preview square to open the color selector.

2nd desktop color

The second desktop color if **Wallpaper** is set to **Off** and a gradient **Color style** is selected. Click the color preview square to open the color selector.

Custom wallpaper download

You can provide a user-specific background image on a download server. Specify the download server under System > System Customization > Corporate Design > Background > Custom Wallpaper Server.

☐ Custom wallpaper is not used. (Default)

Custom wallpaper file

The name of the background image file

The user-specific background image will be downloaded from the specified server if the function was enabled and if requested manually by clicking **Wallpaper update** under **System > System Customization > Corporate Design > Background > Custom Wallpaper Server**. The download can also be launched from the IGEL Universal Management Suite (UMS) via the **Update desktop customization** command.



A user-specific image can be provided on a download server. The file types BMP, JPG, GIF, TIF, PNG and SVG are supported for an own background image and bootsplash. A total storage area of 25 MB is available for all user-specific images. For more information, see *Universal Management Suite > UMS Reference Manual > Firmware Customizations in the IGEL UMS*.


IGEL OS Base System 340 / 647



Background (2nd-8th Monitor)

This article shows how to configure the desktop background of further monitors in multi-monitor environments in IGEL OS.

Menu path: System > System Customization > Corporate Design > Background (2nd-8th Monitor)



You can use predefined IGEL backgrounds, a fill color or a color gradient. You can also use a background image of your own.



You can set up a separate background image for each monitor that is connected to the device.

Wallpaper

Provides a selection of predefined IGEL backgrounds. Possible options:

IGEL OS Base System 341 / 647



- Follows configuration for first monitor (Default)
- Neutral
- Off
- IGEL

Wallpaper style

Provides various design versions. Possible options:

- Follows configuration for first monitor (Default)
- Auto
- Centered
- Tiled
- Stretched
- Scaled
- Zoomed

Color style

Sets a fill color or a color gradient.

Possible options:

- Follows configuration for first monitor (default)
- Solid color
- Horizontal gradient
- Vertical gradient

Desktop color

The desktop color if **Wallpaper** is set to **Off**. Click the color preview square to open the color selector.

2nd desktop color

The second desktop color if **Wallpaper** is set to **Off**. Click the color preview square to open the color selector.

Custom wallpaper download

You can provide a user-specific background image on a download server. Specify the download server under System > System Customization > Corporate Design > Background > Custom Wallpaper Server.

☐ Custom wallpaper is not used. (Default)

Custom wallpaper file

The name of the background image file

The user-specific background image will be downloaded from the specified server if the function was enabled and if requested manually by clicking **Wallpaper update** under **System > System Customization > Corporate Design >**

IGEL OS Base System 342 / 647



Background > Custom Wallpaper Server. The download can also be launched from the IGEL Universal Management Suite (UMS) via the **Update desktop customization** command.



1 A user-specific image can be provided on a download server. The file types BMP, JPG, GIF, TIF, PNG and SVG are supported for an own background image and bootsplash. A total storage area of 25 MB is available for all user-specific images. For more information, see *Universal Management Suite > UMS Reference* Manual > Firmware Customizations in the IGEL UMS.


343 / 647 IGEL OS Base System



Custom Wallpaper Server

This article shows how to configure the download server for your own background images in IGEL OS.

Menu path: System > System Customization > Corporate Design > Background (1st Monitor) > Custom Wallpaper Server



Protocol

Access method for the image Possible options:

- HTTP: Download from a web server. (Default)
- HTTPS: Download from a TLS/SSL-secured web server
- FTP: Download from an FTP server
- Secure FTP: Download via SSH-secured FTP
- FTPS: Download from a TLS/SSL-secured FTP server

IGEL OS Base System 344 / 647



• **FILE**: The image file lies in the file system of the device, possibly as a shared NFS or Windows update. You can enter the location under **Local path**.

Local path

The path to the background image. The parameter is shown when **FILE** is selected as protocol.

Server name

Name or IP address of the server used

Server path

Directory in which you saved the background image

Port

Port of the server on which the service is provided. The field is populated by protocol specific default values.

User name

Name of the user account on the server

Password

Password for this account

Wallpaper update

The button refreshes the background image when clicked.


IGEL OS Base System 345 / 647



Company Logos in IGEL OS 12

You can configure the device to show your company logo in the screensaver and in the start menu.

Menu path: System > Firmware Customization > Corporate Design > Company Logos



Screensaver

Enable image display

✓ The image defined below will be shown as the screensaver. (Default)

File for screen saver logo

Complete path for an image file or a directory that contains a number of image files.



If you enter a folder instead of a single image file as the source, all images in the folder will be displayed as a slide show. The **image display time** for the images can be configured. If you do not specify a file of your own, the *IGEL* logo will be used.

IGEL OS Base System 346 / 647



One image per monitor

✓ The image will be shown on each individual monitor rather than one image across all monitors. (Default)

Image duration

Time in seconds until the image changes. (Default: 10)

Image display mode

Defines how the image is displayed Possible options:

- Small-sized hopping: small image that jumps across the screen. (Default)
- Medium-sized hopping: larger image that jumps across the screen
- Full screen center cut out: Image is displayed across whole screen, edges can be cut off.
- Full screen letterbox: Complete image is shown. A black edge may be visible depending on the format.

Start menu

Start button icon

File name with full path to select your logo as the icon for the start menu in the taskbar. Size: 32x32 pixels




Company logo in start menu

File name with full path to show your company logo in the top of the start menu window. Size: 64x64 pixels

IGEL OS Base System 347 / 647





IGEL OS Base System 348 / 647




Update - App Update Settings in IGEL OS 12

This article shows how to configure app update settings in IGEL OS.



Apps can only be installed by the user if **Permit local app installation** is enabled under **Security > Update**. For more information, see Installing IGEL OS Apps Locally on the Device³⁸.

Menu path: System > Update



Action after app assignment from UMS

Possible options:

- **Download and activate (Apps usable after reboot)**: When an app is assigned to the device, it will be downloaded and installed immediately. The app can be used after the next reboot. (Default)
- **Download only (additional step is needed to activate new app(s))**: When an app is assigned to the device, it will be downloaded immediately. It will be installed when the UMS sends an update command to the device. The device will then reboot; afterward, the app can be used.
- Nothing (additional step is needed to download and activate new app(s)): When an app is assigned to the device, the device does nothing. The app will be downloaded and installed when a timer is triggered; see https://igel-jira.atlassian.net/wiki/pages/createpage.action? spaceKey=igelos12bsdocp&title=%2812.7.3-en%29%20Custom%20CronJob%2FSystemd%20Timer%20in%20IGEL%20OS%2012&linkCreation =true&fromPageId=565641632 The device will then reboot; afterward, the app can be used.

Action after app activation

Possible options:

IGEL OS Base System 349 / 647

^{38.} https://kb.igel.com/en/how-to-start-with-igel/current/installing-igel-os-apps-locally-on-the-device



- Ask User: When the app has been assigned to the device and **Download and activate (Apps usable after reboot)** is selected or the UMS has sent an update command, a dialog with a timeout appears. Depending on the user's action, the device will act as follows:
 - The user clicks **Restart Now**: The device reboots. The app can be used after the reboot.
 - The timeout expires: The device reboots. The app can be used after the reboot.
 - The user clicks **Restart Later**: The app can be used after the next reboot.
- **Reboot immediately**: The device reboots immediately. The app can be used after the reboot.
- Nothing: When the app has been assigned to the device and Download and activate (Apps usable after reboot) is selected or the UMS has sent an update command, the device does nothing. The app will be installed and ready for use on the next reboot.

Show download progress as notification to the user
✓ When an app is downloaded, the download progress is shown as a notification.
□ No download progress is shown.
Timeout for automatical reboot in seconds
Time period between the app installation and the reboot. (Default: 60)
Use a bandwidth limit while updating
☑ Limits bandwidth usage during the downloading of updates to the value set under Limit bandwidth used for updating .
\square Bandwidth usage is not limited during the downloading of updates. (Default)
Limit bandwidth used for updating
The value to which the bandwidth is limited during the downloading of updates. You can give the value with KB, MB, or GB as the quantifier. If no quantifier is given, the value is in megabytes. (Default: 2MB)
Seconds to wait for network connection during a multi stage update
A multi stage update is cancelled if no network connection can be established during this period. (Default: 60)
Check for and download updates for non pinned apps on boot
This option helps keep the apps on the device up-to-date by checking for updates on each boot. This is potentially security-relevant
Non-pinned apps are all apps that are not assigned to a device via the UMS, regardless of whether the assignment was made via a profile or directly. This applies to apps that are dependencies of other apps, for instance. Example: The app Citrix Multimedia Codec is a dependency for the Citrix Workspace App .
✓ On each boot, the device checks for updates of non-pinned apps. If updates are found, they are installed on the device. (Default)
\square Updates of non-pinned apps are not checked automatically.

IGEL OS Base System 350 / 647



Check for and download updates for non pinned apps on given calendar time, use the crontab syntax to specify the calendar time

This option helps keep the apps on the device up-to-date by checking for updates periodically. To define the period, use the crontab syntax.



Consider Network Load

It is recommended to take into account the network load that occurs when a large number of devices download the updated apps. If required, use the settings Use a bandwidth limit while updating and Limit bandwidth used for updating.

Non-pinned apps are all apps that are not assigned to a device via the UMS, regardless of whether the assignment was made via a profile or directly. This applies to apps that are dependencies of other apps, for instance. Example: The app Citrix Multimedia Codec is a dependency for the Citrix Workspace App.

If the defined checking time has been missed because the device has no network or cannot reach the UMS or the IGEL App Portal, the update check is queued until the connection is available again. If the defined checking time has been missed because the device has been powered off, the update check will not be queued.

Possible values: Crontab syntax; if the field is empty, no update check will be performed. For details on the crontab syntax, see https://man7.org/linux/man-pages/man5/crontab.5.html or check out the interactive tool at https:// crontab.guru/.

Repositories

Prioritized list of repositories used for app updates



You can use this option to configure IGEL OS 12 devices to get their updates from distributed peer update servers. For details, see https://kb.igel.com/en/universal-management-suite/current/how-to-usedistributed-app-repositories-in-igel-um.

To manage the list:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking brings up the **Add** dialogue, where you can define the following settings:

Certificate

The certificate used for authentication to the repository

Priority

The number defines the priority of the repository, where a larger number means a higher priority. The priority determines the order in which the device tries to connect to download apps. It will try to connect to the repository with the highest priority, and if that is not available, it will fall back to the next one.

351 / 647 **IGEL OS Base System**



Numbers are accepted from 0 to 4294967295.

Repository URL

The URL of the repository

External binary source

This is relevant if you use distributed app repositories; for details, seehttps://kb.igel.com/en/universal-management-suite/12.06.120/how-to-use-distributed-app-repositories-in-igel-um.

To manage the list:

- Click to create a new entry.
- Click to remove the selected entry.
- Click to edit the selected entry.
- Click to copy the selected entry.

Clicking brings up the **Add** dialogue, where you can define the following settings:

- **Priority**: The number defines the priority of the repository, where a larger number means a higher priority. The priority determines the order in which the device tries to connect to download apps. It will try to connect to the repository with the highest priority, and if that is not available, it will fall back to the next one.
- **Repository URL**: The URL of the repository
- **Username**: The username with which the device downloads the binaries from the app repository.
- **Password**: The password associated with the username.
- Certificate: File path to the SSL certificate that is used for the HTTPS connection

Use only repositories deployed by the UMS

The device can only download apps from repositories for which the UMS acts as an update proxy.

☐ The device can download apps from all the configured repositories. (Default)



The parameter requires UMS 12.04.110 or later.

IGEL OS Base System 352 / 647



Registry in IGEL OS 12

In the registry, you can change almost any firmware parameter, including parameters not shown in the GUI. You will find information on the individual items in the tooltips.


Menu Path: System > Registry



Changes to the registry should only be made by experienced administrators. Incorrect parameter settings can easily destroy the configuration and cause the system to crash. In cases like these, the only way to restore the functionality is to reset the device to the factory defaults!

Registry User Interface

The registry shares most of the GUI elements with the rest of the configuration dialog. For details, see Configuration of IGEL OS 12 Device Settings (see page 6).



- 1 You can use the breadcrumbs to track your navigation within the registry.
- In the Profile Configurator, you can use the toggle button to only see parameters activated by the parameter activator (3) in the registry.
- In the Profile Configurator, you can use the parameter activator to activate registry parameters. When you deactivate the parameter, the value will be automatically set back to the default value. For more on profile creation, see (12.05.100-en) How to Create and Assign Profiles in the IGEL UMS Web App.
- 4 Your changes are marked with indicators on the right side of the parameter. For more on change indicators, see Configuration of IGEL OS 12 Device Settings (see page 6).
- 5 Under **Used In**, you can find the list of configuration pages where the parameter is used. Click on the page link to jump to the page.

Add instance

IGEL OS Base System 353 / 647




Adds instances to the registry. This is possible with parameters that have a percent sign as their last character, e.g. nfymount% . The new instances are numbered consecutively: nfymount1 , nfymount2 etc.



Delete instance

Deletes a previously added instance.




Search in the Registry

You can use the advanced search to search for registry parameters.

IGEL OS Base System 354 / 647





To search for parameters in the registry:

- 1. Enable advanced search using the toggle button.
- 2. Activate Include Registry.
- 3. Start typing in the search field.

 The search results list automatically refreshes as you type.
- 4. Click on a search result to display the registry page. The result is highlighted on the page. When a search result is clicked, the search menu remains displayed in the top right corner with the following navigation options:
 - arrows to go to the next or the previous search result
 - search icon to expand the search tab
 - X to close the search

IGEL OS Base System 355 / 647




Notification - User Notifications in IGEL OS 12

To allow seamless operation for your users, you can control the visibility of user notifications on the device.

You can filter notifications according to their severity. Also, you can define an automatic action for those notifications that require a user action.

Menu path: System > Notification



Show notification of specified severity and above as floating notification

Specifies which levels of notifications are shown in a message window. Please note that, by default, notifications that require a user action are shown independently of this setting. You can change this with **Suppress notifications with a required user action** (see below).

Possible options:

- All: Notifications of the levels "info", "warning", and "error" are shown, as with Info. (Default)
- Info: Notifications of the levels "info", "warning", and "error" are shown.
- Warning: Notifications of the levels "warning" and "error" are shown.
- Error: Notifications of the level "error" are shown.
- None: No notifications are shown.

Show suppressed notification in notification panel

✓ The notifications filtered out by the setting **Show notification of specified severity and above as floating notification** can be retrieved by clicking on ! in the taskbar. The icon shows the number of unread notifications. □ The suppressed notifications cannot be retrieved. (Default)

Suppress notifications with a required user action

IGEL OS Base System 356 / 647



✓ Notifications are suppressed even when they require a user action	. The action is defined by Action in
suppressed notification with user action.	

☐ Notifications that require a user action are not suppressed. (Default)

Action in suppressed notification with user action

Possible options:

- **Default**: The default action defined for the notification is executed. (Default)
- Cancel: The action is canceled.

IGEL OS Base System 357 / 647



Tray Applications in IGEL OS 12

This article describes the tray applications available in IGEL OS 12. You can open the tray apps by clicking the icons in the system tray.



The icons change dynamically to represent the current setup or status. If you hover over the icons, tooltips are displayed with further information.



By default, the system tray and all the tray apps are available. You can configure the system tray and the tray apps under User Interface > Desktop > Taskbar Items. For details, see Taskbar Items in IGEL OS 12 (see page 113).

The access to tray apps on lockscreen is configured separately under **User Interface > Desktop >** Screenlock / Screensaver > Taskbar. For details, see Taskbar in Locked Screen in IGEL OS 12 (see page 61)

The following tray apps are described in detail:

Taskbar Icon	Link to Section
۵	UMS Tray App (see page 359)
হ	Wi-Fi Tray App (see page 359)
Ģ	LAN Tray App (see page 363)
4G	Mobile Broadband Tray App (see page 365)
	Display Tray App (see page 368)
◆ 》	Mouse & Touchpad Tray App (see page 375)
-	Battery Tray App (see page 378)
■	Sound Tray App (see page 379)
*	Bluetooth Tray App (see page 381)
合	Printer Tray App (see page 382)
€	OpenConnect VPN Tray App (see page 385)

IGEL OS Base System 358 / 647



UMS Tray App

→ Open the UMS tray app by clicking the UMS tray icon. The icon is dynamic and represents the state of the connection as described below. The tray app also displays basic information of the connected Universal Management Suite (UMS), like **IP** address and **Hostname**.

UMS Connection Status	Taskbar Icon
Connected	
Connecting	
Disconnected	•
Unmanaged	


Wi-Fi Tray App

 \rightarrow Open the Wi-Fi tray app by clicking the Wi-Fi tray icon. The icon is dynamic and represents the state of the connection.



The Wi-Fi tray app opens. Using the icons at the top of the window, you can:

→ Use the toggle switch of the Wi-Fi tray app to turn Wi-Fi off and on.



- → Add a hidden network.
- → Scan for Wi-Fi networks to refresh the list of available networks.
- → Check the details of the connected network.

IGEL OS Base System 359 / 647



→ Switch between the **Known Networks** list and the **Available Networks** list.



If the Automatic switch of network connection parameter is enabled under Network > Common Settings, the toggle can get disabled. For more information, see Common Settings (see page 170).

Connect to Available Wi-Fi Networks

To connect to a network, do the following:

More...


- 1. Switch to the **Available Networks** list or use the **Scan Wifi** icon to refresh the list.
 - The list of networks is sorted according to their signal strength.
 - Previously configured networks are marked with a star icon. They are listed in the Known Networks List.
 - The currently connected network is marked with a tick icon.



IGEL OS Base System 360 / 647



2. Click on the network to be connected and provide the network key.



You can enable the **Store WiFi key** and **Auto Connect** parameters according to your needs. For information on saving network credentials for Wi-Fi WPA Enterprise connections, see How to Configure the Permanent Storage of User-Provided Network Credentials (Wi-Fi and Ethernet) (see page 539).

3. Click Connect.

The Wi-Fi tray icon changes to show the active connection.

The configured network is listed in the **Known Networks** list.

The configured connections get listed in the IGEL Setup under **Network > Wireless > Wi-Fi Networks**. For more information, see Wi-Fi Networks (see page 142).

4. To disconnect from the connected network, click on the network and click **Disconnect**.

Edit and Delete Known Networks


If you want to edit or delete a network, do the following:

More...

1. Switch to the **Known Networks** list.

IGEL OS Base System 361 / 647





2. Click on the network to be edited or deleted.
You can enable the **Store WiFi key** and **Auto Connect** parameters according to your needs.

If you need to edit or delete Wi-Fi WPA Enterprise connections, you cannot do this via the above dialog. Use the IGEL Setup or the UMS profile, instead.

3. Click **Save** to save the changed configuration or click **Delete** to remove the network from the list.

Connect to Hidden Networks


If you want to connect to a hidden network, do the following:

More...

- 1. Switch to the **Known Networks** list.
- 2. Click the **Add Hidden Network** icon at the top of the window.

IGEL OS Base System 362 / 647





- 3. Set the **Encryption Type**, provide the SSID and the network key.
- 4. Click Connect.

The Wi-Fi tray icon changes to show the active connection.

The configured network is listed in the **Available Networks** list and in the **Known Networks** list.

The configured connections get listed in the IGEL Setup under **Network > Wireless > Wi-Fi Networks**. For more information, see Wi-Fi Networks (see page 142).


5. To disconnect from the connected network, click on the network in the **Available Networks** list and click **Disconnect**.

LAN Tray App

→ Open the LAN tray app by clicking the LAN tray icon. The app displays details about the LAN network connection and provides an option to easily connect to and disconnect from LAN networks.

IGEL OS Base System 363 / 647





The tray icon is dynamic and represents the state of the connection as described below. The state of the connection is determined by the network manager. The network manager periodically requests http://connectivity-check.ubuntu.com/ to check the connectivity.

LAN Status	Taskbar Icon
Connected	_ P
No connection	₽
Connected, but no internet	

IGEL OS Base System 364 / 647




LAN Status	Taskbar Icon
Connecting	<u>_</u>
Disconnected by user	Z i
Connection error	¥P

For information on saving network credentials for Ethernet IEEE 802.1X connections, see How to Configure the Permanent Storage of User-Provided Network Credentials (Wi-Fi and Ethernet) (see page 539).

Mobile Broadband Tray App

→ Open the tray app by clicking the mobile broadband tray icon. The tray icon is dynamic and represents the state of the connection:






Starting from OS version 12.4.1, on devices supporting mobile broadband physical SIM and eSim as well, an automatic switch to the physical SIM slot is performed if eSim has no profile assigned.

The mobile broadband tray app displays details about the WWAN network connection, like the network Provider and the **Signal Strength**, and provides an option to easily connect / disconnect and configure networks.

IGEL OS Base System 365 / 647





- → Use the toggle to switch the WWAN connection off and on.
- If the **Automatic switch of network connection** parameter is enabled under **Network > Common Settings**, the toggle can be disabled. For more information, see Common Settings (see page 170).
- → Click **SIM Details** to display the details and to configure the settings that are enabled for the tray app.




More...

You can set which configurations are available in the tray up under **Network > Mobile Broadband**. For details, see Mobile Broadband in IGEL OS 12 (see page 136).

IGEL OS Base System 366 / 647





You can configure the following:

- Auto Connect
 - ✓ The mobile internet connection is established automatically. (Default)
- Edit PIN

Change the PIN of the SIM card.

- Request PIN on boot
 - Set if PIN needs to be provided at startup.
- Roaming


Use the toggle to enable/disable the connection to roaming networks.

→ Click **Change Provider** to edit the network provider information:

More...

IGEL OS Base System 367 / 647





You can configure the following:

- Country or region
 - Country or region of the service provider.
- Provider

Your mobile network connection provider.

Access Point

APN (Access Point Name) for your network connection. If you do not know the APN, ask your mobile communications operator for it.

Display Tray App



Automatic Display Profile

When the endpoint device is connected to different environments, such as when the user switches between different workplaces, it will attempt to store each monitor setup.

→ Open the display tray app by clicking the tray icon:

Open the display tray app by clicking the tray icon:


IGEL OS Base System 368 / 647



The icon is dynamic in multi-monitor environments and represents the configured **Multiple Display Mode**.

The basic window opens with different content for single display and multiple display setups.

Basic Window - Single Display



Here, you have the following configuration options:


- → Click the info icon to display device information.
- → Set **Orientation**, **Resolution** and **Refresh rate** for the single display.

After clicking **Apply**, you need to confirm keeping the changes before timeout. After the timeout, settings revert to the previous configuration.

IGEL OS Base System 369 / 647



Basic Window - Multiple Display



Here, you have the following options:

→ Click the You have X connected displays or the Custom Configuration button to open the display configuration window.



Display information is always available in the display configuration window, but configuration is only possible if you select Custom as Multiple Display Mode.

→ Change the Multiple Display Mode.

You have the following Multiple Display Mode options:

• Custom (Default)

The configurations made in the display configuration window are applied. Configurations made in the display configuration window are persistent, they carry over reboot.

• Mirror

The content is mirrored to all displays.

Internal only

The internal display will become the primary display. External displays get deactivated.

External only

One of the external display will become the primary display. The internal display gets deactivated.

IGEL OS Base System 370 / 647




Temporary Effect

The Multiple Display Mode option in the basic window can be used to quickly change the display setting temporarily. After reboot or suspend, the **Multiple Display Mode** will reset to the default **Custom**. If you want display configurations to be persistent, select Custom as Multiple Display Mode and click **Custom Configuration** to change the settings in the display configuration window.



After clicking **Apply**, you need to confirm keeping the changes before timeout. After the timeout, settings revert to the previous configuration.

Display Configuration Window





i Display information is always available in the display configuration window, but configuration is only possible if **Custom** display mode is applied in the basic window. You can see the selected mode in the bottom left corner.

Here, you have the following options:


More...

→ You can click **Reset** to restore the last saved configurations.


After clicking **Apply**, you need to confirm keeping the changes in a dialog. After the timeout, settings revert to the previous configuration.

IGEL OS Base System 371 / 647






→ You can click the info icon to display information on **Hardware Limitations** for the device. This information is needed for the configuration, because you cannot create display layouts which exceed the given maximum resolution or number of connected displays.



→ Click the question mark icon to display the **Keyboard shortcuts** that you can use for display configuration.


IGEL OS Base System 372 / 647





Left Hand Panel

→ Select a display from the dropdown at the top, or by clicking the display in the **Layout Area**, to configure the display and to see the details of the selected display at the bottom of the panel.



You can use the parameters to configure the following:

• Orientation

IGEL OS Base System 373 / 647




- Resolution
- · Refresh rate
- Primary toggle

Activate if you would like to make the selected display the primary display. The primary display is marked with a house icon. Only one display can be primary; if a display is marked as primary, the existing primary becomes non-primary.

• Active toggle

Use the toggle to activate/deactivate the selected display. You cannot deactivate all the displays, at least one display must remain active.

Drag and Drop Panel




Here you can:

- Select a display by clicking on it.
- Edit the layout of the displays by drag and drop.
- Deactivate displays by moving them to the **Inactive Displays** row.
- Activate displays by moving from **Inactive Displays** to the **Layout Area**.
- Create mirror groups by moving displays together in the **Mirror with** row.
- Unmirror displays by moving from **Mirror Group** row to **Layout Area**.

IGEL OS Base System 374 / 647





Mouse & Touchpad Tray App

→ Open the tray app by clicking the tray icon.


The icon is dynamic and represents the detected device. If a mouse is detected, the following icon is shown:

If a touchpad is detected, or both a mouse and a touchpad are detected, the following icon is shown:

IGEL OS Base System 375 / 647



Configuring the Mouse in the Mouse & Touchpad Tray App



You can use the mouse & touchpad tray app to configure the following mouse settings for the detected device:

More...

• Primary Button

Sets the primary button both for mouse and touchpad. In IGEL Setup, you can configure this through **Left-handed mode**.

• Pointer Speed

Sets the speed of the pointer both for mouse and touchpad. In IGEL Setup, you can configure this through **Pointer speed**.

• Double-click Speed

Sets how fast two consecutive mouse clicks need to happen to be recognized as a double-click. You can test this with the **click to test** area. In IGEL Setup, you can configure this through **Double**

IGEL OS Base System 376 / 647




click interval. The smaller the interval, the faster the consecutive clicks need to happen to be recognized as a double click.

• Scrolling Direction

Sets the direction of the screen movement when scrolling with the mouse. In IGEL Setup, you can configure this through **Natural scroll.**

Configuring the Touchpad in the Mouse & Touchpad Tray App



You can use the mouse & touchpad tray app to configure the following touchpad settings for the detected device:

More...

• Primary Button

Sets the primary button both for mouse and touchpad. In IGEL Setup, you can configure this through **Left-handed mode** under **User Interface > Input > Mouse**.

IGEL OS Base System 377 / 647



Pointer Speed

Sets the speed of the pointer both for mouse and touchpad. In IGEL Setup, you can configure this through **Pointer speed** under **User Interface > Input > Mouse**.

Enabled

The toggle buttons enables/disables the touchpad.

Touchpad Sensitivity

Sets how sensitive the touchpad is to the touch. In IGEL Setup, you can configure this through **Min speed**, **Max speed**, and **Acceleration**. If you have those values custom configured, it is advised not to change the slider in the tray app, as it will reset the levels in the IGEL Setup.

• Scrolling Direction

Sets the direction of the screen movement when scrolling with the touchpad. In IGEL Setup, you can configure this through **Natural scroll**.

Scrolling Method

Sets the type of finer movement to be detected as scrolling. In IGEL Setup, you can configure this through **Two finger vertical scroll** and **Two finger horizontal scroll** under **User Interface > Input > Touchpad > Scrolling**.

• Tap to Click

The toggle switch enables/disables clicking with a tap on the touchpad. In IGEL Setup, you can configure this through **Tapping mode**.

• Palm Detection

The toggle switch enables/disables palm detection. When enabled, it avoids triggering a function accidentally with the palm of your hand. The function must be supported by the device. In IGEL Setup, you can configure this through **Palm detect** under **User Interface > Input > Touchpad > Advanced**.

Battery Tray App


→ Open the tray app by clicking the battery tray icon. The icon is dynamic and represents the state of the battery charge.

When the battery is charging, the following icon is shown:

When the battery is discharging, the following icon is shown:

IGEL OS Base System 378 / 647





The battery tray app shows information for all available batteries, including multiple internal batteries and batteries of connected bluetooth devices. You can set the CPU power plan regulation under **Powerplan**.



The CPU power plan is set for the current mode in use (AC or Battery). The CPU power plan can be set for all modes under **System > Power Options > System**. For the description of the power plans, see System Power Options in IGEL OS 12 (see page 293).


Sound Tray App

→ Open the sound tray app by clicking the following icons:

When the devices are muted the icons change accordingly to:

IGEL OS Base System 379 / 647





You can do the following in the tray app:

- → Use the dropdown menu to select which output/input device is to be used.
- → Set the volume for the selected output/input device.
- → Enable/disable overamplification. If the overamplification parameters are set under **Devices > Audio > Options**, you cannot change the setting from the tray app.
- → Use the **Mute All** button to mute all the output devices.



IGEL OS Base System 380 / 647




Bluetooth Tray App

- → Open the bluetooth tray app by clicking the tray icon: *
- → Use the toggle button to switch bluetooth on and off.
- → To connect a new bluetooth device:
 - 1. Go to the **Available Devices** view by clicking the button in the top right corner:



2. Select a device from the list of devices that are available to connect and click **Connect**. If the device needs a PIN for the pairing process, it will be displayed above the **Connect** button during the connect process.



3. Some bluetooth devices have no names assigned to them. If you enable **Show Unnamed Devices**, you can see these devices in the list with their MAC address displayed.




- → To manage the connected devices:
 - 1. Go to the **Paired Devices** view by clicking the button in the top right corner:


IGEL OS Base System 381 / 647





2. Select a device from the list and click **Connect**, **Disconnect** or **Unpair**.





Printer Tray App

- → Open the printer tray app by clicking the tray icon: 🖨
- → To connect a new printer:
 - 1. Go to the **Available Printers** view by clicking the button in the top right corner:




IGEL OS Base System 382 / 647




2. Here, you have two options to connect a printer.

You can scan the network for printers, by clicking the scan button. Then, select a printer and click **Connect**.



You can also add a printer by clicking +. Provide the configurations of the printer and click **Connect**.



You can use the Search bar, to search in the list


Available Printers

Pri

HP Printer

The configuration options change according to the selected **Device Type**. You have the following options to set as connection type:

- USB
- TCP
- IPP
- Parallel
- Serial
- → To manage connected printers and printer jobs:
 - 1. Go to the **Connected Printers** view by clicking the button in the top right corner:



IGEL OS Base System 383 / 647




- 2. Select a printer under **Connected Printers.** You can click the buttons to:
- print a test page from the printer
- delete the printer
- set it as default printer
- Only one default n

Only one default printer can be set (i.e. setting a printer to default means that an existing one loses this property.) If there is a default printer set by the admin, the user cannot set another printer as default. If a printer is set by your administrator, you cannot delete or modify it. But you can still print a test page.

Print-Center

Jobs




Under **Jobs**, you can see the list of printer jobs with status info (like **Processing**, **Pending**, **Aborted**). When an error occurs, the error messages are displayed under the job.

→ Use the trash icon to cancel a printer job.

IGEL OS Base System 384 / 647





OpenConnect VPN Tray App

→ Open the OpenConnect VPN tray app by clicking the icon.

You can find the status information of the VPN connection under **More Details**. The status is also shown in the displayed tray icon .

You can click **Disconnect** to disconnect from the OpenConnect VPN connection.

For more information on the OpenConnect VPN App, see OpenConnect VPN³⁹.

IGEL OS Base System 385 / 647

^{39.} https://kb.igel.com/en/igel-apps/current/openconnect-vpn



How to Create Shortcuts to Tray Applications in IGEL OS 12

You can create shortcuts to run commands with the help of custom applications. For example, you can configure a custom application (see page 327) as a desktop shortcut to open a tray application dialog (see page 358). For this, you can use the igel-system-tray CLI commands.

Profile with Tray App Shortcuts Configured as Custom Applications

You can find attached a OS 12 profile with examples of shortcuts for the tray applications available at the time of writing. You can import this profile as described in (12.06.100-en) Exporting and Importing Profiles in the IGEL UMS Web App.

IGEL OS 12 Tray Applications Shortcuts.ipm



The profile comes with shortcuts in the start menu, the desktop and the desktop context menu. The shortcuts use the suitable icon for each app.

How to Create Shortcuts as Custom Application

To create a custom application and configure shortcuts:


- In the profile configurator, go to System > System Customization > Custom Application. For details, see Custom Application in IGEL OS 12 (see page 327).
- 2. Add a new custom application session and give it a name.
- 3. Set the starting methods of the session according to your needs. For example, you can set a shortcut in the desktop context menu. For details, see Starting Methods for Apps (see page 644).
- 3. Under **Settings > Icon large**, set the icon to be displayed for the shortcut.



You can browse icons that are available in the system with the /usr/bin/yad-icon-browser command:

IGEL OS Base System 386 / 647





IGEL OS Base System 387 / 647





4. Under **Settings > Command**, enter the command you would like the custom application to perform.

For example, set igel-system-tray- d input for opening the mouse tray app.

CLI of Tray Applications for Reference

```
igel-system-tray --help
Usage:
  igel-system-tray [OPTION...]
Help Options:
 -h, --help
                             Show help options
 --help-all
                             Show all help options
 --help-gapplication
                             Show GApplication options
                             Show GTK+ Options
  --help-gtk
Application Options:
  -v, --version
                             Print application version and terminate
                             Reload the running system tray
  -r, --reload
  -e, --enable
                             Enable the given tray icon. Currently available: [audio,
mobile_broadband, wifi, lan, battery, rmagent, printer, ums_status]
                             Show dialog. Currently available: [display,
  -d, --dialog
display_advanced, audio, mobile_broadband, wifi, lan, battery, input, printer,
ums_status]
 -m, --monitor-backend
                             Force a specific monitor backend, possible values are:
randr (default), file. Backends can be configured by appending parameters with a ":",
for example file backend needs an input parameter: --monitor-backend=file:input=/tmp/
monitor.json
 -s, --screen
                             Set screen lock state: locked, unlocked
  -V, --verbose
                             Start in verbose mode
  --display=DISPLAY
                             X display to use
```

IGEL OS Base System 388 / 647



Boot Process

The following stages of the boot process are important from a configuration perspective:

- 1. Second stage loader, the loading of the kernel
 - You can access the Boot Menu in this stage. For details, see Boot Menu (see page 390).
 - You can set up Base Custom Commands with specific execution times. For details, see Base (see page 313).
- 2. Network Integration
 - After the kernel has loaded, network configurations are applied. Depending on the settings of the endpoint device, there are three possible ways of integrating the endpoint device into the network environment:
 - DHCP
 - BOOTP
 - Manually configured IP address

The network interface can be stopped and restarted on the Linux Console (accessible via [Ctrl]+[Alt]+[F11]) with this command: /etc/init.d/

network stop /etc/init.d/network start

- 3. Starting the X server and the local windowmanager
 - You can set up Desktop Custom Commands for the stages of the X server launch. For details, see Desktop Custom Commands in IGEL OS 12 (see page 315).

IGEL OS Base System 389 / 647




Boot Menu in IGEL OS 12

During the boot process, a boot menu is available on request. Through this menu, you can start boot modes for troubleshooting. There are modes to access system parameters, or to reset the device to the factory defaults if the device is configured incorrectly or if you experience problems when booting.

→ During the boot process, press the [Esc] key repeatedly in rapid succession in the second stage loader, when the loading kernel message is shown on the screen.

The boot menu is displayed with the available boot modes:



Using the arrow keys, navigate to one of the boot modes and press the [Enter] key to start the process. You can start the following boot modes:

- Quiet boot (see page 391): Normal startup. (Default)
- Verbose boot (see page 391): Start with system messages and an interactive root shell
- VESA only boot (see page 391): Basic graphic boot
- Emergency boot (setup only) (see page 391): Only the Setup window is available
- Failsafe boot with CRC check (see page 392): Start with an integrity check of the operating system
- Reset to factory defaults (see page 392): Reset the client to factory defaults
- Custom boot command (see page 392): Boot with configurable command line options

IGEL OS Base System 390 / 647



Quiet Boot

Quiet boot is the default boot mode. It is the normal startup mode. In this mode, all kernel messages are disabled and the graphical user interface is started.

Verbose Boot

Unlike in **Quiet boot** mode, the kernel messages are shown in **Verbose boot** mode. The boot process also pauses before the graphics system and the user session start.

This gives you an opportunity to open a root shell and interactively execute debugging commands (for example, ifconfig).



Only use the root shell if you have adequate knowledge of Linux or if you are instructed to do so by the IGEL Helpdesk and are given appropriate guidance. Incorrect use can destroy the operating system.

To execute debugging commands:

- 1. Select **Verbose boot** from the boot menu.
- 2. Wait until the boot messages stop at Reached target IGEL Network Online.
- 3. Open a virtual console with one of the key combinations:
 - [Ctrl] + [Alt] + [F11]
 - [Ctrl] + [Alt] + [F12]
- 4. Log in by pressing [Return] and enter the root password if necessary.
- 5. Go through the desired individual commands.
- 6. Now enter the following command to continue the normal boot process: systemctl

default

The graphical user session starts.

VESA Only Boot

Use this boot mode if normal boot has graphic issues, for example, if the device has limited Graphical Processor Unit (GPU) support. This mode is not manufacturer specific. In this mode resolution and multimonitor mode and performance might be limited.

Emergency Boot (Setup Only)

In the **Emergency boot** mode, the device is started without network drivers and with a resolution of 640 x 480 - 60 Hz. After the boot process, the **Setup** window is opened automatically.

This mode is useful, for example, if you have selected an excessively high screen resolution or a wrong mouse type and these settings can no longer be changed in the normal setup. Unlike with a reset, the setup opens with the actual settings.

IGEL OS Base System 391 / 647



→ Once you are done with the changes, close the setup window to reboot the device.

Failsafe Boot with CRC Check

During a **Failsafe boot**, a check of the file system is carried out first. Then, the **Verbose boot** is started.

This mode is helpful if you no longer have a bootable system after a firmware update. The **Failsafe boot** checks where the problem is. If need be, an old version will be booted and you will need to repeat the firmware update.

Reset to Factory Defaults



If you select **Reset to factory defaults**, all personal settings on the device (including your password and the sessions you have configured) will be lost.



You can reset IGEL OS devices to factory defaults through the boot menu, but the best practice is to reset devices using the OSC as descried in How to Deploy IGEL OS 12 with IGEL OS Creator (OSC)⁴⁰. You can also reset your device to factory defaults through the UMS Web App. In this case, the device will be removed from the UMS and you will have to register your device with the UMS again. For details, see How to Reset a Device to Factory Defaults via the IGEL UMS Web App⁴¹.

Before the procedure is carried out, a warning message is displayed. If the device is protected by an administrator password, you will be prompted to enter this password.

If you know the password:

- 1. Confirm the warning message.
- 2. Enter the password. You have three attempts.

If you do not know the password:

- 1. Confirm the warning message.
- 2. When you are prompted to enter the password, press the [Enter] key three times.
- 3. Press [c].
 - The Terminal Key is displayed.
- 4. Contact us at license@igel.com⁴².
- 5. Enter the Terminal Key that is shown, the firmware version, and your contact details. IGEL will send you a Reset to Factory Defaults Key that is specific to your device. To ensure that the process is as straightforward and yet as secure as possible, each key is valid for just one device.

Custom Boot Command

In the **Custom boot command** mode, preconfigured options are placed on the kernel command line. This allows you, for example, to investigate and rectify problems with specific hardware components.

IGEL OS Base System 392 / 647

^{40.} https://kb.igel.com/en/igel-os-base-system/current/how-to-deploy-igel-os-12-with-igel-os-creator-osc

^{41.} https://kb.igel.com/en/universal-management-suite/current/how-to-reset-a-device-to-factory-defaults-via-the-

^{42.} mailto:license@igel.com





🔀 The Custom boot command is merely a temporary solution – it is not an everyday booting method. It must therefore be selected manually in the boot menu.

To configure the options for the **Custom boot command**, proceed as follows:

- 1. Open a local terminal and log in as root.
- 2. Enter the following command to bring up the current options:
 - bootreg get /dev/igfdisk boot_cmd
- 3. Save your desired options with the following command: bootreg set /dev/igfdisk boot_cmd "<Your Options>"
- 4. Check the options that you have entered: bootreg get /dev/igfdisk boot_cmd

if you would like to delete options for the Custom boot command, leave an empty string of characters in their place: bootreg set /dev/igfdisk boot_cmd ""

IGEL Tech Video



Sorry, the widget is not supported in this export. But you can reach it using the following URL:

https://www.youtube.com/watch?v=bpfWNIR6eUE



In the video, IGEL OS11 is used for demonstration.

IGEL OS Base System 393 / 647



Articles on Deploying and Updating IGEL OS 12

- How to Deploy and Use IGEL OS Dual Boot (IGEL Business Continuity & Disaster Recovery) (see page 395)
- Downgrade Limit on IGEL OS 12.7.1 or Higher (see page 407)
- How to Deploy IGEL OS 12 with IGEL OS Creator (OSC) (see page 408)
- How to Deploy IGEL OS 12 with IGEL OS 12 SCCM Add-on (see page 439)
- How to Deploy IGEL OS 12 with IGEL OS Creator for Windows (OSCW) (see page 464)
- How to Deploy IGEL OS 12 with PXE (see page 504)
- How to Use IGEL OS 12 with UD Pocket (see page 515)
- Troubleshooting: SCEP Certificate Renewal Failure due to Hostname Change (see page 522)
- Upgrading from IGEL OS 11 to IGEL OS 12 (see page 524)

IGEL OS Base System 394 / 647



How to Deploy and Use IGEL OS Dual Boot (IGEL Business Continuity & Disaster Recovery)

If Windows becomes unavailable, whether due to a security breach, malware infection, or a system failure, you can quickly boot into IGEL OS and maintain business continuity. IGEL OS Dual Boot also enables testing or evaluation of IGEL OS alongside Windows, without replacing the existing environment.

How IGEL Dual Boot Works

IGEL provides a Windows installer that installs IGEL OS in parallel with Microsoft Windows. The installer reduces the size of the Windows system partition and creates a new partition for IGEL OS. Then it retrieves the initial IGEL OS image from the device's storage, writes it to this partition, and installs an IGEL bootloader. After installation, the user can choose the system to be booted using hotkeys at boot time, or permanently set the default boot entry within Windows through a system tray app.



i IGEL OS should be booted, updated, and tested periodically as part of your BC&DR plan. We recommend working with your assigned TRM to coordinate the process.

Requirements

- You have local administrator rights on the device.
- Windows 11 with EFI Boot is running on the device.
- Minimum of 36 GB of free storage space in the Windows system partition (C:) 20 GB as reserve storage space for Windows + 16 GB for IGEL OS. 128 GB storage space is recommended.
- You have acquired the following software:
 - IGEL OS Dual Boot 1.0 or higher. Please contact your IGEL Representative to get access and
 - The Dual Boot variant of IGEL OS 12.7.2 or higher from https://igel.com/software-downloads > OS 12 Base System Image for Dual Boot.


Installing IGEL OS Dual Boot


Installation via GUI

- 1. Save the installer and the IGEL OS package ZIP file on your Windows device.
- 2. Double-click the installer icon, confirm the dialog **Do you want to allow this app to make changes to your devices?** and accept the license agreement.

395 / 647 **IGEL OS Base System**








IGEL OS Base System 396 / 647






- 3. Provide the following data (some of the files are optional as they can be provided by the UMS after device registration):
 - **Base...**: The ZIP file that contains the Dual Boot variant of IGEL OS, e.g. IGEL_OS_12.7.2_dualboot.zip
 - **Certificates...**: (Optional) One or more certificate files (multiple files can be selected in the file browser). Possible formats: *.crt, *.cer, *.pem
 - **Licenses...**: (Optional) The license file that contains the license for this device, as a plain file or in an archive. Possible formats: *.lic, *.lic.gz
 - **Settings..**: (Optional) The settings file for your device, as a plain file or in an archive. Possible formats: *.ini, *.ini.gz, *.ini.bz
 - **Show IGEL Boot menu**: If enabled, the IGEL Boot menu is shown at the next system start. (Default: enabled)
 - Enable boot-entry check at each startup: If enabled, the correct installation of the IGEL bootloader will be checked on each startup of MS Windows. If necessary, it will be repaired. (Default: enabled)

IGEL OS Base System 397 / 647







4. Click Next.

IGEL OS Base System 398 / 647





IGEL OS Dual Boot installer is installed; afterward, the device boots into IGEL OS.



IGEL OS Base System 399 / 647



You're about to be signed out


The system will restart in 30 seconds to complete IGEL OS Dual Boot installation.

Close



IGEL OS Base System 400 / 647





4. Connect your device to the UMS to integrate it with your environment. For in-depth introductory information, see How to Start with IGEL⁴³

Installation via Command-Line Interface (CLI)

You can install IGEL OS Dual Boot via CLI. The exact syntax depends on whether you are using the EXE file or the MSI installer.

The files to be installed are specified with the following parameters:

- /base path to the ZIP file that contains the IGEL OS Base System. Prefills the corresponding field in the installer GUI
- /certs one or more certificate file paths (semicolon-separated). Populates the Certificates list in the GUI

IGEL OS Base System 401 / 647

^{43.} https://kb.igel.com/en/how-to-start-with-igel/current/



- /licenses one or more license file paths (semicolon-separated). Populates the Licenses list in the GUI
- /settings one or more settings file paths (semicolon-separated). Populates the Settings list in the GUI

To switch off the boot menu, use the following parameter:

• /nobootmenu - prevents the boot menu from being shown at system startup.

To perform a silent installation, which is the preferred option for scripting, use this parameter:

- /silent a dialog is shown, but the installation is performed without user intervention
- /verysilent the installation is performed without user intervention, no dialog is shown

Example using the EXE file:

```
setup-igel-dual-boot_1.0.0.exe /base="C:\temp\base.zip" /certs="C:\
\certs\a.crt;C:\certs\b.crt" /licenses="C:\licenses\l1.lic;C:\
\licenses\l2.lic.gz" /settings="C:\config\s1.ini;C:\config\s2.ini.gz" /
verysilent
```

Example using the MSI installer:

```
setup-igel-dual-boot_1.0.0.msi WRAPPED_ARGUMENTS="/base=""C:\temp\base.zip"" /
certs=""C:\certs\a.crt;C:\certs\b.crt"" /licenses=""C:\licenses\l1.lic;C:
\licenses\l2.lic.gz"" /settings=""C:\config\s1.ini;C:\config\s2.ini.gz"" /
verysilent"
```

Licensing with the Universal Management Suite (UMS)

If you have not included the license files during installation, the licenses must be deployed via the UMS.

If Your IGEL OS Dual Boot Devices Are Connected to a Separate UMS

In this case, you can deploy the licenses you have received with your Business Continuity purchase to all devices of your UMS.

If Your IGEL OS Dual Boot Devices Are Connected to a Productive UMS

In this case, you must define distribution conditions in your UMS to differentiate between the devices already registered in the UMS and those devices that are to receive the licenses from your Business Continuity purchase.

To define the appropriate distribution conditions:

IGEL OS Base System 402 / 647



- 1. Create a view that collects devices whose device name starts with "BC". For details on creating a view, see https://kb.igel.com/en/universal-management-suite/current/how-to-create-a-new-view-in-the-igel-ums.
- 2. Define the distribution conditions for your BC&DR licenses based on the view you have created. For details on defining distribution conditions, see Distributing Licenses to Devices in a Specified View⁴⁴.

Switching IGEL OS at Boot Time

Using the IGEL Boot Menu

When IGEL OS Dual Boot is installed, you can start IGEL OS at boot time using the IGEL Boot Menu. It is available for a short time during device startup. This also applies in the case of an emergency, i.e., if the MS Windows installation has been compromised.

- → Choose the desired operating system from the menu:
 - **Windows (default)**: Please note that the system to be booted next can be defined by the tray app under MS Windows. Also note that the selection made here overrides the setting of the tray app.
 - **OS 12 IGEL OS Dual Boot**: The IGEL OS system that has been installed with the Dual Boot facility is started
 - IGEL OS USB Boot: If an IGEL OS USB Boot stick is inserted into the device, the system located on
 it is started
 - Advanced Options:
 - IGEL OS Verbose boot: See Boot Menu in IGEL OS 1245, section Verbose Boot46
 - IGEL OS VESA only boot: See Boot Menu in IGEL OS 1247, section VESA Only Boot48
 - IGEL OS Emergency boot (setup only): See Boot Menu in IGEL OS 12⁴⁹, section Emergency Boot (Setup Only)⁵⁰

IGEL OS Base System 403 / 647

^{44.} https://kb.igel.com/en/igel-subscription-and-more/current/configuring-the-distribution-conditions#HowtoConfiguretheDistributionConditionsofLicensesinIGEL-DistributingLicensestoDevicesinaSpecifiedViewDistributing-Licenses-to-Devices-in-a-Specified-View

^{45.} https://kb.igel.com/en/igel-os-base-system/current/boot-menu-in-igel-os-12

^{46.} https://kb.igel.com/en/igel-os-base-system/current/boot-menu-in-igel-os-12#id-(12.7.1-en)BootMenuinIGELOS12-VerboseBootVerboseBoot

^{47.} https://kb.igel.com/en/igel-os-base-system/current/boot-menu-in-igel-os-12

^{48.} https://kb.igel.com/en/igel-os-base-system/current/boot-menu-in-igel-os-12#id-(12.7.1-en)BootMenuinIGELOS12-VESAOnlyBootVESABoot

^{49.} https://kb.igel.com/en/igel-os-base-system/current/boot-menu-in-igel-os-12

^{50.} https://kb.igel.com/en/igel-os-base-system/current/boot-menu-in-igel-os-12#id-(12.7.1-en)BootMenuinIGELOS12-EmergencyBoot(SetupOnly)EmergencyBoot





Using a Hotkey

If the IGEL Boot Menu is disabled, you can choose the system to boot.

- → During bootup, press one of the following hotkeys:
 - [+] on the keypad
 - [R]

Changing the Default Operating System via the System Tray App

1. Open the tray app menu and right-click the IGEL OS icon <a> .

IGEL OS Base System 404 / 647






2. Click Configuration Menu.



- 3. Select the desired behaviour on next boot and click **Ok**.
 - Windows: The device will boot into Windows.
 - IGEL OS: The device will boot into IGEL OS.
 - **Show IGEL Boot Menu**: The device will show the IGEL Boot Menu.

IGEL OS Base System 405 / 647





Uninstalling IGEL OS Dual Boot

 $\,\rightarrow\,$ Uninstall IGEL OS Dual Boot like any other program on your device.

When IGEL OS Dual Boot is uninstalled, the device reverts to booting into Windows only, as before. The IGEL OS partition will be deleted, and the 16 GB storage space will be added to the Windows partition again.

IGEL OS Base System 406 / 647



Downgrade Limit on IGEL OS 12.7.1 or Higher

As of IGEL OS 12.7.1, there is a downgrade limit for the IGEL OS Base System app in certain situations. IGEL OS Base System can no longer be downgraded to versions older than 12.7.0. This restriction applies to IGEL UD Pocket⁵¹ devices and endpoints with Secure Boot enabled (see Verifying that Secure Boot is Enabled⁵²). In such cases, downgrade attempts to versions prior to 12.7.0 will be refused to maintain system integrity and boot security.

Known Issues for IGEL OS 12.7.1

• Downgrades to versions prior to 12.7.0 are possible - despite the implemented downgrade limit - via the Local App Portal or using igelpkgctl through local terminal. In UMS-managed environments, disabling the Local App Portal is recommended to enforce the downgrade limit. For how to disable the local app installation, see Installing IGEL OS Apps Locally on the Device⁵³.



If the older shim bootloader signature (in 12.6.1 PR1 or earlier) is revoked and Secure Boot is enabled, the device may become unbootable. Verify boot compatibility before downgrading.

IGEL OS Base System 407 / 647

^{51.} https://kb.igel.com/hardware/current/ud-pocket-powered-by-igel-ud-pocket-products

^{52.} https://kb.igel.com/security-safety/current/verifying-that-secure-boot-is-enabled

^{53.} https://kb.igel.com/en/how-to-start-with-igel/current/installing-igel-os-apps-locally-on-the-device



How to Deploy IGEL OS 12 with IGEL OS Creator (OSC)

With the IGEL OS Creator (OSC), you can install IGEL OS 12 on any supporting device. Moreover, you can use the IGEL OS Creator to recover a broken installation of IGEL OS that cannot boot anymore.



Installing the IGEL OS operating system via OSC destroys all data on the target device's mass storage device (hard disk, flash memory, SSD).

Devices Supported by IGEL OS 12

For a detailed list, see Devices Supported by IGEL OS 12.

Licensing

For information on licensing, see Essential IGEL Licensing FAQ.

Create USB Installation Medium

Windows

- 1. Download the ZIP archive for OS Creator from the IGEL Download Server⁵⁴.
- 2. Unzip the contents into a local directory.
- 3. Connect a USB memory stick with at least 4 GB capacity to the computer. All existing data on the USB memory stick will be destroyed.
- 4. Double-click the preparestick.exe file from the unzipped directory.


If you are in the "administrators" group, the program will start after you have confirmed a dialog. If you are not in the "administrators" group, you must enter the administrator password to start the program.

The dropdown menu **Isofile** shows the ISO file contained in the unzipped directory, e.g. osc12.01.110.iso.

IGEL OS Base System 408 / 647

^{54.} https://www.igel.com/software-downloads/igel-os-12-secure-endpoint/






5. Under **Destination USB stick**, select the USB storage medium on which you would like to save the installation data.

It is recommended that you only have one USB storage medium connected during this procedure. If you accidentally select the wrong medium, all data on it will be lost.

Generally speaking, the list of available USB storage media is refreshed automatically. If, however, you would like to refresh it manually, click on **View > Refresh USB Device List**.


IGEL OS Base System 409 / 647





6. Click Start writing process.


7. Confirm the following dialog:




In the program window, the progress of the process is shown.

IGEL OS Base System 410 / 647





When the process is finished, a message window is displayed.



- 8. Close the message window and the program.
- 9. After about 3 seconds, remove the USB memory stick.



If you remove the USB memory stick too early, the writing process may still need to be completed. In this case, the data on the memory stick gets corrupted.

The USB memory stick for OSC installation is ready for use.

Linux

- 1. Download the ZIP archive for OS Creator from https://www.igel.com/software-downloads/.
- 2. Unzip the contents into a local directory.
- 3. You will need the ISO file (e.g., osc12.4.1.iso) from this directory to create a bootable medium.
- 4. Connect a USB memory stick with at least 4 GB capacity to the computer.

IGEL OS Base System 411 / 647



All existing data on the USB memory stick will be destroyed.

5. Open a terminal emulator and enter the command dmesg to determine the device name of the USB memory stick.

Example output:

```
[\ldots]
[19514.742229] scsi 3:0:0:0: Direct-Access JetFlash Transcend 8GB
1100 PQ: 0 ANSI: 6
[19514.742805] sd 3:0:0:0: Attached scsi generic sg1 type 0
[19514.744688] sd 3:0:0:0: [sdb] 15425536 512-byte logical blocks:
(7.89 \text{ GB}/7.35 \text{ GiB})
[19514.745370] sd 3:0:0:0: [sdb] Write Protect is off
[19514.745376] sd 3:0:0:0: [sdb] Mode Sense: 43 (0) 00 00 00
[19514.746040] sd 3:0:0:0: [sdb] Write cache: enabled, read cache:
enabled, doesn't support DPO or FUA
[19514.752438] sdb: sdb1
```

In this example, the device name searched for is /dev/sdb.



Ensure that you have determined the correct device name. If you use the wrong device name, the dd command in the next step can destroy your operating system.

- 6. The following command writes the installation data to the USB memory stick (example): dd if=osc12.4.1.iso of=/dev/sdX bs=1M oflag=direct Replace sdX with the device name of the USB memory stick that you have determined. When the dd command has terminated, you can see the terminal emulator input prompt again.
- 7. Wait for about 3 seconds after the dd command has terminated, and remove the USB memory stick.



If you remove the USB memory stick too early, the writing process may still need to be completed. In this case, the data on the memory stick gets corrupted.

The USB memory stick for OSC installation is ready for use.

IGEL OS Base System 412 / 647



Create DVD Installation Medium

The ISO file in the installation directory for OSC is a so-called hybrid image. It can not only be copied onto USB storage devices but can also be used to create a bootable DVD.

Burn ISO Image (Windows)

- 1. In Explorer, open the directory that contains the ISO file.
- 2. Right-click on the ISO file.
- 3. Select Burn disc image.

Burn ISO Image (Linux)

Under Linux, various burning programs with a graphical user interface or for the command line are available.

The Ubuntu Wiki⁵⁵ explains how to burn an ISO image onto a DVD using several programs.

Boot Settings

OSC works on systems with BIOS and UEFI.

Your system must support booting from USB storage media or from a DVD. This may already be enabled, or you may have to enable it yourself.



IGEL OS 12 supports UEFI Secure Boot. Refer to the manual of your device's manufacturer to learn whether your device supports Secure Boot and how to enable it. Enabling Secure Boot often consists of two steps. First, the boot mode has to be changed to UEFI Boot in the BIOS; after that, Secure Boot can be activated, also in the BIOS. For instructions on how to check whether Secure Boot has been properly enabled, see(en) Verifying that Secure Boot is Enabled.

For UEFI Secure Boot on devices manufactured by IGEL, see (en) UEFI Secure Boot Enabling Guides.




If IGEL OS fails to boot in UEFI mode, try switching to **Force Legacy (non UEFI) boot**. IGEL OS will then be installed in legacy/BIOS mode.

IGEL OS Base System 413 / 647

^{55.} https://help.ubuntu.com/community/BurningIsoHowto#Burning_from_Ubuntu





General Hints on Changing the Boot Settings

The required key presses for this may vary from vendor to vendor. However, here are some hints:

- → While the device is booting, try pressing [F12] (in general), [F10] (Intel devices), or [F9] (Hewlett-Packard devices) to access a list of boot devices and select your USB installation medium.
- → If the above does not work, access the BIOS settings via pressing [Del], [F1], or [F2] during boot, activate booting from USB storage media and/or change the boot order.
- → See the BIOS/UEFI documentation for your system for details of how to boot from USB storage media.

Changing the Boot Settings of Devices Manufactured by IGEL



If the USB installation medium is not found, though the USB boot is enabled, try the following:

- Reconnect the USB installation medium and reboot the endpoint device.
- Use another USB port.

UD7 (H860C)

- 1. Power up the device while pressing the [Del] button repeatedly in rapid succession.
- 2. If a password prompt is shown, enter the BIOS password.
- 3. Select Setup Utility.
- 4. Select the **Boot** tab.

IGEL OS Base System 414 / 647



- 5. Set **USB Boot** to **<ENABLED>**.
- 6. Save the settings and exit.
- 7. Connect the USB stick to the device.
- 8. Reboot the device while pressing the [Del] button repeatedly in rapid succession.
- 9. Select **Boot Manager**.
- 10. Select the USB stick as the boot medium and press **Enter**.
- 11. You can continue with the installation procedure.

UD3 (M350C)

- 1. Power up the device while pressing the [Del] button repeatedly in rapid succession.
- 2. If a password prompt is shown, enter the BIOS password.
- 3. Select Setup Utility.
- 4. Select the **Boot** tab.
- 5. Set **USB Boot** to **<ENABLED>**.
- 6. Save the settings and exit.
- 7. Connect the USB stick to the device.
- 8. Reboot the device while pressing the [Del] button repeatedly in rapid succession.
- 9. Select **Boot Manager**.
- 10. Select the USB stick as the boot medium and press Enter.
- 11. You can continue with the installation procedure.

Installation Procedure



The installation will overwrite all existing data on the target drive.

- 1. Connect the prepared USB memory stick to the target device and switch the target device on.
- 2. Select one of the following options from the boot menu:

IGEL OS Base System 415 / 647






- **Standard Installation + Recovery**: Boots the system with just a few messages from the USB memory stick and launches the installation program. (Default)
- Verbose Installation + Recovery: Boots the system from the USB memory stick and shows the Linux boot messages. You can use a USB serial adapter for debugging purposes. For this purpose, the Registry key system.kernel.bootparams.serial_console_debug must be enabled (path: System > Registry > system > kernel > bootparams > serial_console_debug > Enable debug console). The serial port parameters are as follows: 115200 baud, 8 bits, 1 stop bit, no parity, no flow control.
- Failsafe Installation + Recovery: Fallback mode; to be used if the graphical boot screen cannot be displayed.
- **Memory Test**: Memory test, only available in legacy/BIOS mode. This option does not carry out an installation.
- 3. Select the language for the installation process.

IGEL OS Base System 416 / 647






4. If IGEL OS 12 has been running on the device before and you want to preserve the device's settings, ensure that **Migrate old settings** is enabled.




- 5. If one of the following is the case, make sure that **Migrate licenses** is enabled:
 - Your device has been operating with IGEL OS 11 before and you want to preserve the device's IGEL OS 11 licenses because you want to test IGEL OS 12 and downgrade to IGEL OS 11 afterward
 - Your device has been operating with IGEL OS 12 before and you want to keep the licenses on the device

IGEL OS Base System 417 / 647






6. Check the **Target drive** to ensure that the system is installed on the desired drive.




7. Click Install IGEL OS.

IGEL OS Base System 418 / 647






8. Accept the **EULA** by clicking **I agree**.



IGEL OS Base System 419 / 647




9. To view the details for the target drive, click **More Info**.




10. Click Install IGEL OS.

IGEL OS Base System 420 / 647






The installation program will install IGEL OS 12 on the target drive. If you see the success message, the installation is complete.



IGEL OS Base System 421 / 647




11. Click Reboot.



12. Remove the USB memory stick.

13. Close the message window.



The system will shut down and then boot IGEL OS 12.

The device is ready for onboarding; for details, see Onboarding IGEL OS 12 Devices⁵⁶.

IGEL OS Base System 422 / 647

^{56.} https://kb.igel.com/en/how-to-start-with-igel/current/onboarding-igel-os-12-devices



Installation Procedure for Factory Images




The installation will overwrite all existing data on the target drive.

Preparing the Image

1. Connect the prepared USB memory stick to the target device and switch on the target device.

2. Select **Standard Installation + Recovery** or **Verbose Installation + Recovery**.



3. Select the language for the installation process.


423 / 647 IGEL OS Base System






The installation program **IGEL OS Creator** opens. Here, you can configure settings for the installation process and start it.

4. Activate **Factory Image** and enter your factory ID.




IGEL OS Base System 424 / 647






5. Check the **Target drive** to ensure that the system is installed on the desired drive.



6. If you want to change the initial settings for the devices you are about to deploy, click **Edit**.


IGEL OS Base System 425 / 647





The IGEL Setup opens, enabling you to change the settings in the same way as with a regular IGEL OS installation. The changes are stored on the USB memory stick from which the IGEL OS Creator (OSC) is executed. For details about the settings, see Configuration of IGEL OS 12 Device


Settings (see page 6).



7. If you want to undo your changes and restore the original settings, click **Reset**.

IGEL OS Base System 426 / 647






8. If you want to perform manual tests with visual feedback on each device, enable **Enable Reset** after first boot. The test procedure is described under Unit Testing (see page 435).



If **Reset after first boot** is activated, the first boot of your devices MUST take place BEFORE shipment to end customers!

IGEL OS Base System 427 / 647






9. If you want to perform automatic tests (unattended), enable both **Reset after first boot** and **Enable Reset after first boot**. The test procedure is described under Automatic Unit Testing (see page 436).



If **Reset after first boot** is activated, the first boot of your devices MUST take place BEFORE shipment to end customers!

IGEL OS Base System 428 / 647






9. To start the installation, click **Install IGEL OS**.

IGEL OS Base System 429 / 647






10. Confirm the warning dialog.

IGEL OS Base System 430 / 647






The installation of IGEL OS 12 starts.

IGEL OS Base System 431 / 647






The installation program will set up IGEL OS 11 on the target drive. If you see the success message, the installation is complete.

IGEL OS Base System 432 / 647






11. Click Shutdown.

IGEL OS Base System 433 / 647





12. Read out the image from your device to deploy it on the units.



DO NOT BOOT THE EXACT FACTORY IMAGE THAT IS INTENDED FOR DEPLOYMENT ON YOUR DEVICES! ALL DEVICES TO WHICH THIS IMAGE HAS BEEN DEPLOYED WOULD SHARE ONE AND THE SAME UNIT ID. AS A RESULT, YOUR DEVICES WOULD BE PRACTICALLY UNUSABLE.

If you want to test the factory image before its deployment, transfer it to your target medium first and then boot the image on the machine on which you created it, or any other test machine. The important thing is that the factory image that will be mass-deployed to your units has not been booted before.



The maximum size of the image created by the IGEL OS Creator (OSC) is 64 GiB. Therefore, only the first 64 GiB of your storage medium is needed. If your devices have larger storage, this will allow for faster deployment.

- 13. To ensure the integrity of the image, you should create checksums of the original image and the deployed images and then compare them. For details, see IGEL Endpoint Partners: Ensuring Image Integrity with a Checksum⁵⁷.
- 14. Proceed as appropriate:

IGEL OS Base System 434 / 647

^{57.} https://kb.igel.com/en/igel-os/11.10.250/igel-endpoint-partners-ensuring-image-integrity-wi



- If **Reset after first boot** is inactive, you can deploy the images on the units and roll them out straight away. The deployment should include a comparison of the checksums.
- If **Reset after first boot** has been activated, deploy the images on the units and continue with Unit Testing (see page 435).
- If Automatically shutdown at first boot has been activated, deploy the images on the units and continue with Automatic Unit Testing (see page 436).


Unit Testing

Perform the following procedure on the original device and every unit on which the image has been deployed.



The first boot test MUST take place with each unit BEFORE it is rolled out. (Otherwise, the device would present the green test screen on the first boot instead of the IGEL Setup Assistant.)

1. Start the device and review the green test screen.



2. Click OK.

You can access IGEL OS in a regular way and perform your tests.

3. Shut the device down.

The device is ready for roll-out.

IGEL OS Base System 435 / 647




Automatic Unit Testing

When **Reset after first boot** and **Automatically shutdown at first boot** has been enabled, the device writes a log file on its first boot and then shuts down automatically.

Your test routine must perform the following procedure:

1. Start the device.

The device will perform a check and write the results to a file on the first VFAT partition of the device's storage medium. The file format is JSON, and the file name is check.log. After a few seconds, the machine shuts down automatically. During the uptime, the green test screen is shown.



2. Get the file check.log from the first VFAT partition of the storage medium and analyze it. The contents of the file are described below.

Example Content of check.log

```
{
    "product": "Standard PC",
    "serial": "12345678",
    "product_id": "UC1-LX",
```

IGEL OS Base System 436 / 647



```
"version": "12.4.1",
  "bootmode": "UEFI Secure Boot",
  "flashsize": "7688 MB",
  "date": "2024-09-26, 08:08 AM",
  "status": "SUCCESS",
  "log": ""
}
```

Explanation of the JSON Fields

	Explanation		
product	Product id from DMI		
serial	Serial number from DMI		
product_	The IGEL product ID. This value is also shown in the About window:		
id	Product		
	Copyright	IGEL Technology GmbH	
	IGEL OS Build Date	Freitag, 31. Mai 2024	
	_IGEL OS Version	12.4.1	
	Product ID	UC1-LX	
	Product Name	IGEL OS 12	
	Website	https://www.igel.com	
version	The version of the IGEL OS Base System. This value is also shown in the About window:		
	Product		
	Product Copyright	IGEL Technology GmbH	
		IGEL Technology GmbH Freitag, 31. Mai 2024	
	Copyright	**	
	Copyright IGEL OS Build Date	Freitag, 31. Mai 2024	
	Copyright IGEL OS Build Date IGEL OS Version	Freitag, 31. Mai 2024 12.4.1	

IGEL OS Base System 437 / 647



Field	Explanation		
bootmode	The boot mode: Legacy, UEFI, or UEFI Secure Boot. This value is also		
	shown in the About window:		
	Hardware		
	Boot Mode	UEFI	
	CPU Model	Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs)	
	Device Type	Legacy x86 System	
	Flash Size	15970 MB	
	Graphics Chipset	VMware Inc. Abstract VGA II Adapter	
	Memory Size	5915 MB	
	Total Operating Time	416 days 11 hours	
	Unit ID	AUTO-DATA SANDON	
flashsiz	· ·	not the complete available disk space). This value is	
flashsiz e	The size of the IGEL partition (also shown in the About wind	•	
	also shown in the About wind	•	
	also shown in the About wind Hardware Boot Mode CPU Model	UEFI Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs)	
	also shown in the About wind Hardware Boot Mode CPU Model Device Type	UEFI Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs) Legacy x86 System	
	also shown in the About wind Hardware Boot Mode CPU Model Device Type Flash Size	UEFI Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs) Legacy x86 System 15970 MB	
	also shown in the About wind Hardware Boot Mode CPU Model Device Type Flash Size Grapnics Cnipset	UEFI Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs) Legacy x86 System 15970 MB VMware Inc. Abstract VGA II Adapter	
	also shown in the About wind Hardware Boot Mode CPU Model Device Type Flash Size Graphics Chipset Memory Size	UEFI Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs) Legacy x86 System 15970 MB VMware Inc. Abstract VGA II Adapter 5915 MB	
	also shown in the About wind Hardware Boot Mode CPU Model Device Type Flash Size Graphics Chipset Memory Size Total Operating Time	UEFI Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs) Legacy x86 System 15970 MB VMware Inc. Abstract VGA II Adapter 5915 MB 416 days 11 hours	
	also shown in the About wind Hardware Boot Mode CPU Model Device Type Flash Size Graphics Chipset Memory Size	UEFI Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs) Legacy x86 System 15970 MB VMware Inc. Abstract VGA II Adapter 5915 MB	
	also shown in the About wind Hardware Boot Mode CPU Model Device Type Flash Size Graphics Chipset Memory Size Total Operating Time	UEFI Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs) Legacy x86 System 15970 MB VMware Inc. Abstract VGA II Adapter 5915 MB 416 days 11 hours	
e	also shown in the About wind Hardware Boot Mode CPU Model Device Type Flash Size Grapnics Cnipset Memory Size Total Operating Time Unit ID	UEFI Intel(R) Xeon(R) Gold 6354 CPU @ 3.00GHz (2 CPUs) Legacy x86 System 15970 MB VMware Inc. Abstract VGA II Adapter 5915 MB 416 days 11 hours 005056934909	

IGEL OS Base System 438 / 647



How to Deploy IGEL OS 12 with IGEL OS 12 SCCM Add-on

IGEL OS 12 SCCM Add-on facilitates deploying IGEL OS via Microsoft SCCM. The package contains IGEL OS Base System as a dd image that will be booted using a Windows PE boot file customized for this purpose.

Optionally, you can use a different version of IGEL OS Base System, add certificates and license files, and compress the image file; for details, see Alternative Deployment (see page 457). Moreover, you can choose whether you want to deploy the IGEL OS dd image together with the Windows PE boot image as one single file or separately via a network share.

With the installation of IGEL OS SCCM Add-on, a customized Windows PE image and a task sequence for deploying IGEL OS are created, and the IGEL OS Image Manager is installed.

This article is based on version 2.2.0 of IGEL OS 12 SCCM Add-on; the supplied version of IGEL OS Base System is 12.3.1. For details on this version, see the Readme_2.2.0.txt.

Prerequisites

 Microsoft Endpoint Configuration Manager (see https://docs.microsoft.com/en-us/mem/ configmgr/)



i The solution presented here has been developed and tested with the current version of Microsoft Endpoint Configuration Manager (status 01/2024). For details on the versioning of Microsoft Endpoint Configuration Manager, see https://docs.microsoft.com/en-us/mem/configmgr/core/plan-design/changes/whats-newincremental-versions.


- Configured PXE environment for OS deployment; all target devices must be in a network where they are available either from the main site server or a distribution point. (For further information, see https://docs.microsoft.com/en-us/mem/configmgr/osd/plan-design/infrastructurerequirements-for-operating-system-deployment)
- All target devices have a minimum of 4 GB RAM.
- On the host on which Microsoft Endpoint Configuration Manager is running, Microsoft Power Shell Script execution must be allowed, at least for signed scripts (the Powershell scripts that come with IGEL OS SCCM Add-on are signed by IGEL).

Installing IGEL OS SCCM Add-On

- 1. Go to https://www.igel.com/software-downloads/cosmos/ > OS 12 Base System Deployment Tool for SCCM and download the executable file to the host on which Microsoft Endpoint Configuration Manager is running.
- 2. Start the executable file.
- 3. Accept the EULA and click **Next**.

439 / 647 **IGEL OS Base System**






4. On the **Site Server configuration** page, review the field **Site Server Name (FQDN)**, which should be prefilled, and enter the **Site Code** of this Endpoint Configuration Manager site. Then, click **Next**.

IGEL OS Base System 440 / 647






5. If you plan to deploy the IGEL OS image separately via a network share, i.e., not embedded in the boot file, enter the shared **Network folder** containing the IGEL OS image and the corresponding **Username**. Then, click **Next**.

IGEL OS Base System 441 / 647






The installation of IGEL OS SCCM Add-on starts.

IGEL OS Base System 442 / 647






Verifying the Installation

1. Under Software Library, select **Operating Systems > Boot Images** and check if the **IGEL Boot Image** (WIM) is available.

IGEL OS Base System 443 / 647






2. Go to **Task Sequences** and check if **IGEL Create**, **IGEL Create over Net**, and **IGEL Inplace Upgrade** are available. These task sequences will drive and control the deployment process.

IGEL OS Base System 444 / 647





Provisioning IGEL OS via a PXE Boot Environment

The task sequences provided by IGEL OS SCCM Add-on will deploy IGEL OS to a device collection via a PXE boot environment. The task sequence will be executed after the device has booted into the IGEL Boot Image (igel.wim).

You can choose between the following task sequences:


- **IGEL Create**: The IGEL OS image (minimal.bin) is built into the IGEL Boot Image (igel.wim)
- **IGEL Create over Net**: IGEL OS image (minimal.bin) is provided separately via a network share

To deploy the PXE boot environment:

- 1. Check if you need to define your own custom device collection to allocate your target devices or if you can use one of the preconfigured collections.
- 2. Under **Software Library**, select **Operating Systems > Boot Images**. Open the context menu for **IGEL Boot Image** and select **Distribute content**.
- 3. Open the **Distribute Content Wizard** and check if **IGEL Boot Image** is shown in the **Content** area. Afterward, continue with the wizard.

IGEL OS Base System 445 / 647






4. If your device requires a specific network driver: Select **Operating Systems > Boot Images**, Open the context menu for **IGEL Boot Image**, and select **Properties**. Then, select the **Drivers** tab and add the driver.

IGEL OS Base System 446 / 647






5. Select **Operating Systems > Boot Images**, Open the context menu for **IGEL Boot Image** and select **Update distribution points**.


IGEL OS Base System 447 / 647





IGEL OS Base System 448 / 647






6. If you want to deploy the IGEL OS image separately via a network share: Select **Operating**Systems > Task Sequences, open the context menu for IGEL Create over Net, and then select

Edit. Otherwise, continue with step 8.

IGEL OS Base System 449 / 647






- 7. If you want to deploy the IGEL OS image separately via a network share (continued): Edit the settings for the task **Connect to Network Folder** as follows:
 - **Path**: Enter the path to the network share you want to use for distributing the IGEL OS image.
 - Account: Click **Set** to open the account data dialog and enter the required data:
 - User name: The username for accessing the network share, in the format DOMAIN\user
 - **Password** / **Confirm password**: The password for accessing the network share

IGEL OS Base System 450 / 647






8. Select Operating Systems > Task Sequences, open the context menu for IGEL Create or IGEL Create over Net, and then select Deploy.

IGEL OS Base System 451 / 647






The **Deploy Software Wizard** opens.

9. Click the **Browse** button next to **Collection:**.

IGEL OS Base System 452 / 647






The **Select Collection** dialog opens.

10. From the list of collections, select the collection that contains your target devices and click **OK**.

IGEL OS Base System 453 / 647






In our example, a user-created collection named **IGEL OS Collection** is selected.

11. Click **Next** to continue with the wizard.

IGEL OS Base System 454 / 647






All target devices receive the PXE boot request that triggers them to boot the IGEL Boot Image.

IGEL OS Base System 455 / 647






The target devices load the IGEL Boot Image (WIM).

IGEL OS Base System 456 / 647





Alternative Deployment


You can deploy a different IGEL OS image as an alternative to the image that comes with IGEL OS SCCM Add-on. The current main version is available from igel.com⁵⁸. Optionally, you can add pre-configured settings, certificates, and license files to the image. In addition, you can compress the image to reduce the network load during distribution; please note that this increases the processing effort on the endpoint's side because the image needs to be decompressed.

- Open a web browser, go to https://www.igel.com/software-downloads/cosmos/ > OS 12 Base System Deployment Tool for SCCM, download the current IGEL OS file, and unzip it. The IGEL OS image is ready for deployment.
- 2. Start the IGEL OS Image Manager by clicking on the desktop icon.
- 3. Click **Select** next to **Select IGEL OS bin file** and choose your image file.

58. http://igel.com

IGEL OS Base System 457 / 647






- 4. If you want to add settings, certificates, or license files, click **Add** next to the relevant item and choose the relevant files.
 - Add IGEL OS settings: The settings for IGEL OS. These settings can also be configured via the local Setup, the UMS device configurator, or a UMS profile.
 - Add certificate: Certificate files
 - Add IGEL licenses: License files

IGEL OS Base System 458 / 647






- 5. Set **Update SCCM IGEL Boot Image** according to your deployment method:
 - **NO**: Select this option if you want to modify only the IGEL OS image, but not the IGEL OS boot image (Windows PE).
 - **COPY**: Select this option if you want to deploy the IGEL OS image together with the basic Windows PE boot image. The Windows PE boot image and the IGEL OS image will be baked into one file which is distributed by the Microsoft Endpoint Configuration Manager.
 - **DELETE**: Select this option if you want to deploy the IGEL OS image separately via a network share. Only the basic Windows PE boot image will be distributed by the Microsoft Endpoint Configuration Manager; at a later stage, the devices will fetch the IGEL OS image from the network share.

IGEL OS Base System 459 / 647






6. If you want to compress the IGEL OS image, enable **Compress IGEL OS bin file**.

IGEL OS Base System 460 / 647






7. When you have chosen your files, click **Apply**.

IGEL OS Base System 461 / 647






The files are added to the image.

IGEL OS Base System 462 / 647





IGEL OS Base System 463 / 647



How to Deploy IGEL OS 12 with IGEL OS Creator for Windows (OSCW)

The IGEL OS Creator for Windows (OSCW) is able to convert Windows machines to IGEL OS 12, provided that they fulfill the hardware requirements.



On modern computers such as secured-core PCs (see e.g. https://www.microsoft.com/en-us/windows/ business/devices?col=secured-core-pcs), there may be a BIOS setting related to Secure Boot that allows the use of Microsoft's 3rd party UEFI Secure Boot Certificate. The usual description of such a BIOS setting is "Allow Microsoft 3rd Party UEFI CA". This setting must be set to enabled, as IGEL uses the 3rd party certificate to support UEFI Secure Boot. If UEFI Secure Boot is enabled, but "Allow Microsoft 3rd Party UEFI CA" is not enabled, you may be unable to boot IGEL OS Creator or UD Pocket. Similarly, if the setting "Allow Microsoft 3rd Party UEFI CA" is disabled after a previous installation of IGEL OS, IGEL OS will fail to boot. For how to enable the setting, see (en) Secured-Core PCs: Microsoft 3rd-Party UEFI Certificate for Secure Boot.

Choose the instructions according to your needs:

• IGEL OS Creator for Windows (OSCW) for IGEL OS 12 on Windows 11/10 Workstations (see page 465)

464 / 647 **IGEL OS Base System**



IGEL OS Creator for Windows (OSCW) for IGEL OS 12 on Windows 11/10 Workstations

Introduction

The IGEL OS Creator (OSC) for Windows is able to convert any Windows 11 or Windows 10 machine to IGEL OS 12, provided that it fulfills the hardware requirements, see IGEL OS 12 Hardware Support.

Read all the following chapters and follow the instructions in the order given.

Prerequisites

Hardware

• For supported hardware, see IGEL OS 12 Hardware Support.

Software

The following software and configuration must be present on the target machines:

- Windows 11 or Windows 10 (32 Bit or 54 Bit)
- Microsoft Bitlocker is disabled

Network

- All machines are in a network that can be reached by the UMS.
- For buddy mode: All machines must be joined to a Microsoft Active Directory (AD) and be accessible by the same AD user with reading permissions.

Getting the Required Software

The following software must be downloaded resp. installed:

IGEL Universal Management Suite (UMS) 12.01.100 or Higher

- 1. Download UMS 12.01.120 or higher from https://www.igel.com/software-downloads/igel-os-12-secure-endpoint/ > Universal Management Suite 12.
- 2. Update your UMS to version 12.01.120 or later resp. install UMS 12.01.120. For update instructions, see IGEL UMS Update; for installation instructions, see IGEL UMS Installation.

OSCW Files

- 1. Download OSC for Windows 1.01.100 or higher (EXE or MSI installer)
 - EXE file: https://www.igel.com/software-downloads/igel-os-12-secure-endpoint/ > OS
 Creator for Windows > setup-igel-osc-for-windows_<VERSION>.exe

IGEL OS Base System 465 / 647



- MSI file: https://www.igel.com/software-downloads/igel-os-12-secure-endpoint/ > OS
 Creator for Windows > setup-igel-osc-for-windows_<VERSION>.msi
- 2. Download IGEL OS 12.4.1 or higher (ISO): https://www.igel.com/software-downloads/igel-os-12-secure-endpoint/ > OS Creator (Deployment Tool (USB) for IGEL OS 12) > osc<VERSION>.zip

Check List

- ▼ The UMS is updated to version 12.01.120 or higher.
- OSC for Windows 2.1.0 or higher is available.
- ☑ IGEL OS 12.4.1 or higher (ISO file) is available.

Transferring the IGEL OSC File to the UMS

In this step, we will transfer the IGEL OS firmware file (ISO) to the UMS so that the UMS can deploy it to the target machines.



Do not register the file as a file object. This might lead to various issues, particularly in ICG and HA environments.

- 1. Get access to the file system of the machine on which your UMS Server is running.
- 2.Copy osc-<version>.iso to <UMS Installation
 directory>\rmguiserver\webapps\ums_filetransfer

Deploying the OSCW Installer on the Target Machines

In this step, we will deploy the OSCW installer on the target machines.

Deploy the installer on all devices that are to be converted. The following methods are available for deployment:

- SCCM (System Center Configuration Manager):
 - → Use the MSI installer (e.g. setup-igel-osc-for-windows_<VERSION>.msi) and deploy it just like any software. The OSCW installer is installed silently.
- Group policy:
 - → Use the MSI installer (e.g. setup-igel-osc-for-windows_<VERSION>.msi) and deploy it just like any software. The OSCW installer is installed silently.
- File-based methods:
 - → Transfer the EXE file (e. g. setup-igel-osc-for-windows_<VERSION>.exe) to your target machines and install it on each machine; see Installing the OSCW Installer from a File (see page 467).

You can use file sources such as:

• USB memory stick

IGEL OS Base System 466 / 647




- Network drive
- DVD

Installing the OSCW Installer from a File

On the target machine, double-click setup-igel-osc-for-windows_<VERSION>.exe and confirm the Windows UAC (user account control). The OSCW installer is digitally signed by "IGEL Technology GmbH".
 The setup wizard opens.


2. Read the licence agreement, accept it and click Next.



3. Click **Next** to install IGEL OS Creator for Windows on your device.

IGEL OS Base System 467 / 647





Check List

The OSCW installer is installed on each target machine.

Registering the Target Machines to the UMS

In this step, we will register all target machines to the UMS. This is necessary because the conversion to IGEL OS will be triggered by the UMS.

Two registration methods are available: a scan by the UMS and automatic registration.

- Registering by a UMS Scan (see page 468)
- Registering by Automatic Registration (see page 470)

Registering by a UMS Scan


- 1. Open the UMS Console and click to scan for devices.
- 2. Select the scope in which the devices are located; for details, see (12.04.120) How to Scan the Network for Devices and Register Devices on the IGEL UMS.
- 3. Click **Scan**. The dialog **Found devices** opens.
- 4. In the Filter field, enter "IGEL Unified Management Agent OSCW".

IGEL OS Base System 468 / 647





5. Select all target machines and click **Ok**.




The target machines are registered with the UMS.

6. In the **Result** dialog, click **Ok**.

IGEL OS Base System 469 / 647





Registering by Automatic Registration

For this method, a DNS entry or DHCP option must be set.

→ Follow the instructions in (12.04.120) Registering Devices Automatically on the IGEL UMS.

Check List

All target machines are registered with the UMS.

Configuring the OSCW Installer

In this step, we will provide the OSCW installer with the download source for the ISO file that contains the IGEL OS Creator.

Two methods are available:

• Configuring the OSCW Installer in Normal Mode (see page 471): Each target machine individually downloads the ISO file from the server (UMS). This increases the amount of outgoing traffic from the UMS.

IGEL OS Base System 470 / 647



• Configuring the OSCW Installer in Buddy Mode: This method is recommended if the connection bandwidth of the download source is limited; it ensures a more balanced use of network bandwidth during the distribution of the ISO file to the target machines. First, a group of target machines downloads the ISO file. Then, these machines serve as the download source ("update buddies") for the remaining target machines. As a requirement, all devices must be joined to a Microsoft Active Directory (AD) and be accessible by the same AD user with reading permissions.

Configuring the OSCW Installer in Normal Mode


To provide the OSCW installer with the download source for the IGEL OS Creator file (ISO), we will create a profile that provides the path to that file. To assign the profile to the target machines, we will use a view that recognizes the target machines by their product ID.

The configuration comprises the following steps:

- Creating a Profile (see page 471)
- Creating a View to Select All Target Machines (see page 473)
- Assigning the Profile to the Target Machines (see page 478)
- Monitoring the Process (see page 480)

Creating a Profile


1. In the structure tree of the UMS Console, go to **Profiles** and open **New Profile** in the context menu.



- 2. In the **New Profile** dialog, change the settings as follows and confirm with **Ok**.
 - Profile Name: A name for the profile, e. g. "IGEL OS Creator for Windows configuration"
 - Based on: Select "IGEL Unified Management Agent < VERSION>".


IGEL OS Base System 471 / 647





The configuration dialog opens.

3. Click Converter.



You are taken to **System > OSC > Converter** where you can set all relevant parameters.

- 4. Change the settings as follows (click the icon to enable the configuration; the icon will change to icon):
 - Download URL of IGEL OS Creator: Enter https://[IP address of your UMS Server]:8443/ums_filetransfer/or http://[IP address of your UMS

IGEL OS Base System 472 / 647




Server]:9080/ums_filetransfer/

Example: https://192.168.178.100:8443/ums_filetransfer/ or http://
192.168.178.100:9080/ums_filetransfer/

• Username: Enter the username for the UMS.

• Password: Enter the password for the UMS user.



5. Click Save.


Creating a View to Select All Target Machines

The target machines must be selected to assign the profile to them. For the selection, a view will be used.


1. In the structure tree of the UMS Console, go to **Views** and select **New View** in the context menu.

IGEL OS Base System 473 / 647






2. Enter a name for the view, e.g. "IGEL OS Creator for Windows - target machines" and click **Next**.



IGEL OS Base System 474 / 647




3. On the **Select criterion** page, select **Product ID** and click **Next**.



4. On the **Text search** page, enter "OSCW" and click **Next**.

IGEL OS Base System 475 / 647






5. On the **Create new view** page, click **Finish**.

IGEL OS Base System 476 / 647





The number of matches is shown.


6. Click **Load devices** to view the target machines.



7. The target machines are shown.


IGEL OS Base System 477 / 647





Assigning the Profile to the Target Machines

1. Select the view you have created beforehand and select **Assign objects to the devices of the view**.




2. In the **Assign objects** dialog, select the profile you have created beforehand, click to assign it and then click **Ok**.

IGEL OS Base System 478 / 647





3. In the **Update time** dialog, select **Now** and click **Ok**.



4. Confirm the **Information** dialog.

IGEL OS Base System 479 / 647





The target machines download the ISO file. This may take a few minutes.


Monitoring the Process

- 1. In the structure tree of the UMS, open the context menu of one of the target machines and select **Other commands > Refresh system information**.
- 2. In the dialog, click **Refresh system information** and then from time to time.

 In the **Attribute** area, under **Firmware Description**, the current status of the OSC installation is shown.

IGEL OS Base System 480 / 647






When a device is ready, the value of **Firmware Description** changes to "IGEL OSC Ready for Conversion".

IGEL OS Base System 481 / 647





3. When **Firmware Description** reads "IGEL OSC Ready for Conversion", continue with Starting the Conversion in IGEL OS Creator (see page 502).

Check List

- The conversion profile is assigned to all target machines.
- All target machines have downloaded the IGEL OS Creator (ISO), which is indicated by the Firmware Description "IGEL OS Ready for Conversion".

Next Step

>> Starting the Conversion in IGEL OS Creator (see page 502)

IGEL OS Base System 482 / 647



Configuring the OSCW Installer in Buddy Mode

The target machines designated as update buddies download the ISO file containing the IGEL OS firmware from the UMS. When they have downloaded the file, the remaining target machines download it from the update buddies.



Make sure that all devices are joined to a Microsoft Active Directory (AD) and are accessible by the same AD user with reading permissions.

First, we create a profile for the update buddies that provides the OSCW installer with the download source for the ISO file. Then, we will assign this profile to the update buddies; the assignment of the profile triggers the update buddies to download the file. After that, we create a profile for the remaining target machines which configures them to use the update buddies. When the update buddies have downloaded the file, we can assign the profile to the remaining target machines. On assignment, each target machine selects an update buddy automatically and starts downloading the file from it.

The configuration comprises the following steps:


- Creating a Profile for the Update Buddies (see page 483)
- Assigning the Profile to the Update Buddies (see page 486)
- Checking if the Update Buddies are ready (see page 488)
- Creating a Profile for the Remaining Target Machines (see page 488)
- Creating a View to Select the Target Machines (see page 491)
- Assigning the Profile to the Target Machines (see page 497)
- Monitoring the Process (see page 499)

Creating a Profile for the Update Buddies


1. In the structure tree of the UMS Console, go to **Profiles** and open **New Profile** in the context menu.

483 / 647 **IGEL OS Base System**





- 2. In the **New Profile** dialog, change the settings as follows and click **Ok**:
 - Profile Name: A name for the profile, e. g. "IGEL OS Creator for Windows update buddies"
 - Based on: Select "IGEL Unified Management Agent < VERSION>".




The configuration dialog opens.

3. Click Converter.

IGEL OS Base System 484 / 647






You are taken to **System > OSC > Converter** where you can set all relevant parameters.

- 5. Change the settings as follows (click the icon to enable the configuration; the icon will change to .):
 - Download URL of IGEL OS Creator: Enter https://[IP address of your UMS Server]:8443/ums_filetransfer/ or http://[IP address of your UMS Server]:9080/ums_filetransfer/
 Example: https://192.168.178.100:8443/ums_filetransfer/ or http://
 192.168.178.100:9080/ums_filetransfer/
 - **Username**: Enter the username for the UMS.
 - **Password**: Enter the password for the UMS user.

IGEL OS Base System 485 / 647






6. Click Save.

Assigning the Profile to the Update Buddies


1. In the structure tree of the UMS console, select the machines that will serve as update buddies and




2. Select the update buddies profile, click and then **Ok**.

IGEL OS Base System 486 / 647





3. In the **Update time** dialog, select **Now** and click **Ok**.




IGEL OS Base System 487 / 647



Checking If the Update Buddies Are Ready

Perform the following check for each update buddy:

- 1. In the structure tree of the UMS, open the context menu of the update buddy and select **Other commands > Refresh system information**.
- 2. In the dialog, click **Refresh system information** and then every few seconds. In the **Attribute** area, under **Firmware Description**, the current status of the download is shown. When it reads "IGEL OSC Ready for Conversion", the update buddy is ready for use.




Creating a Profile for the Remaining Target Machines

1. In the structure tree of the UMS Console, go to **Profiles** and open **New Profile** in the context menu.


IGEL OS Base System 488 / 647





- 2. In the **New Profile** dialog, change the settings as follows:
 - Profile Name: A name for the profile, e. g. "IGEL OS Creator for Windows target machines"
 - Based on: Select "IGEL Unified Management Agent < VERSION>".

3. Click Ok.




The configuration dialog opens.

IGEL OS Base System 489 / 647



4. Click Converter.




You are taken to **System > OSC > Converter** where you can set all relevant parameters.

- 5. Change the settings as follows (click the icon to enable the configuration; the icon will change to :
 - Select Buddy Mode.
 - **Username**: Common username in Microsoft Active Directory for all target machines, including the update buddies.
 - Password: Common password associated with the Username.

IGEL OS Base System 490 / 647





6. Click Save.


Creating a View to Select the Target Machines

The target machines must be selected in order to assign the profile to them. For the selection, a view will be used.

1. In the structure tree of the UMS Console, go to **Views** and select **New View** in the context menu.

IGEL OS Base System 491 / 647






2. Enter a name for the view, e. g. "IGEL OS Creator for Windows - target machines" and click **Next**.

IGEL OS Base System 492 / 647






3. On the **Select criterion** page, select **Product ID** and click **Next**.

IGEL OS Base System 493 / 647






4. On the **Text search** page, enter "OSCW" and click **Next**.

IGEL OS Base System 494 / 647






5. On the **Create new view** page, click **Finish**.


IGEL OS Base System 495 / 647





The number of matches is shown.


6. Click **Load devices** to view the target machines.



7. The target machines are shown.


IGEL OS Base System 496 / 647





Assigning the Profile to the Target Machines


1. Select the view you have created beforehand and select **Assign objects to the devices of the view**.




2. In the **Assign objects** dialog, select the profile for the target machines, click to assign it and then click **Ok**.

IGEL OS Base System 497 / 647






3. In the **Update time** dialog, select **Now** and click **Ok**.



IGEL OS Base System 498 / 647



4. Confirm the **Information** dialog.




The target machines download the ISO file.

Monitoring the Process

- 1. In the structure tree of the UMS, open the context menu of one of the target machines and select **Other commands > Refresh system information**.
- 2. In the dialog, click **Refresh system information** and then every few seconds. In the **Attribute** area, under **Firmware Description**, the current status of the download is shown.

IGEL OS Base System 499 / 647






When a device is ready, the value of **Firmware Description** changes to "IGEL OSC Ready for Conversion".

IGEL OS Base System 500 / 647





3. When **Firmware Description** reads "IGEL OSC Ready for Conversion", continue with Starting the Conversion in IGEL OS Creator (see page 502).

Check List

- The conversion profile is assigned to all target machines.
- ☑ All target machines have downloaded the OSCW ISO file, which is indicated by the Firmware Description "IGEL OS Ready for Conversion".

Next Step


>> Starting the Conversion in IGEL OS Creator (see page 502)

IGEL OS Base System 501 / 647




Starting the Conversion in IGEL OS Creator

1. In the UMS structure tree, select the view you have created for selecting the target machines, and click **Load devices**.




2. Select all machines and in the context menu, select **Specific Device Command**.



3. In the **Specific Device Command** dialog, select **Convert to IGEL OS** and click **Execute**.

IGEL OS Base System 502 / 647





On the devices, a dialog is displayed. When the dialog is confirmed, the conversion starts immediately. If the dialog is not confirmed, the conversion starts after 20 seconds. When the conversion is complete, the **Product** information in the UMS is changed to "IGEL OS 12".

IGEL OS Base System 503 / 647



How to Deploy IGEL OS 12 with PXE



Internet Access Required

In contrast to a typical PXE environment, the installation of IGEL OS 12 requires Internet access because the endpoint devices must be able to reach the IGEL App Portal.

Prerequisites

- Your devices meet the requirements for IGEL OS 12. For further information, see Hardware > Supported Devices > IGEL OS 12 Hardware Support > Devices Supported by IGEL OS 12
- Your devices are able to boot via the network
- Your devices are in a network with Internet access
- A DHCP Server is available in your network

Retrieving the Required Files from the OSC ZIP File

- 1. Open a web browser, go to https://www.igel.com/software-downloads/cosmos/, and select the folder **OS 12 BASE SYSTEM IMAGE FOR PXE**.
- 2. Download the ZIP file (e.g. osc_12.2.1_pxe.zip) and extract it.

 We will distribute the required files to their appropriate locations later on.

Setting up the DHCP Server

When the devices are powered on, they need to be directed to the TFTP server that provides the low-level files required for booting. This is done by the DHCP server. In our example, we use a Microsoft Windows DHCP server; other DHCP can be used as well.


In the following, we will create three vendor classes, two for UEFI and one for BIOS.

- 1. On your Windows server, go to **DHCP** and right-click on **IPv4**.
- 2. Define each vendor class as follows:
 - a. In the **DHCP Vendor Classes** dialog, click **Add**.
 - b. Enter the data according to the vendor class you are creating:
 - i. Vendor class for UEFI on an x86 architecture:
 - **Display name**: PXEClient (UEFI x86)
 - Description: PXEClient:Arch:00006
 - ii. Vendor class for UEFI on an x64 architecture:
 - **Display name**: PXEClient (UEFI x64)
 - **Description**: PXEClient:Arch:00007
 - iii. Vendor class for BIOS on x86 and x64 architectures:

IGEL OS Base System 504 / 647



- **Display name**: PXEClient (BIOS x86 & x64)
- Description: PXEClient:Arch:00000




- 3. Perform the following steps for each vendor class you have created:
 - a. Right-click **Scope** ([IP address]) **DHCP range > Policies** and select **New Policy** from the context menu.
 - b. At **Policy Name**, enter the name exactly as you did for the vendor classes, i.e, once PXEClient (UEFI x86), once, PXEClient (UEFI x64), and once PXEClient (x86 & x64).
 - c. Click Next.
 - d. In the Configure Conditions for the policy screen, click Add.
 - e. In the Add/Edit Condition dialog, click the drop-down menu Value:.
 - f. Select the appropriate vendor class.
 - g. Activate Append wildcard. click Add and then OK.
 - h. Click Next,
 - i. Answer the question **Do you want to configure an IP address range for the policy?** with **No** and click **Next**.
 - j. Activate option **060** and edit it, according to the policy you are at:
 - For PXEClient (UEFI x86), enter PXEClient.
 - For PXEClient (UEFI x64), enter PXEClient.
 - For PXEClient (BIOS x86 & x64), leave the option empty.
 - k. Activate option **066** and enter the Fully Qualified Domain Name (FQDN) or the IP address of your TFTP server.
 - l. Activate option **067** and enter the path to the appropriate .efi file on your TFTP server. For example, this might be grub/bootx64.efi for the PXEClient (UEFI x64)

IGEL OS Base System 505 / 647



vendor class if you are using GRUB as the bootloader.


4. Review your **Scope Options**; they should be similar to this:



5. Go to **Server Options**, add option **066**, and enter the Fully Qualified Domain Name (FQDN) or the IP address of your TFTP server.

IGEL OS Base System 506 / 647






Deploying the TFTP Server

In this step, we deploy that TFTP server that provides the bootloader and a minimal OS that will load the higher-level components of IGEL OS.

- 1. Install a TFTP server, e.g. SolarWinds. see https://www.solarwinds.com/de/free-tools/free-tftp-server
- 2. Specify the directory in which the PXE boot files will be stored, typically C:\TFTP-Root

IGEL OS Base System 507 / 647





3. Copy the directories and files from the tftp/ directory of your OSC ZIP file to the TFTP root directory, in our example C:\TFTP-Root. The directory structure must be preserved. The most important contents are:

- GRUB Bootloader for 64-bit EFI systems
- GRUB Bootloader for i386/BIOS systems
- Configuration file for GRUB Bootloader

IGEL OS Base System 508 / 647




Providing the PXE Configuration File (pxe-config.json)

The file <code>pxe-config</code> is used at an early stage of the boot process and will be provided by the TFTP server. It specifies the download paths for specific necessary files, an authentication token for connecting with the IGEL App Portal, and the version of the Base System that is to be installed.


First, we retrieve the file from the UMS, then we edit it to adapt it to our environment. Afterward, we put it into the appropriate directory on the TFTP server.

Retrieving the File from the UMS

1. Open the UMS Web App, go to **Apps** and click the icon.




2. In the area **PXE Configuration**, select the version of the IGEL OS Base System you want to install and the validity period for the authentication token that enables access to the App Portal.




IGEL OS Base System 509 / 647






3. Click **Generate**.



IGEL OS Base System 510 / 647





IGEL OS Base System 511 / 647



The file pxe-config. json is downloaded by your browser.

Editing the "pxe-config.json" File

```
    In the OSC ZIP file (example: osc_12.2.1_pxe.zip), check out the contents of the webserver/ directory. We will create a reference for each file in step 2.
    Example: osc.bspl osc.nvgfx osc.sys
```

- 2. Edit pxe-config.json as follows:
 - "osc"/"partitions": Enter a list of the URLs of the files to be downloaded from your web server. The format is http://<WEB SERVER ADDRESS>/<PATH>/<FILENAME>
 - "apps"/"version": Ensure that the desired version of IGEL OS is specified. Example:

```
{
    "osc": {
        "partitions": [
            "http://igel-pxe-weberver/osc.bspl",
            "http://igel-pxe-weberver/osc.nvgfx",
            "http://igel-pxe-weberver/osc.sys"
        ]
    },
    "appdata": {
        "app_portal": "https://app.igel.com/api/",
        "auth_token":
"eyJ0eXAi0iJKV1QiLCJhbGci0iJSUzUxMiJ9.eyJmaW5nZXJwcmludCI6IjQ2Njc
E4NkMyMTk4Njg3MUIzMEUwMzU3NUQ5Q0NFRTQzNUJGRkU3M0IxQjYxRkMiLCJib2R5Ijp7InVt
c0lkIjoiVU1TL
UNMVVNURVItLTQ0MDMxLTE2ODgxMzQzNTY4NDEtMi0wIn0sInR5cGUi0iJ1bXMiLCJleHAi0jE
3MDA00DAxMDgs
ImlhdCI6MTY5NzgwMTcwOH0.p-03tX5Zoesud95cpZBJuBCJU77fGzd17J3i1cbCIvhdIAB8D6
CmAdN6kFQ-9Qn
q35SmhyN8f8Jyn63AZEhmiAKPYVGNu10gVxN-oIU3SBTE74JlU0W26kQuYNEa-WqyAh4BGm-
dJ2qnyqH7_5L08F
DFalJChN8v7DlZ5MVA_G9IWNQ6d87cM13dNFbuH4gK9z6lvKKI2s9Mfr2WQcu5qxBi3HhR-
f3M45zCMyUfm95Tu
eON48tAyfLPbxlqBUjm2FREJN89dqoZpo-obfcLQ85od6bFyotnK-MDm27-
BQvSlOpRujki2wMMYHz1vBeEJJfN
l78aGha5wRDpvrffr0gd_vY4Taicd8hwETcAmI9ihks0H04gj6GIYZ1dBTbSGBMdooBkB4T5nK
trSX3I0kKCm79-
```

IGEL OS Base System 512 / 647



Proving the PXE Configuration File (pxe-config.json) via the TFTP Server

```
→ Copy pxe-config.json to <TFTP ROOT>/images/.Example file path: C:\TFTP-Root\images\pxe-config.json
```


Configuring the Web Server (IIS)

For installing the components of IGEL OS 12, we need a web server. In our example, we will use the Microsoft Internet Information Server (IIS).

- 1. If IIS is not already available on your Windows server, install it.
- 2. Add the file name extensions and the corresponding MIME types for all file types that are present in the webserver/ directory of the OSC ZIP file. In our example:
 - File name extension .bspl; MIME type application/octet stream
 - File name extension: .sys; MIME type application/octet stream
 - File name extension: .nvgfx; MIME type application/octet stream

IGEL OS Base System 513 / 647





- 3. Specify a directory in which the required files will be stored, in our example C:\HTTP-Root
- 4. Copy all files from the webserver/ directory of the OSC ZIP file into the directory on the web server that has been defined in the section "osc"/"partitions" of your pxe-config.json (see Editing the "pxe-config.json" File (see page 512)). In our example, the directory is C:\HTTP-Root and the files are osc.bspl, osc.nvgfx, and osc.sys. The files may vary depending on the version of your OSC ZIP file.



Web Server Check

We recommend checking the URLs for these files in a web browser to ensure the download is functional.

Installing IGEL OS via PXE

 \rightarrow Start the devices in your PXE environment. If everything has been set up correctly, your devices boot into IGEL OS 12.

IGEL OS Base System 514 / 647



How to Use IGEL OS 12 with UD Pocket

UD Pocket boots IGEL OS on your computer. However, it does not make any changes to the operating system already installed on the device's storage – UD Pocket runs entirely from the USB stick.

To facilitate booting your UD Pocket, you can use the IGEL UD Pocket Starter. The IGEL UD Pocket Starter creates a boot option for the UD Pocket so that there is no need to change the boot settings manually. You can install the IGEL UD Pocket Starter easily on an endpoint device running Microsoft Windows 10 or 11 - provided Microsoft BitLocker is not active on the device. When you uninstall the IGEL UD Pocket Starter, it is removed without any trace on the device.

UD Pocket, like all IGEL operating systems, can be managed centrally using the IGEL Universal Management Suite (UMS). UD Pocket uses IGEL OS, which is described in detail under Configuration of IGEL OS 12 Device Settings (see page 6).

UD Pocket has a partition that contains this manual and is readable under Windows. The manual describes setting up and starting UD Pocket on your computer.



These instructions apply to UD Pocket / Powered by IGEL UD Pocket and UD Pocket 2 / Powered by IGEL UD Pocket 2.



If you use the IGEL UD Pocket, note that there is a downgrade limit, see Downgrade Limit on IGEL OS 12.7.1 or Higher (see page 407).

Requirements

To use UD Pocket, your computer must meet the following requirements:

- USB 3.0 or 2.0 port from which the computer can boot
- Capability of booting from USB storage media
- Ethernet or wireless adapter. For a detailed list of supported graphics and network chips, see the IGEL Linux 3rd Party Hardware Database⁵⁹.
- The device is supported by IGEL OS; for details, see Devices Supported by IGEL OS 12.

If you want to use the IGEL UD Pocket Starter, the following requirements apply:

- Microsoft Windows 10 or 11 is installed on the endpoint device.
- The device has EFI BIOS
- Microsoft BitLocker is deactivated

IGEL OS Base System 515 / 647


^{59.} https://www.igel.com/linux-3rd-party-hardware-database/



Installing the IGEL UD Pocket Starter


1. Download setup-igel-udp_starter_<VERSION_NUMBER>.exe from https://
 www.igel.com/software-downloads/

2. Copy the file to your endpoint device, double-click it, and follow the instructions of the IGEL UD Pocket Starter Setup Wizard.




IGEL OS Base System 516 / 647





IGEL OS Base System 517 / 647






Configuring the Boot Order

You can define which operating system is booted by default, i.e. if the user does not make a selection in the boot menu.


1. In the system tray, click on the IGEL OS icon.

IGEL OS Base System 518 / 647





- 2. Choose the desired default operating system and click **Save**.
 - Windows: Windows is booted by default, even if a UD Pocket is plugged into the device.
 - **UD Pocket**: IGEL OS is booted from the UD Pocket, provided it is plugged in.



Starting Your IGEL UD Pocket (With IGEL UD Pocket Starter Installed)

- 1. Plug the UD Pocket into a free USB slot of your device.
- 2. Turn o your device; if the device is already switched on, restart it.

 Your device boots into IGEL OS, provided you have chosen this option when **configuring the boot order**.

IGEL OS Base System 519 / 647



Starting Your IGEL UD Pocket (Without IGEL UD Pocket Starter)

Booting from Your UD Pocket

- 1. Plug the UD Pocket into a free USB slot of your device.
- 2. Turn on your device; if the device is already switched on, restart it.
- 3. If a boot menu is presented that contains **IGEL UD Pocket** as an option, select this option. If not, proceed with the next step **Customizing the Boot Settings**.

Customizing the Boot Settings

Booting from USB storage media may already be enabled on your device, or you may have to enable it yourself. The required key presses for this may vary from vendor to vendor. However, here are some hints:

- → While the device is booting, try pressing [F12] (in general), [F10] (Intel devices), or [F9] (Hewlett-Packard devices) to access a list of boot devices and select **IGEL UD Pocket**.
- \rightarrow If the above does not work, access the BIOS settings via pressing [Del], [F1], or [F2] during boot, activate booting from USB storage media, and/or change the boot order.
- → See the BIOS/UEFI documentation for your system for details on how to boot from USB storage media.
 - IGEL OS supports UEFI Secure Boot. Refer to the manual of your device's manufacturer to learn whether your device supports Secure Boot and how to enable it. Enabling Secure Boot often consists of two steps. First, the boot mode has to be changed to UEFI Boot in the BIOS; after that, Secure Boot can be activated, also in the BIOS. How to check whether Secure Boot has been properly enabled, you can learn under (en) Verifying that Secure Boot is Enabled.
 - if UD Pocket fails to boot in UEFI mode, try it in legacy/BIOS mode. If this does not help, try another endpoint device to verify that the UD Pocket is functional and/or check for BIOS updates for your endpoint device and the latest IGEL OS updates.
- Do not remove the UD Pocket from the computer until you have shut down the IGEL OS contained on it. Otherwise, you can damage the operating system on UD Pocket and lose your settings as well as data on other removable media.

After the First Boot-Up

To get started with your IGEL OS 12 device, see (en) How to Start with IGEL.

IGEL OS Base System 520 / 647



IGEL Tech Video



Sorry, the widget is not supported in this export. But you can reach it using the following URL:

https://www.youtube.com/watch?v=iURhgESsn6k

IGEL OS Base System 521 / 647



Troubleshooting: SCEP Certificate Renewal Failure due to Hostname Change

When SCEP certificate is linked to the DNS name of the device, the renaming of the device can lead to certificate renewal failure. This is indicated by the notification: "Renewal of client certificate failed - subject has changed OLDNAME > NEWNAME ".

Problem

If DNS name (auto) is selected under Network > SCEP Client (NDES) > Certificate (see page 176) > Type of CommonName/SubjectAltName, the hostname (also known as computer name or terminal name) is used for the SCEP certificate.

When the device gets renamed, the change is ignored for the network authentication and the certificate with the old hostname remains in use by default. This way the network authentication continues to function despite of the mismatch between the certificate with the old hostname and the one with new hostname.

However, when the certificate needs to get renewed, it usually fails because the SCEP server does not hand out a certificate for the new hostname based on the legitimacy of the old certificate.

Solution

To change the configuration:

1. Go to System > Registry > network.scepclient.cert%.hostname_change_handling Accessories User Interface Network Devices Security System Q (81 Time and Date network.scepclient.cert%.hostname_change_handling Remote Management Hostname change handling Remote Access v cert% Logging cacert md5fingerprint Power Options System Customization challenge_password_command Update checkintervall Registry crypt_password hos tname_change_hand ling

The default value is **Ignore**, this is why hostname changes are ignored in network authentication.

Set the the parameter to **Reset**.
 As a result, when the hostname changes, any existing certificate gets discarded and the whole SCEP process starts over.

IGEL OS Base System 522 / 647





The **Reset** option is helpful when starting over the whole SCEP process is desired. It will not work when e.g. a fixed challenge password is configured and not valid anymore. So when the hostname is changed carelessly, the **Ignore** option's consequences are less severe.

523 / 647 IGEL OS Base System



Upgrading from IGEL OS 11 to IGEL OS 12

For instructions on upgrading endpoint devices from IGEL OS 11.09 to IGEL OS 12 via the Universal Management Suite (UMS), see Upgrading (Migration) from IGEL OS 11 to IGEL OS 12⁶⁰.

IGEL OS Base System 524 / 647

 $^{60.\} https://kb.igel.com/en/igel-os/current/upgrading-migration-from-igel-os-11-to-igel-os-12-to-i$



Articles on Integrating IGEL OS 12 Devices Into Your Infrastructure

- How to Customize the Unit ID Computation for IGEL OS Creator (OSC) (see page 526)
- Troubleshooting: UMS Tray App Reports Connection failure: read failed (see page 530)

IGEL OS Base System 525 / 647



How to Customize the Unit ID Computation for IGEL OS Creator (OSC)

In Which Cases Should I Change the Computation of the Unit ID?

Every IGEL OS device has a unit ID which must be unique and persistent. This is crucial for the administration and licensing of the device. For devices with a permanently installed IGEL OS (not UD Pocket), the unit ID is derived from the MAC address of a network interface.

The unit ID is computed on the first boot after IGEL OS has been successfully installed by IGEL OS Creator (OSC). In almost all cases, the default algorithm for computing the unit ID will choose the appropriate MAC address. However, in the rare case that the MAC address chosen by the default algorithm is not the ideal one for your requirements, e.g. if the chosen network device is not used later on, you can define custom rules. To apply your custom rules, you must write them to a file within the IGEL OS Creator (OSC).



Changing the Unit ID of a Registered Device

When the unit ID of a device that is registered with the UMS is changed, the registration is broken. In this case, you must re-register the device, e.g. by scanning.

Requirements

- Bootable USB memory stick with IGEL OS Creator (OSC) 12.2.2 or higher. If you haven't got this software already, download it from https://www.igel.com/software-downloads/igel-os-12-secure-endpoint/.
- A Linux machine; the examples in this article are based on IGEL OS.

What Is the Default for Computing the Unit ID?

The default algorithm for choosing the MAC address for unit ID computation is as follows:

- 1. If a network interface exists that matches a license already installed on the device, discard all other network interfaces.
- 2. Discard network interfaces that do not have the highest subsystem priority. The subsystem priorities are (from highest to lowest): PCI, SDIO, USB, others.
- 3. Discard wireless network interfaces if a wired interface exists.
- 4. From the remaining network interfaces, use the one that is first in lexicographical order.

Which Computation Rules Are Available?

The following list contains all available rules for unit ID computation. Please note that if several network interfaces meet the criteria, the first one in the lexicographic order is selected unless the rule reverse_order is applied.

• prefer_pci: If a network interface connected via the PCI subsystem exists, discard all interfaces connected via other subsystems.

IGEL OS Base System 526 / 647



- prefer_sdio: If a network interface connected via the SDIO subsystem exists, discard all interfaces connected via other subsystems.
- prefer_usb: If a network interface connected via USB subsystem exists, discard all interfaces connected via other subsystems.
- prefer_wired: If a wired network interface exists, discard all wireless interfaces.
- prefer_wireless: If a wireless network interface exists, discard all wired interfaces.
- ignore_licensed: Do not take into account whether an interface is licensed or not. (In contrast to the default behavior where network interfaces that match the device's license are given preference.)
- reverse_order: If more than one equivalent network interface is found, use the last one in the lexicographical order instead of the first one,

Creating a Custom Set of Rules

To achieve a specific computation of the unit ID, you can combine several rules.

Example

The set of rules prefer_wireless, ignore_licensed, reverse_order leads to the following behavior:

- 1. prefer_wireless: If a wireless network card is connected, all wired network cards are discarded.
- 2. ignore_licensed: If there are several wireless network cards and one of them matches the device's license, this does not count as a reason to use it for unit ID computation.
- 3. reverse_order: As the licensing criterion does not count, the position of a network device's name in the lexicographic order is the next criterion. By default, the first device in lexicographic order would be selected, but reverse_order defines that the last device is selected.

Applying the Set of Rules to Your OSC (IGEL OS)

In the following description, we use IGEL OS. On other Linux variants, the procedure may differ; in particular, mounting the memory stick may require sudo.

- 1. Plug the USB memory stick with IGEL OSC on it into your device.
- 2. Open a terminal on the device and log in as root. For details on configuring a terminal on IGEL OS, see Terminals (see page 13).
- 3. Create a directory to which the memory stick will be mounted, e.g. stick/

	mkdir stick			
l				

IGEL OS Base System 527 / 647

stick

root@ITC54E1AD8CECBE:~#



4. Determine the device name of the memory stick with lsblk

```
lsblk
The output should look something like this:
▶ Local Terminal
                                                                                  HWI SUPPORT=0 HWI PRODUCT_ID=1 HWI_HARDWARE_ID=0 HWI_HARDWARE_NAME='Legacy_x86_system'
root@
                   ::~# lsblk
NAME
      MAJ:MIN RM
                   SIZE RO TYPE MOUNTPOINT
        8:0 0 238,5G 0 disk
sda
                     9M 0 part
 -sda1
         8:1
               0
             0
                   200M 0 part
 -sda2
         8:2
 -sda3
        8:3
               0 200M 0 part
 -sda4
         8 · 4
                  63 6G
                         0 nart
                   7,5G 0 disk
2,2G 0 part
         8:16
        8:17 1
 -sdb1
                    50M 0 part
 -sdb2
         8:18
               0 63,66 0 disk
igtu
        61:0
igf1
        61:1
               0 746,6M 0 disk /dev/.mnt-system/ro/sys
igf23
       61:23 0 3,3M 0 disk /dev/.mnt-system/ro/bootsplash
igf26
       61:26 0 21,5M 0 disk /dev/.mnt-system/ro/services/cjk
       igf39
igf55
       61:60 0 374,7M 0 disk /dev/.mnt-system/ro/services/nvgfx
igf60
igf66
       61:66 0 14,6M 0 disk
       61:68 0 876K 0 disk /dev/.mnt-system/ro/services/fonts 61:94 0 88,3M 0 disk /dev/.mnt-system/ro/services/hpihvdoc
igf68
igf94
igf200 61:200 0 128M 0 disk
└-200 253:2 0 128M 0 dm
                                /userhome/.pki
                  1G 0 disk
1G 0 dm
igf239 61:239 0
<sup>1</sup>—239 253:1 0
                                /cache
                   5M 0 disk /license
igf254 61:254 0
igf255 61:255 0
                    24M 0 disk
      253:0
 -255
               0
                    24M 0 dm
zram0
      252:0
               0
                   1,1G
                         0 disk [SWAP]
      252:1
               0
                   1,1G 0 disk [SWAP]
zram1
zram2
      252:2
               0 1,1G 0 disk [SWAP]
               0
      252:3
                   1,1G 0 disk [SWAP]
zram3
root@ITC54E1AD8CECBE:~# pwd
/root
root@ITC54E1AD8CECBE:~# mkdir stick
root@ITC54E1AD8CECBE:~# ls
```

5. When you have determined which of the listed devices is your memory stick, mount the second partition to the stick/ directory. In our example, this is sdb2.


```
mount /dev/sdb2 stick/
```

IGEL OS Base System 528 / 647



6. Use your favorite text editor, e.g. vi, to create your unit_id_rules.ini file.

```
vi stick/igel/unit_id_rules.ini
```



7. Unmount the partition.

umount stick

Now you can use the modified OSC on your memory stick to install IGEL OS on your devices.

IGEL OS Base System 529 / 647



Troubleshooting: UMS Tray App Reports Connection failure: read failed

IGEL OS 12 devices are disconnected form the IGEL Universal Management Suite (UMS) and you can see the following error message in the UMS tray app: Connection failure: read failed or in device logs. This error occurs because the TLS handshake is aborted during the establishment of a TLS connection to the UMS. This can happen when the IGEL OS 12 device has an expired client certificate.

Environment

- IGEL OS registered in UMS more than 1 year ago
- IGEL OS version 12.4.1 or lower

Problem

For devices with older IGEL OS 12 version, that is, running IGEL OS version 12.4.1 or lower, the client certificates are never renewed. These certificates expire 1 year after device registration in the UMS. As a result, devices cannot connect to the UMS and you can see the following error message in the UMS tray app: ERROR: Connection

failure: read failed

You can also see the same error message in the device log files when the device is trying to connect to the UMS.

```
0E0C5188SD6 igel-rmagent-connector[7921]: Try to connect ...
ITC00 igel-rmagent[1976]: Dispatch local request: Connect
ITC00 igel-rmagent[1976]: Connecting to device connector
ITC00 igel-rmagent[7942]: WS connector process terminated: status=0
ITC00 igel-rmagent[1976]: ERROR: Connection failure: read failed
ITC00 igel-rmagent[1976]: Response to local command Connect: id=4cc192df45a742beb8c14379a8bbba65 status=1 message='ERROR: Connection failure: read failed'
ITC00 igel-rmagent[1976]: Disconnected
```

Solution

The mitigation of the issue is done by allowing expired certificates to be temporarily accepted for device connection to the IGEL UMS. This way, the devices can be updated without manual intervention.

For details, see Troubleshooting: IGEL OS 12 Devices Failing to Connect to UMS Due to Expired Client Certificates⁶¹.

For details on how to enable the custom TrustManager for the IGEL Cloud Gateway, see Troubleshooting: IGEL OS 12 Devices Failing to Connect to the ICG Due to Expired Client Certificates⁶².

IGEL OS Base System 530 / 647

^{61.} https://kb.igel.com/en/universal-management-suite/current/troubleshooting-igel-os-12-devices-failing-to-conn

^{62.} https://kb.igel.com/en/igel-cloud-gateway/current/troubleshooting-igel-os-12-devices-failing-to-conn



Articles on Network Configuration in IGEL OS 12

- How to Configure Wi-Fi Network Roaming in IGEL OS 12 (see page 532)
- How to Configure Server Certificate Verification during 802.1x Authentication in IGEL OS 12 (see page 535)
- How to Configure the Permanent Storage of User-Provided Network Credentials (Wi-Fi and Ethernet) (see page 539)

IGEL OS Base System 531 / 647



How to Configure Wi-Fi Network Roaming in IGEL OS 12

This article describes the parameters for configuring/optimizing Wi-Fi roaming for devices with IGEL OS 12. With this configuration, a device moving around will automatically select the strongest Wi-Fi access point available at the current position.

To find the settings described in this article, go to **System > Registry**.



The settings changes described here should only be made by experts.

Requirements

- Devices with IGEL OS 12.7.0 or higher
- All Wi-Fi networks within the device may roam are configured on the device

Roaming with Access Points that Share the Same SSID

Preventing Roaming

→ To make a device stick to the access point it is connected to, even if candidates with better signal quality are present, enable **network.interfaces.wirelesslan.device0.lock_initial** and set **network.interfaces.wirelesslan.device0.bgscan.module** to **none**. This should be regarded as a last resort for problems caused by too much roaming.

Configuring Background Scanning for a Stronger Signal

When background scanning is enabled, the Wi-Fi module continuously scans the environment for a potentially better signal. Background scanning is done by the simple module of wpa_supplicant. The parameters for background scanning are configurable.

Background Scanning

- → To configure backup scanning, set **network.interfaces.wirelesslan.device0.bgscan.module** according to your needs:
 - none: No background scanning is done.
 - **default**: Background scanning is performed by the "simple" module with typical settings. (Default)
 - **simple**: Background scanning is performed by the "simple" module. The settings can be adjusted; see Background Scanning Behaviour According to the Signal Strength (see page 533).

IGEL OS Base System 532 / 647



Background Scanning Behaviour According to the Signal Strength

These settings are available when **network.interfaces.wirelesslan.device0.bgscan.module** is set to **simple**.

When the signal strength falls below the defined threshold, background scanning is performed in a short interval. When the signal strength is higher than the threshold, background scanning is performed in a long interval.

- → To adjust the signal strength threshold, change the dBm value in **network.interfaces.wirelesslan.device0.bgscan.simple.signal_strength**. (Default: -45)
- → To adjust the short interval that is used when the signal strength falls below the defined threshold, change the interval in seconds in **network.interfaces.wirelesslan.device0.bgscan.simple.short_interval**. (Default: 30)
- → To adjust the long interval that is used when the signal strength is higher than the defined threshold, change the interval in seconds in **network.interfaces.wirelesslan.device0.bgscan.simple.long_interval**. (Default: 300)

Roaming Between Wi-Fi Networks with Different SSIDs

Interval for Triggering Automatic Roaming

→ To adjust the interval within which the device will check if automatic roaming might be necessary, edit the value **network.interfaces.wirelesslan.device0.mssid_check_interval** (default: 10s). This includes detecting that a connection has been lost and that a new one must be established.

Quality Threshold for Triggering a Scan

If the current quality is below the quality threshold, the device will start scanning for a better network.

→ To adjust the quality threshold, edit the percentage value of **network.interfaces.wirelesslan.device0.mssid_quality_threshold** (default: 20).

Quality Difference Threshold for Switching Over to a New Network

If the quality of a network is higher than that of the current network by a defined percentage, the new network is considered a candidate.

→ To adjust the quality difference threshold, edit the percentage value in **network.interfaces.wirelesslan.device0.mssid_quality_difference_threshold** (default: 40).

Quality Threshold for Re-Using a Network after Reboot

The network used before the reboot is preferred if its quality percentage is higher than a defined value.

→ To adjust the quality difference threshold, edit the percentage value in **network.interfaces.wirelesslan.device0.mssid_previously_used_threshold** (default: 55).

IGEL OS Base System 533 / 647



User-Initiated Roaming

→ To enable roaming via the Wi-Fi tray icon's context menu (see https://kb.igel.com/en/igel-os-base-system/ 12.6.1/tray-applications-in-igel-os-12#wifi), activate

network.interfaces.wirelesslan.device0.mssid_user_selection (default: disabled).

- → To prevent automatic roaming from interfering with user-initiated roaming, make the following settings:
 - network.interfaces.wirelesslan.device0.mssid_quality_threshold: 0
 - network.interfaces.wirelesslan.device0.mssid_quality_difference_threshold: 101
 - network.interfaces.wirelesslan.device0.mssid_previously_used_threshold: 0

Faster Roaming

Faster Wi-Fi roaming can be achieved by preventing the ARP cache from being purged and/or by limiting the frequencies to be scanned.

→ To prevent the ARP cache from being purged, which saves about 1 sec, set network.interfaces.wirelesslan.device0.arp_ndisc_evict_nocarrier to 0.



⚠ When the ARP cache is not purged during roaming, packet loss may occur.

- → To limit the frequencies to be scanned, make the following settings:
 - network.interfaces.wirelesslan.device0.freq_list: <LIST OF FREQUENCIES IN MHZ>. Example: 2412 2437 2462
 - network.interfaces.wirelesslan.device0.freq_list: <LIST OF FREQUENCIES IN MHZ>. Example: 2412 2437 2462

IGEL OS Base System 534 / 647




How to Configure Server Certificate Verification during 802.1x Authentication in IGEL OS 12

You can use registry key configurations for verifying server certificate during 802.1x authentication in wireless and LAN connections in IGEL OS 12.

Example Configuration

If you would like to configure a substring to be matched against the subject of the certificate presented by the authentication server, you can do that through a dedicated registry key:

- Configure the network connection under Network > Wireless > Wi-Fi Network or Network > LAN Interfaces for IGEL OS 12 devices. This can be done through a profile, or through local configurations. For details, see Wi-Fi Networks Configuration in IGEL OS 12⁶³ and LAN Interfaces in IGEL OS 12⁶⁴.
- 2. In the profile configurator, go to the **Search** and enable **Include Registry**.



- 3. Start typing the name of the registry key and open the search result under **Results in Registry** to navigate there in the registry.

 For example search for:
 - network.interfaces.wirelesslan.device1.alt_ssid for authentication through WLAN

IGEL OS Base System 535 / 647

^{63.} https://kb.igel.com/en/igel-os-base-system/current/wi-fi-networks-configuration-in-igel-os-12

^{64.} https://kb.igel.com/en/igel-os-base-system/current/lan-interfaces-in-igel-os-12



network.interfaces.ethernet.device for authentication through Ethernet



You can also use the **Registry** navigation tree to get to the registry keys. Each dot in the registry key marks a level deeper in the tree. For example, for network.interfaces.ethernet.device1, you need to click through network > interfaces > ethernet > device1.

4. Find the right instance of the registry key to update. Instances are present for each configured connection. Instances are marked by the numbers in the registry keys, like device0.alt ssid1.



For WLAN, the instance you are looking for is the one where network.interfaces.wirelesslan.device0.alt_ssidX.network_name contains the right name (SSID).

5. Fill out the registry key field with the substring.

Useful Registry Keys

You can use the following registry parameters to further configure the 802.1x authentication. You can find them by searching for the registry key as described above.

Subject alternative matches

List of strings separated by ";" to be matched against altSubjectName of the certificate presented by the authentication server, for example DNS:server.example.com

Registry key for WiFi:

network.interfaces.wirelesslan.device0.alt_ssid0.wpa.altsubject_matches

Registry key for LAN: network.interfaces.ethernet.device0.ieee8021x.altsubject_matches

Domain match

List of FQDNs separated by ";" to be matched against the certificate presented by the authentication server.

Registry key for WiFi:

network.interfaces.wirelesslan.device0.alt_ssid0.wpa.domain_match

Registry key for LAN: network.interfaces.ethernet.device0.ieee8021x.domain_match

Domain suffix match

List of FQDN suffixes separated by ";" to be matched against dNSName elements of the certificate presented by the authentication server.

Registry key for WiFi:

network.interfaces.wirelesslan.device0.alt_ssid0.wpa.domain_suffix_match

536 / 647 **IGEL OS Base System**



Registry key for LAN:

network.interfaces.ethernet.device0.ieee8021x.domain_suffix_match

Subject match

Substring to be matched against the subject of the certificate presented by the authentication server.

Registry key for

WiFi: network.interfaces.wirelesslan.device0.alt_ssid0.wpa.subject_match

Registry key for LAN: nnetwork.interfaces.ethernet.device0.ieee8021x.subject_match

Phase 2 alternative subject matches

List of strings separated by ";" to be matched against altSubjectName of the certificate presented by the authentication server.

Registry key for WiFi:

network.interfaces.wirelesslan.device0.alt_ssid0.wpa.phase2_altsubject_matches

Registry key for LAN:

network.interfaces.ethernet.device0.ieee8021x.phase2_altsubject_matches

Phase 2 Domain match

List of FQDNs separated by ";" to be matched against the certificate presented by the authentication server during the inner "phase 2" authentication.

Registry key for WiFi:

network.interfaces.wirelesslan.device0.alt_ssid0.wpa.phase2_domain_match

Registry key for LAN:

nnetwork.interfaces.ethernet.device0.ieee8021x.phase2_domain_match

Phase 2 Domain suffix match

List of FQDN suffixes separated by ";" to be matched against dNSName elements of the certificate presented by the authentication server during the inner "phase 2" authentication.

Registry key for WiFi:

network.interfaces.wirelesslan.device0.alt_ssid0.wpa.phase2_domain_suffix_match

Registry key for LAN:

network.interfaces.ethernet.device0.ieee8021x.phase2_domain_suffix_match

Phase 2 Subject match

Substring to be matched against the subject of the certificate presented by the authentication server during the inner "phase 2" authentication.

IGEL OS Base System 537 / 647



Registry key for WiFi:

network.interfaces.wirelesslan.device0.alt_ssid0.wpa.phase2_subject_match

Registry key for LAN:

network.interfaces.ethernet.device0.ieee8021x.phase2_subject_match

IGEL OS Base System 538 / 647



How to Configure the Permanent Storage of User-Provided Network Credentials (Wi-Fi and Ethernet)

In the following article, you will learn how you can configure the permanent storage of the username (identity) and password in IGEL OS that are provided by an end user via an entry mask when connecting to the enterprise network.

Problem

Username and password are required for IEEE 802.1x authentication for wireless and Ethernet connections with certain authentication methods like e.g. EAP-PEAP-MSCHAPv2 or EAP-TTLS-PAP, see Wi-Fi Networks Configuration in IGEL OS 12⁶⁵ and Authentication in IGEL OS 12⁶⁶. If you do not preconfigure the username (identity) and password via a UMS profile or the device's local Setup, these credentials can be entered by an end user via an entry mask. However, they are not saved, so the end user has to re-enter the credentials each time the endpoint device reboots or resumes from suspend (sleep) mode.

Solution

You can enable the permanent storage of the credentials entered by an end user for enterprise network connections using the following registry keys. If enabled, the credentials are stored securely on the device.

The credentials for the following networks can be stored:

- Wi-Fi (WPA Enterprise)
- Ethernet (IEEE 802.1X)

This applies to those use cases where the network credentials are not preconfigured via a UMS Profile or the device's local Setup.

Wi-Fi

For the relevant Wi-Fi network, edit the configuration as follows:


→ Go to System > Registry > network > interfaces > wirelesslan > device0 > alt_ssid[number of the relevant Wi-Fi network] > wpa > allow_saving_credentials and set Allow saving credentials to permanent.

IGEL OS Base System 539 / 647


^{65.} https://kb.igel.com/en/igel-os-base-system/current/wi-fi-networks-configuration-in-igel-os-12

^{66.} https://kb.igel.com/en/igel-os-base-system/current/authentication-in-igel-os-12





If you have activated the above registry key, the entry mask will include the option for saving the network credentials:




Ethernet (IEEE 802.1X)

For the relevant network device, edit the configuration as follows:


→ Go to System > Registry > network > interfaces > ethernet > device[number of the relevant network device] > ieee8021x > allow_saving_credentials and set Allow saving credentials to permanent.

IGEL OS Base System 540 / 647





If you have activated the above registry key, the entry mask will include the option for saving the network credentials:



IGEL OS Base System 541 / 647



Articles on Single-Sign On (SSO) with IGEL OS 12

- Facilitated Switching between IdPs for Single-Sign On (SSO) In IGEL OS 12.2 (see page 543)
- How to Configure Single Sign-On (SSO) on IGEL OS 12 (see page 547)

IGEL OS Base System 542 / 647



Facilitated Switching between IdPs for Single-Sign On (SSO) In IGEL OS 12.2

Overview

Switching between Okta and Microsoft Entra ID has been facilitated with IGEL OS 12.2.

With IGEL OS 12.01, the behavior of the SSO configuration was as follows: When you wanted to switch the IdP between Okta and Microsoft Entra ID, you had to delete and re-enter the public client identifier and the secret every time. This goes back to the fact that these values were not stored as separate parameters on the device.

With IGEL OS 12.2 or higher, the SSO configuration has been optimized. The public client identifiers and the secrets are now handled separately for Okta and Microsoft Entra ID. To benefit from this improvement, the profile must be based on IGEL OS 12.2.



Automatic Update Results in Broken SSO

If your devices have been updated because **Auto-update Default Version to newest version** is active (see Universal Management Suite > IGEL UMS Web App > Apps - Import and Configure Apps for IGEL OS 12 Devices via the IGEL UMS Web App > Updating IGEL OS Apps > How to Configure Update Settings for Apps in the IGEL UMS Web App), and the SSO settings are still defined by a profile for IGEL Base System 12.01, SSO will not function anymore. In this case, you must immediately create an appropriate profile for IGEL OS Base System 12.2, as described in this article.



Important Measures for Devices that Retain Base System 12.01

If some of your devices are to keep IGEL OS Base System 12.01, ensure the following:

- The current SSO profile is set to version 12.01.x of the IGEL OS Base System, not to the default version. This is done by setting the **App Selector** to version **12.01**.x explicitly. If the base system version remains set to the default version, and the default version is then set to 12.2 or higher, the settings will be lost when the profile is saved.
- The current SSO profile (based on IGEL OS Base System 12.01) remains assigned to those devices.


Setting Up a New Profile for Easy IdP Switching

- 1. In the UMS Web App, create a new profile for the IGEL OS Base System based on version 12.2. This can be done by setting the profile's **App Selector** to version **12.2.0** explicitly or by setting the base system's default version to 12.2 and the profile's **App Selector** to **Default version**.
- 2. For your Okta configuration, go to **Security > Logon > Single Sign-On** and edit the settings as follows:

IGEL OS Base System 543 / 647



- Enable Single Sign-On with Identity Provider.
- Set Identity Provider to Okta.
- Provide the Okta URL for your user. This is the Okta organization URL. Example: "https://mycompany.okta.com"
- Provide the **Client ID**. This is the client ID that was created in Okta.
- Provide the Client secret.




- 3. For your Microsoft Entra configuration, go to **Security > Logon > Single Sign-On** and edit the settings as follows:
 - Enable Single Sign-On with Identity Provider.
 - Set Identity Provider to Azure ID.
 - Enter the **Azure AD Tenant Name/ID**. This is the value you have obtained as **Directory** (tenant) ID in the Microsoft Entra Portal.
 - Set the appropriate **Application (client) ID**. This is the value you have obtained as **Application (client) ID** in your Microsoft Entra ID Portal.
 - Enter the Client secret.



The secret for Microsoft Entra ID can only be viewed once. If you have not stored it, you need to generate a new one.

IGEL OS Base System 544 / 647






- 4. Assign this profile to all relevant devices.
- 5. If you want to switch between Okta and Microsoft Entra ID, simply select the appropriate **Identity Provider**:

IGEL OS Base System 545 / 647





IGEL OS Base System 546 / 647



How to Configure Single Sign-On (SSO) on IGEL OS 12

With IGEL OS 12, you can use Single Sign-On (SSO) via a cloud-based identity provider (IdP) to access the local device and apps.

The following identity providers are supported:

- Okta
- Microsoft Entra ID (formerly known as Microsoft Azure AD)
- Ping Identity | PingOne
- VMware Workspace ONE Access

Generally, IGEL OS 12 supports OpenID Connect authentication. For IdPs that adhere closely to this standard, there is a good chance that they can be used with IGEL OS 12.



Generally, you can edit the IGEL OS 12 device configuration as follows:

- via the IGEL UMS Web App:
 - Configuration > Create new profile (You select one or several apps that will be configured by the profile. If the IGEL OS base system app is selected, all other apps are shown under the tab "Apps"; if not, each app is displayed as a separate tab)
 - Apps > [name of the app] > Create new profile (used to quickly configure a profile for the selected app. It is also possible to add other apps that will be configured by this profile)
 - **Devices > [name of the device] > Edit Configuration** (shows all installed apps. Apps are displayed under the tab "Apps")
- via IGEL Setup locally on the device (shows all installed apps. Apps are displayed under the tab "Apps")

The best practice to configure your devices is via profiles. For details on how to create profiles, see (en) IGEL UMS 12: Basic Configuration.

Apps and Utilities for IGEL OS 12 That Support SSO with Microsoft Entra ID

- IGEL Azure Virtual Desktop Client (AVD)
- Zoom client (SSO via Chromium)
- Web apps, e. g. Office 365 (SSO via Chromium)
- Device login
- Screenlock

Apps and Utilities for IGEL OS 12 That Support SSO with Okta

- Web apps, e. g. Okta portal (SSO via Chromium)
- Device login
- Screenlock

547 / 647 **IGEL OS Base System**



Apps and Utilities for IGEL OS 12 That Support SSO with Ping Identity / PingOne

- Web apps (SSO via Chromium)
- Device login
- Screenlock

Apps and Utilities for IGEL OS 12 That Support SSO with VMware Workspace ONE Access

- VMware Horizon (if Chromium is used for authentication)
- Web apps (SSO via Chromium)
- Device login
- Screenlock

Apps and Utilities for IGEL OS 12 That Support SSO with Other IdPs

- Web apps (SSO via Chromium)
- Device login
- Screenlock

Setting up SSO with Microsoft Entra ID


To enable SSO with Entra ID on IGEL OS 12 devices, an Entra application must be registered first. Then, you can configure IGEL OS 12 to use this application for authentication; the Entra application is referenced via its Public Client Identifier.

Registering an Entra Application

- 1. In your Entra AD Portal, go to **App registrations > New registration**.
- 2. Edit the data as follows and then click **Register**:
 - Add a proper name for the application. Note that this name will be visible to the user once during the consent process for granting permissions. In our example, "IGEL OS Single signon" is used as the name.
 - Select the option Accounts in this organizational directory only ([name of your organization's AD Portal] only Single tenant).
 - Under Redirect URI (optional), select the option Public client/native (mobile & desktop) and enter "http://localhost/callback" as the URI.

IGEL OS Base System 548 / 647






3. Check if the **User.Read** permission is granted.

IGEL OS Base System 549 / 647






4. Click Add a permission.

IGEL OS Base System 550 / 647






5. Select Microsoft Graph.

IGEL OS Base System 551 / 647






6. Select **Delegated permissions**.

IGEL OS Base System 552 / 647






7. Enable the following permissions and then click **Add permissions**:

- email
- openid
- profile

IGEL OS Base System 553 / 647






8. Check if the permissions are correct.

IGEL OS Base System 554 / 647






9. Go to Certificates & secrets and click New client secret.

IGEL OS Base System 555 / 647






10. Enter a **Description**, define when the secret **Expires**, and then click **Add**.

IGEL OS Base System 556 / 647







11. Copy the **Value** of the client secret.

IGEL OS Base System 557 / 647





12. Go to **Overview** and copy the **Application (client) ID** and the **Directory (tenant) ID**. In the IGEL OS configuration, these values will be used as the **Public client identifier (client/application ID)** and the **Azure ID Tenant Name/ID**.




IGEL OS Base System 558 / 647



Configuring IGEL OS for SSO with Entra ID

- 1. Go to **Security > Logon > Single Sign-On** and edit the settings as follows:
 - Enable Single Sign-On with Identity Provider.
 - Set Identity Provider to Azure ID.
 - Enter the Azure AD Tenant Name/ID. This is the value you have obtained as Directory (tenant) ID in Azure AD Portal.
 - Set the appropriate **Application (client) ID**. You have obtained this value as **Application** (client) ID in your Azure AD Portal.
 - Enter the Client secret.



- 2. If you want to use an automatic desktop login with predefined credentials that are stored securely on your endpoint device:
 - Enable Automatically perform login.
 - Under **Username for autologin**, enter a user's name known to your IdP.
 - Under **Password for autologin**, enter the enter the corresponding password.



A Please be aware that after the automatic desktop login, a fully unlocked desktop session will run on your endpoint device. This feature should only be used for use cases where no interactive login is possible. It is good practice to restrict this user's access to only the relevant components and data that are necessary for the specific use case.

Please also note that Multi-Factor Authentication (MFA) is not possible when automatic login is enabled.

3. Click Save or Save and close.

The desktop of the device is terminated. The login screen is displayed.

IGEL OS Base System 559 / 647




You can now use the apps and utilities for IGEL OS 12 that support SSO with Entra ID (see page 547). For details on importing apps from the IGEL App Portal and installing them on IGEL OS devices, see (en) IGEL UMS 12: Basic Configuration.

All methods of multi-factor authentication are available except the hardware token.

Configuring SSO with Okta

Registering an Application in Okta

1. Log in to Okta with your admin account, and from the **Applications** menu, select **Applications Create App Integration**.




- 2. Edit the settings as follows and then click **Next**.
 - Set Sign-in method to OIDC OpenID Connect.

IGEL OS Base System 560 / 647




Set Application type to Native Application



- 3. Edit the settings as follows and then click **Save**.
 - Under **App integration name**, enter a name for your application, e.g. "IGEL OS Single signon".
 - Make sure that as the **Grant type**, the option **Authorization Code** is selected.
 - Under Sign-in redirect URIs, enter "http://localhost/callback".

IGEL OS Base System 561 / 647






The app integration is created.

4. Select the **General** tab and then click **Edit**.

IGEL OS Base System 562 / 647






5. Under Client authentication, select Client secret and make sure that under Proof Key for Code Exchange (PKCE), Require PKCE as additional verification is enabled. Afterward, click Save.

IGEL OS Base System 563 / 647






The client secret will be created.

6. Copy the **Client ID** and the **Secret** (client secret).

IGEL OS Base System 564 / 647






Configuring IGEL OS for SSO with Okta

- 1. Go to **Security > Logon > Single Sign-On** and edit the settings as follows:
 - Enable Single Sign-On with Identity Provider.
 - Set Identity Provider to Okta.
 - Provide the **Okta URL** for your user. This is the Okta organization URL. Example: "https://mycompany.okta.com/"
 - Provide the Client ID. This is the client ID that was created in Okta.
 - Provide the Client secret.

IGEL OS Base System 565 / 647





- 2. If you want to use an automatic desktop login with predefined credentials that are stored securely on your endpoint device:
 - Enable Automatically perform login.
 - Under **Username for autologin**, enter a user's name known to your IdP.
 - Under **Password for autologin**, enter the enter the corresponding password.

A

Please be aware that after the automatic desktop login, a fully unlocked desktop session will run on your endpoint device. This feature should only be used for use cases where no interactive login is possible. It is good practice to restrict this user's access to only the relevant components and data that are necessary for the specific use case.

Please also note that Multi-Factor Authentication (MFA) is not possible when automatic login is enabled.

3. Click Save or Save and close.

The desktop of the device is terminated after the profile is applied. The login screen is displayed. You can now use the apps and utilities for IGEL OS 12 that support SSO with Okta (see page 547). If you want to use multi-factor authentication, you can configure this in the Okta console. The available methods are Google Authenticator, E-Mail, and Okta Verify.


Setting up SSO with Ping Identity / PingOne

Setting up Your Application

1. Log in to your Pingldentity account, go to **Applications**, and click the add symbol to create a new application.

IGEL OS Base System 566 / 647






2. Provide an **Application Name**, select **Native** as the **Application Type**, and click **Save**.

IGEL OS Base System 567 / 647






3. Select the **Configuration** tab and click the edit button.

IGEL OS Base System 568 / 647






- 4. Edit the configuration as described below and click **Save**.
 - Response Type: Select Code.
 - Grant Type: Select Authorization Code and set PKCE Enforcement to \$256_REQUIRED.
 - **Redirect URIs**: Enter http://localhost/callback
 - Token Endpoint Authentication Methods: Select Client Secret Post.

IGEL OS Base System 569 / 647







IGEL OS Base System 570 / 647



5. Select the **Resources** tab and click the edit button.



- 6. Ensure that the following resource scopes are activated and click **Save**.
 - email
 - openid
 - profile



IGEL OS Base System 571 / 647



p1:create:device PingOne API	
p1:create:pairingKey PingOne API	
p1:delete:device PingOne API	
p1:delete:pairingKey PingOne API	
p1:delete:sessions PingOne API	
p1:delete:userLinkedAccounts PingOne API	
p1:read:device PingOne API	
p1:read:oauthConsent PingOne API	
p1:read:pairingKey PingOne API	
p1:read:sessions PingOne API	
p1:read:user PingOne API	
p1:read:userConsent PingOne API	
p1:read:userLinkedAccounts PingOne API	
	p1:create:pairingKey PingOne API p1:delete:device PingOne API p1:delete:pairingKey PingOne API p1:delete:sessions PingOne API p1:delete:userLinkedAccounts PingOne API p1:read:device PingOne API p1:read:oauthConsent PingOne API p1:read:pairingKey PingOne API p1:read:sessions PingOne API p1:read:userConsent PingOne API p1:read:userConsent PingOne API p1:read:userConsent PingOne API

IGEL OS Base System 572 / 647




PingOne API	
API p1:reset:userPassword PingOne API	0
API p1:update:device PingOne API	
PingOne API	
API p1:update:user PingOne API	
API p1:update:userMfaEnabled PingOne API	
API p1:validate:userPassword PingOne API	
API p1:verify:user PingOne API	
phone OpenID Connect	
profile OpenID Connect	☑
Save Cancel	

7. Review the list of **ALLOWED SCOPES**.

IGEL OS Base System 573 / 647





- 8. Select the Configuration tab and copy the following data for later use:
 - Client ID
 - Client Secret

IGEL OS Base System 574 / 647






9. Expand the list of **URLs** and copy the **Issuer** URL for later use.

IGEL OS Base System 575 / 647






IGEL OS Base System 576 / 647



10. Activate your application.

IGEL OS Base System 577 / 647






IGEL OS Base System 578 / 647



Configuring IGEL OS for SSO with Ping Identity / PingOne

- 1. Go to **Security > Logon > Single Sign-On** and edit the settings as follows:
 - Enable Single Sign-On with Identity Provider.
 - Set Identity Provider to Ping Identity | PingOne.
 - Provide the PingOne issuer URL for your user. This is the Issuer URL provided in the Ping Identity configuration portal. Example: https://auth.pingone.eu/0815abcxyz123456/as
 - Provide the **Client ID**. This is the client ID that was created in Ping Identity.
 - Provide the Client secret.



- 2. If you want to use an automatic desktop login with predefined credentials that are stored securely on your endpoint device:
 - Enable Automatically perform login.
 - Under **Username for autologin**, enter a user's name known to your IdP.
 - Under **Password for autologin**, enter the enter the corresponding password.

IGEL OS Base System 579 / 647



A

Please be aware that after the automatic desktop login, a fully unlocked desktop session will run on your endpoint device. This feature should only be used for use cases where no interactive login is possible. It is good practice to restrict this user's access to only the relevant components and data that are necessary for the specific use case.

Please also note that Multi-Factor Authentication (MFA) is not possible when automatic login is enabled.

3. Click Save or Save and close.


The desktop of the device is terminated after the profile is applied. The login screen is displayed. You can now use the apps and utilities for IGEL OS 12 that support SSO with Ping Identity / PingOne (see page 548).

If you want to use multi-factor authentication, you can configure this in the Ping Identity console.

Setting up SSO with VMware Workspace ONE Access

Registering an Application in VMware Workspace ONE Access

1. In the VMware Workspace ONE Access console, go to **Settings > OAuth 2.0 Management** and click **Add client**.



- 2. Set up the client as follows and finally click **Save**.
 - Access type: Select User Access Token.
 - Client type: Select Confidential.
 - Client ID: Enter a client ID that suits your needs; respect the allowed characters.

Example: IGEL_OS_SSO

- Grant type: Enable Authorization Code Grant.
- **Redirect URI**: Enter http://localhost/callback
- User grant: Disable Prompt users for scope acceptance.
- Scope: Edit the settings as follows:

IGEL OS Base System 580 / 647



Email: Enabled
Profile: Enabled
User: Disabled
NAPPS: Disabled
OpenID: Enabled
Group: Disabled
Admin: Disabled

- PKCE support: This option is enabled because Authorization Code Grant is selected as the Grant type.
- Issue refresh token: Enable or disable this option according to your needs.
- Access token TTL: Adjust the time to live for the authorization token according to your needs.
- Idle token TTL: Adjust the time to live for the idle token according to your needs.

IGEL OS Base System 581 / 647




SAVE CANCEL	
A secret will be available and autogenerate	ed when you click save
Access type*	User Access Token
Client type*	O Public O Confidential
Client ID*	IGEL_OS_SSO
	Characters allowed are: alphanumeric (A-Z, a-z, 0-9) period (.), underscore (_), and hyphen (-) and at sign (@). 256 characters max.
Grant type * (i)	Client Credentials Grant
3.4	Password Grant
	✓ Authorization Code Grant
	Refresh Token Grant ①
Redirect URI*	http://localhost/callback
User grant	Prompt users for scope acceptance
Scope*	✓ Email ✓ Profile ☐ User ☐ NAPPS
	OpenID Group Admin
21/22	_
PKCE support	PKCE Support is enabled when Authorization Code Grant is selected in Grant type
	Grant is selected in Grant type
Token type	Bearer
Issue refresh token	
Access token TTL *	3 hours ~
Idle token TTL	10 days ~

3. Review the settings and copy the following data for later use:

IGEL OS Base System 582 / 647



- Client ID
- Shared Secret




Configuring IGEL OS for SSO with VMware Workspace ONE Access

- 1. Go to **Security > Logon > Single Sign-On** and edit the settings as follows:
 - Enable Single Sign-On with Identity Provider.
 - Set Identity Provider to VMware Workspace ONE Access.

IGEL OS Base System 583 / 647



- Provide the **Workspace ONE Access issuer URL** for your user. Pattern: https://<YOUR WORKSPACE ONE ACCESS URL>/SAAS/auth
- Provide the Client ID. This is the client ID that was created in VMware Workspace ONE
- Provide the Client secret.



- 2. If you want to use an automatic desktop login with predefined credentials that are stored securely on your endpoint device:
 - Enable Automatically perform login.
 - Under **Username for autologin**, enter a user's name known to your IdP.
 - Under **Password for autologin**, enter the enter the corresponding password.

🛕 Please be aware that after the automatic desktop login, a fully unlocked desktop session will run on your endpoint device. This feature should only be used for use cases where no interactive login is possible. It is good practice to restrict this user's access to only the relevant components and data that are necessary for the specific use case.

Please also note that Multi-Factor Authentication (MFA) is not possible when automatic login is enabled.

IGEL OS Base System 584 / 647



3. Click **Save** or **Save and close**.

The desktop of the device is terminated after the profile is applied. The login screen is displayed. You can now use the apps and utilities for IGEL OS 12 that Support SSO with VMware Workspace ONE Access (see page 548).

If you want to use multi-factor authentication, you can configure this in the VMware Workspace ONE Access portal.

Configuring SSO with Other IdPs That Use OpenID Connect

For setting up your application or client, the exact procedure depends on the exact OpenID Connect solution you are using. Therefore, the settings in the IdP console can only be described generically.

Setting up Your Application / Client

In your IdP console, edit the parameters as follows (the exact parameter names will probably deviate):

Parameter	Values
Response type	code
Scopes	openid, profile, email
Redirect URI	http://localhost/callback
Code challenge method	S256
Response mode	fragment
Client authentication	client_secret_post

Configuring IGEL OS for SSO with Generic OpenID Connect




Please note that automatic login is not possible with generic OpenID connect.

- 1. Go to **Security > Logon > Single Sign-On** and edit the settings as follows:
 - Enable Single Sign-On with Identity Provider.
 - Set Identity Provider to OpenID Connect.
 - Provide the **Issuer URL** for your user. This is the **Issuer** URL provided in the IdP console. Example for Keycloak: https://keycloak.yourcompany.com/realms/yourrealm
 - Provide the **Client ID**. This is the client ID that was created in the IdP console.
 - Provide the Client secret.

IGEL OS Base System 585 / 647





2. Click Save or Save and close.

The desktop of the device is terminated. The login screen is displayed.

You can now use the apps and utilities for IGEL OS 12 that support SSO with OpenID Connect (generic) (see page 548).

For details on importing apps from the IGEL App Portal and installing them on IGEL OS devices, see (en) IGEL UMS 12: Basic Configuration .

For supported multi-factor authentication methods, check the documentation of your IdP.


Enabling Local Login (Optional)

To have a fallback option if something goes wrong with SSO, e.g. a network failure, it is recommended to configure local login in addition.

IGEL OS Base System 586 / 647



- 1. Open the profile configurator and go to **Security > Logon > Local user**.
- 2. Activate **Login with local user password** and enter a password.



IGEL OS Base System 587 / 647



Articles on Integrating IGEL Apps With Your Base System

• How to Set the Default Browser in IGEL OS 12 (see page 589)

IGEL OS Base System 588 / 647



How to Set the Default Browser in IGEL OS 12

If a browser app is installed, it is automatically set as the default browser. If several browsers are installed on your system, you should define a default browser. The default browser will be used for Single Sign-On (SSO).




Importance of Setting a Default Browser Correctly

Please note the following:

- If several browsers are installed and no browser is set as default, the browser whose name is last in alphabetical order is the default. Example: If Chromium, Edge, Firefox, and Island are installed and no default browser is set, Island will be the default browser.
- If several browsers are erroneously set as default, the browser from this selection whose name is last in alphabetical order will be the actual default.

In the following example, we will set the Chromium browser as the default browser.


1. In the Web UMS, open the profile for your desired default browser.



2. Go to System > Registry > app > [your browser] > mimetype > default_browser and enable **Default browser**, and save your settings.

IGEL OS Base System 589 / 647





IGEL OS Base System 590 / 647



Articles about Securing IGEL OS 12

- How to Use Smart Card and Smart Key Authentication in IGEL OS 12 (see page 592)
- How to Mitigate Terrapin Vulnerability through Registry Parameter in IGEL OS (see page 596)
- How to Keep Your IGEL OS 12 System up to Date (see page 597)

IGEL OS Base System 591 / 647



How to Use Smart Card and Smart Key Authentication in IGEL OS 12

In IGEL OS 12 you can enable smart card authentication to Microsoft Azure Virtual Desktops (AVD) by leveraging Microsoft Entra Certificate-Based Authentication (CBA). This article guides you through the necessary configurations. You can also see the blog post for an overview: https://www.igel.com/blog/authentication-to-windows-365-with-igel-smart-card/.



For more information on the Common Access Card (CAC) / Personal Identity Verification (PIV) smart cards and Yubikey PIV supported by IGEL, see https://www.igel.com/blog/cac-piv-smart-cards-yubikey-and-more-insider-tips-on-how-igel-os-use-both/.

Prerequisites

- IGEL OS Base System version 12.6.0 or higher
- IGEL AVD App verison 1.3.0 or higher



US Military / Government customers need to contact their regional IGEL representative for the complete configuration.

Process Overview

- 1. If you are a US Military / Government customer, contact the regional IGEL representative for configuration support.
- 2. Configure Microsoft Entra ID Certificate Based Authentication as described in https://learn.microsoft.com/en-us/entra/identity/authentication/concept-certificate-based-authentication.
- 3. Configure Smart Card Middleware in IGEL OS.
- 4. Configure AVD in IGEL UMS Web App.
- 5. Test the authentication on the IGEL OS endpoint device.

Configure Smart Card Middleware

IGEL has a built-in OpenSC that you can use as middleware, or you can choose a middleware from the IGEL App Portal.

Built-in OpenSC as Middleware

1. In the profile configurator, go to System > Registry > scard > pkcs11 > use_opensc


IGEL OS Base System 592 / 647



2. Enable the parameter.

Smart Card Middleware from IGEL App Portal

- 1. Go to the IGEL App Portal⁶⁷.
- 2. Open the **Smartcard** category.



- 3. Choose an app and import to the IGEL UMS.
- 4. Install the app on the IGEL OS endpoints according to your app distribution process.
- 5. Reboot the endpoint devices.

 The middleware will become active automatically.

67. https://app.igel.com/

IGEL OS Base System 593 / 647




Configure the AVD Session in IGEL UMS Web App

1. Import the AVD app from the IGEL App Portal to your UMS.



- 2. Create a new profile. For details, see How to Create and Assign Profiles in the IGEL UMS Web App⁶⁸.
- 3. Select **OS 12** (shown only if there are OS 11 devices registered in the UMS) and enter the **name** of the profile.
- 4. Click **Select Apps** and select **IGEL Azure Virtual Desktop**.
- 5. Click Save.
- 6. Go to Apps > AVD > AVD Sessions.
- 7. Click + to create a new session and add a **Session Name**.
- 8. Go to the **Advanced Options** of the session.



68. https://kb.igel.com/en/universal-management-suite/current/how-to-create-and-assign-profiles-in-the-igel-ums-

IGEL OS Base System 594 / 647



- 9. Enable Microsoft Authentication Library (MSAL)
- 10. Go to **System > Registry.**
- 11. Go to the registry key **scard.scwatchd.enable** and enable **Smart Card Insert and Removal Actions**.

This will allow executing commands when a hardware event is triggered by inserting or removing the smart card from the reader.

12. Go to **scard.scwatchd.insert_action** and set the following command as the value:

```
export avduser=$(pkcs11getloginname | grep "^Login:" | sed -e "s/^Login://"); su -c
"appwrap avd0 avd" user
```

This will read out the User Principal Name (UPN) on smart card insert and start the session.

13. Go to **scard.scwatchd.removal_action** and set the following command as the value:

```
export avduser=""; killall -9 igelrdp3-avd; killall -9 igelrdp3-msal-auth
```

This will reset the 'avduser' variable and hard kill the running processes to disconnect from the Windows 365 session.

14. Go to app.avd.sessions.avd0.options.cmd_ext and set the following command as the value:

```
--username $avduser
```

This will tell the IGEL AVD App to set the username to the previously retrieved UPN during the card insert.

Test Authentication

Once the configurations are applied, you should test the authentication process on the endpoint device.

You should get a similar experience as in the below demo video:



Sorry, the widget is not supported in this export. But you can reach it using the following URL:

https://www.youtube.com/watch?v=R3068gY17TQ

IGEL OS Base System 595 / 647




How to Mitigate Terrapin Vulnerability through Registry Parameter in IGEL OS

To mitigate Terrapin Vulnerability, you can enable a registry parameter that will disable weak MACs and Chipers to prevent terrapin attacks. For more information on terrapin attacks and the related CVE-2023-48795, see Security & Safety > IGEL Product Security Information > ISN 2023-39: SSH Terrapin Vulnerability and https://terrapin-attack.com/ and https://cve.mitre.org/cgi-bin/cvename.cgi?name=2023-48795.



If you use OpenSSH 9.6p1 both on the client and server there is no need to use this registry parameter. IGEL OS versions 12.3.1 or higher use the latest OpenSSH 9.6p1. When you use this version or newer on the peer, they will automatically use the new "strict KEX" protocol extension.



To enable Terrapin mitigation through the registry parameter:

- 1. In configuration, go to System > Registry > network > ssh_server > enable_terrapin_mitigation.
- 2. Enable the parameter.
- 3. Click **Save** or **Save and Close** to save the change.

The following options vulnerable to Terrapin attack are disabled:

- the ChaCha20-Poly1305 cipher
- all -cbc ciphers
- all -ctr ciphers
- all -etm@openssh.com macs

IGEL OS Base System 596 / 647



How to Keep Your IGEL OS 12 System up to Date

Rationale

Software updates fix newly discovered vulnerabilities in the IGEL OS Base System and the apps installed. This means that keeping up with updates is one of the most important measures in securing IGEL OS systems.

Prerequisites

- Your devices are managed by the Universal Management Suite (UMS) 12
- Your Universal Management Suite (UMS) has access to the IGEL App Portal. It must be registered for this; see (en) Registering the UMS.
- Your devices have valid licenses

Receiving regular safety information

→ To get new ISNs and ISN updates delivered to your inbox, subscribe to the Security Announcements Mailing List. Go to http://igel.com and find the "Subscribe for Updates" form at the bottom of the page. This will initially subscribe you to all mailings from IGEL, but by using the unsubscribe link at the bottom of a mail, you can select which communications you wish to receive and which not.

Before You Begin

As the steps for the Base System differ from those for the other apps, the procedure is as follows:

- Setting the UMS to Update Regularly (see page 597)
- House Keeping: Delete Older, Unused Versions Regularly (see page 600)
- Setting up a Test Directory (see page 601)
- Keeping the Base System up to Date (see page 604)
 - Testing the Base System Updates on One or a Few Devices (see page 604)
 - Rolling out the Base System Update on All Devices (see page 622)
- Keeping Other Apps up to Date (see page 626)
 - Testing the App Updates on One or a Few Devices (see page 626)
 - Rolling out the App Update on All Devices (see page 630)

Setting the UMS to Update Regularly


To ensure you have every version of your apps available in the UMS, we will set the UMS to import new versions automatically.


Follow these steps for each app installed on your devices. We will use the Base System as an example.

1. In your UMS Web App, go to **APPS** and then open the **Update Settings**.

IGEL OS Base System 597 / 647









2. Enable Check for updates and auto-import into UMS and Update Default Version manually.

IGEL OS Base System 598 / 647






The UMS is now kept always up-to-date. The latest software versions are imported automatically. As **Update Default Version manually** is selected, the updates are not automatically rolled out to the devices.



IGEL OS Base System 599 / 647






House Keeping: Delete Older, Unused Versions Regularly

If you have configured your UMS to import every new version of your imported apps, as described above, you should dispose of older, unused versions. It is recommended to do this regularly.

→ In your UMS Web App, go to the app version in question and click to remove it.

IGEL OS Base System 600 / 647






Setting up a Test Directory


It is highly recommended that test devices be put into a separate directory.

1. In your UMS Web App, go to **DEVICES** and create a directory for your test devices, e.g., "Update test".



IGEL OS Base System 601 / 647







IGEL OS Base System 602 / 647




3. Find your test devices and put them into the new test directory using drag & drop.





603 / 647 IGEL OS Base System






Keeping the Base System up to Date

Testing the Base System Updates on One or a Few Devices

To prepare for testing the Base System update, we will proceed in two steps:

- 1. Create a test profile to be able to activate or configure new features, e.g. security features of the new Base System version
- 2. Assign the new Base System version explicitly to the test devices




Creating the Test Profile

To create a test profile, we will duplicate the productive profile by exporting and re-importing it.

1. In your UMS Web App, go to the **Configuration Objects** and then find the relevant profile.

IGEL OS Base System 604 / 647







2. Click **Export Profile** and save the file on your machine.

IGEL OS Base System 605 / 647









4. Click and import the file.

IGEL OS Base System 606 / 647









IGEL OS Base System 607 / 647






The imported profile is displayed underneath the original profile. The imported profile can be distinguished from the original one by its ID, which is higher.




4. Select the imported profile, and click / to change the name appropriately.

IGEL OS Base System 608 / 647







5. Set the app version of the test profile to the target version.


IGEL OS Base System 609 / 647

Screenshot Tool

System Log Viewer
 Task Manager


8₽ App Selector






IGEL OS Base System 610 / 647





IGEL OS Base System 611 / 647






Assigning the Profiles to the Test Devices

1. Find your test devices and detach the relevant productive profiles from each test device.

IGEL OS Base System 612 / 647






2. Assign the test profile to your test directory.


IGEL OS Base System 613 / 647






IGEL OS Base System 614 / 647






IGEL OS Base System 615 / 647





IGEL OS Base System 616 / 647






Assigning the New Base System Version to the Devices

1. Go to each of your test devices and check under **Assigned Objects** if a version of the IGEL OS Base System is assigned to the device.

IGEL OS Base System 617 / 647







2. Move your mouse to the right side of the **IGEL OS Base System** entry; if a **Detach object** button (appears, click it and confirm your change.

IGEL OS Base System 618 / 647








3. Go to the test directory and click **Assign Object**.

IGEL OS Base System 619 / 647






2. In the dialog **Assign Object to Directory**, choose the desired version of the IGEL OS Base System and assign it to the directory.


IGEL OS Base System 620 / 647





IGEL OS Base System 621 / 647






After a dialog timeout, the devices update to the new version of the IGEL OS Base System. You can perform your tests as appropriate.

Rolling out the Base System Update on All Devices

1. Go to your productive profile and ensure it is set to use the default version of the app.


IGEL OS Base System 622 / 647






IGEL OS Base System 623 / 647






2. In the apps section, select the app to be updated, and click **Set Default Version**.




IGEL OS Base System 624 / 647



2. Set the default version to the version you have tested successfully.



3. Choose whether the update should take place immediately or on the next reboot.



On reboot, the devices update their Base System to the default version.


IGEL OS Base System 625 / 647



Keeping the Other Apps up to Date

Testing the App Updates on One or a Few Devices


1. Go to each of your test devices and check under **Assigned Objects** if a version of the app is assigned to the device.




2. Move your mouse to the right side of the app's entry; if a **Detach object** button (appears, click it and confirm your change.

IGEL OS Base System 626 / 647








3. Go to the test directory and click **Assign Object**.

IGEL OS Base System 627 / 647






2. In the dialog **Assign Object to Directory**, choose the desired version of the app and assign it to the directory.


IGEL OS Base System 628 / 647





IGEL OS Base System 629 / 647






After a dialog timeout, the device reboots to install the new version of the app. You can perform your tests as appropriate.

Rolling out the App Update on All Devices


1. In the apps section, select the app to be updated, and click **Set Default Version**.

IGEL OS Base System 630 / 647






2. Set the default version to the version you have tested successfully.



3. Choose whether the update should take place immediately or on the next reboot.

IGEL OS Base System 631 / 647






4. Go to the directory that contains your productive devices and click **Assign Object**.


IGEL OS Base System 632 / 647





IGEL OS Base System 633 / 647





On reboot, the devices update their app to the new version.

IGEL OS Base System 634 / 647



Articles about Hardware-Related Topics

- How to Handle More Than One Touchscreen in IGEL OS 12 (see page 636)
- How to Use Multiple GPUs in IGEL OS 12 (see page 638)
- Troubleshooting USB Fiber Network Adapter Does Not Work on IGEL OS (see page 640)

IGEL OS Base System 635 / 647



How to Handle More Than One Touchscreen in IGEL OS 12

If you connect multiple touchscreens to your IGEL OS device, you can configure them either using the configuration options or through script.

Prerequisites

You need OS Base System version 12.2.2 or higher.

Using the Configuration Options

To configure multiple touchscreens:

- Connect only one touchscreen and configure it using the options under User Interface > Input >
 Touchscreen, section Multimonitor. For details, see Touchscreen Configuration in IGEL OS 12 (see page 92).
- 2. If the first touchscreen works, connect the next touchscreen.

 It will get assigned to the next monitor in the monitor order. The order is the numbering shown by screenid or in the display tray app.
- 3. If you have more than 2 monitors, continue connecting them this way.

 The touch screen to monitor assignment can be done through the monitor order.

Using a Script

To configure touchscreens using a script:

- 1. Connect the touchscreens.
- 2. Check which touchscreens are available with fix_touchscreen_matrix show. It should show you something like this:

```
Found Touchscreen: Name: UNITEC USB Touch (Windows 8)

XID: 19

USB: Bus 1 Port 2 -> HUB Port 2 -> HUB Port 3 (conf entry: usb1-2.2-port3)

Configured for screen: dp1 (DisplayPort)

Available connected monitors setup name: dp1 screenid name: DisplayPort X11 name: DP-1

Available connected monitors setup name: dp2 screenid name: DisplayPort(II) X11 name: DP-2
```

IGEL OS Base System 636 / 647



```
Starting screenid to identify connected monitors.
Script will exit if screenid is closed
```

- The screenid will make it easier to identify the correct monitor.
 - 2. For configuration (that is, assigning the touchscreens to the monitors), create a /wfs/user/ touchconf.ini file with the information from above. The file should look like this:

```
# Format usb<bus num>[-[portnum]]-port<portnum>-><conn setup name>
# Use fix_touchscreen_matrix show to get the needed data (conf entry: ... contains
\# Setup name: ... is the setup connector name you should use
# a entry could look like this: usb1-2.3.1-port3->dp2
usb1-2.2-port3->dp1
usb1-2.3.1-port3->dp2
```

IGEL OS Base System 637 / 647



How to Use Multiple GPUs in IGEL OS 12

If you run IGEL OS 12 on a device with multiple physical GPUs and multiple monitors, you need to check GPU configurations and you may need to modify them to successfully operate all connected screens. This article provides general explanation and the necessary configurations for a multi-4K monitor setup.


Primary and Secondary GPU in Linux

To find the right configuration, we need to understand how Linux uses multiple GPUs for an extended desktop across multiple monitors. When several screens are in use, the Linux driver merges multiple physical GPUs into one logical X screen by having one GPU (the primary GPU) doing all the rendering for all the screens. The secondary GPU only receives a copy of the frame buffers that it needs to display.

The internal GPUs of the devices are usually slower, thus the GPU on the add-in card (from now called the external GPU) would be better as primary GPU, because the primary GPU does all the rendering. However, if the external GPU doesn't have sufficient memory (e.g. minimum 2GB VRAM) it may run out of memory when asked to render for all connected screens (especially if 4K screens are involved). In this case, it is better to configure the internal GPU to have more memory and use it as the primary GPU despite the performance loss - otherwise, some screens may remain blank.

Example Configuration for the Use Case of Six 4K Monitors with HP Elite t755

When you are connecting six 4K monitors to a HP Elite t755, you need to consider GPU settings to successfully operate all screens. Go through the decision tree and perform the necessary configurations described below.



IGEL OS Base System 638 / 647



1. Enable GPUs from different manufacturers under **System > Registry** using x.drivers.<hw>.use_modesetting, <hw>. amdgpu|ati|intel|nouveaux|nvidia|...



if the GPUs use different drivers (usually different vendors, e.g. Intel and Nvidia), you need to turn on modesetting_driver on all involved GPU drivers.

For more information on registry parameters, see Registry in IGEL OS 12 (see page 353).

2. Check the VRAM of the external GPU. If the external GPU has less than 2 GB VRAM, it should be operated as a secondary GPU. This way, it only needs to maintain the frame buffer for the two displays attached to it.

To configure the external GPU as the secondary GPU:

- a. In the configuration dialog go to System > Registry > x > drivers > swap_card0_with_card1.
- b. Enable Make the secondary graphic card to the primary one.



Configuring this in the BIOS does not yield the expected result because the BIOS only defines which GPU to use for boot messages.

- 3. If the internal GPU is used as primary GPU, you need to assign 2GB VRAM to the internal GPU to guarantee that it has enough VRAM to render all screen content. This needs to be done by forcing the corresponding setting in the BIOS:
 - a. Start the HP BIOS (Setup Utility) by pressing F10 during boot.
 - b. Navigate to **Advanced > Device Options > Auto**.
 - c. Then press the key "cursor left" and the word **Auto** will change to **Force**.
 - d. Now navigate one line down to **UMA Frame Buffer Size** and change the 512MB to 2048MB.
 - e. Leave the **Device Options** by pressing [F10] for Accepting the change.
 - f. Then navigate to File > Save Changes and Exit.
 - g. Press [Enter] to save this change.



If the internal GPU doesn't have enough VRAM, the driver will allocate system memory to alleviate the situation. This helps at first but fails during a suspend/resume cycle when the driver tries to re-allocate the system memory. As a result, the two monitors connected to the external GPU remain dark.

639 / 647 **IGEL OS Base System**



Troubleshooting - USB Fiber Network Adapter Does Not Work on IGEL OS

You use fibre-to-USB adaptors with your IGEL OS 12 devices. IGEL OS can see the adaptor, but no network trafic is transmitted.

Problem

Some USB ethernet fiber adaptors work with 4.4.x kernel but not with newer ones.

Solution

As of IGEL OS 12.7.1, you can activate the asix_thirdparty driver to get some fibre USB ethernet adapters to work.


- 1. In the Profile Configurator, create a profile for IGEL OS Base System. For more information on profile creation, see How to Create and Assign Profiles in the IGEL UMS Web App⁶⁹.
- 2. Go to **System > Registry** and enbale the following registry key:

Parameter	Use thirdparty asix kernel module.
Registry	network.drivers.asix.prefer_thirdpart
Range	[Auto] [Yes] [No]
Value	Auto

IGEL OS Base System 640 / 647

^{69.} https://kb.igel.com/en/universal-management-suite/current/how-to-create-and-assign-profiles-in-the-igel-ums-





IGEL OS Base System 641 / 647



Articles on Miscellaneous Topics

IGEL OS Base System 642 / 647



Troubleshooting: Error Message "Problem with libva for Chromium 2.16.0 BUILD 3.0 RC1" after Reboot

Environment

- A version of IGEL OS between 12.3.0 and 12.4.1 is installed on the device
- The Chromium app is installed on the device
- The app "libva for Chromium" is not assigned to the device
- Automatic update on boot is enabled on the device (System > Update > Check for and download updates for non pinned apps on boot or System > Update Check for and download updates for non pinned apps on given calendar time, use the crontab syntax to specify the calendar time)

Problem

On bootup, the device shows the error message "Problem with libva for Chromium 2.16.0 BUILD 3.0 RC1".

Background: Because the library app "libva for Chromium" is installed as a dependency app for Chromium, it has been updated to the version that Chromium requires, which is 2.19.0+0.1.rc.1. This version is supported by IGEL OS 12.5.0 or higher; it can not be installed with IGEL OS 12.4.1 and earlier.

However, apart from the error message, there should be no issue; video playback should work as usual.

Solution

There are three possible solutions:

- Update IGEL OS Baye System to 12.4.2 or higher (release planned for the 18th of July, 2024).
 IGEL OS Base System 12.4.2 recognizes if the reason why the latest version of "libva for Chromium" can not be installed lies in other dependencies, like the Base System, and avoids needless error messages.
- Assign the app "libva for Chromium" explicitly in the appropriate version
- Disable automatic update on boot (System > Update > Check for and download updates for non pinned apps on boot or System > Update Check for and download updates for non pinned apps on given calendar time, use the crontab syntax to specify the calendar time)

IGEL OS Base System 643 / 647



Starting Methods for Apps

For all sessions that can be started by the user, a selection of starting methods is provided.

Session name: Name for the session.



Starting Methods for Session

Start menu

✓ The session can be launched from the start menu.

Menu folder

If you specify a folder name or a path comprising a number of folder names separated by "/", a menu path will be created for the session. The menu path will be used in the start menu and in the desktop context menu.

Start menu's system tab

✓ The session can be launched with the start menu's system tab.

Application Launcher

✓ The session can be launched with the Application Launcher.

Application Launcher folder

If you specify a folder name or a path comprising a number of folder names separated by "/", a menu path will be created for the session. The menu path will be used in the Application Launcher.

Desktop

✓ The session can be launched with a program launcher on the desktop.

Desktop folder

If you specify a folder name or a path comprising a number of folder names separated by "/", a menu path will be created for the session. The menu path will be used for the program launcher on the desktop.

Desktop context menu

IGEL OS Base System 644 / 647



✓ The session can be launched with the desktop context menu.

Quick start panel

✓ The session can be launched with the quick start panel.

Password protection

Specifies which password will be requested when launching the session.

Possible values:

- **None**: No password is requested when launching the session.
- Administrator: The administrator password is requested when launching the session.
- **User**: The user password is requested when launching the session.
- **Setup user**: The setup user password is requested when launching the session.



Password protection only works if the selected password is configured under Security > Password. Without the password configuration, the session will launch without requesting a password. For more information, see Password and User Types in IGEL OS 12 (see page 233).

Hotkey Configuration

Hotkey

 $|\vec{v}|$ The session can be started with a hotkey. A hotkey consists of one or more **modifiers** and a **key**.

Modifiers

A modifier or a combination of several modifiers for the hotkey. You can select a set key symbol/combination or your own key symbol/combination. A key symbol is a defined chain of characters, e.g. Ctrl.



Do not use [AltGr] as a modifier (represented as Mod5). Otherwise, the key that is configured as a hotkey with AltGr cannot be used as a regular key anymore. Example: If you configure [AltGr] + [E] as a hotkey, it is impossible to enter an "e".

These are the pre-defined modifiers and the associated key symbols:

- (No modifier) = None
- 17 = Shift
- [Ctrl] = Ctrl
- # = Mod4

IGEL OS Base System 645 / 647



When this keyboard key is used as a modifier, it is represented as Mod4; when it is used as a key, it is represented as Super_L.

• [Alt] = Alt

Key combinations are formed as follows with |:

• Ctrl+# = Ctrl|Super_L

Key

Key for the hotkey

1 To enter a key that does not have a visible character, e. g. the [Tab] key, open a terminal, log on as user and enter xev -event keyboard. Press the key to be used for the hotkey. The text in brackets that begins with keysym contains the key symbol for the **Key** field.

Example: Tab in (keysym 0xff09, Tab)

Autostart Configuration

Autostart

✓ The session will be launched automatically when the device boots.

Restart

✓ The session will be relaunched automatically after the termination.

Autostart delay

Waiting time in seconds between the complete startup of the desktop and the automatic session launch.

Autostart notification

This parameter is available if **Autostart** is activated and **Autostart delay** is set to a value greater than zero.

For the duration defined by **Autostart delay**, a dialog is shown which allows the user to start the session immediately or cancel the automatic session start.

☐ No dialog is shown; the session is started automatically after the timespan specified with **Autostart delay**.

IGEL OS Base System 646 / 647



Autostart requires network

✓ If no network is available at system startup, the session is not started. A message is shown. As soon as the
network is available, the session is started automatically.
\square The session is started automatically, even when no network is available.

IGEL OS Base System 647 / 647